

## User Manual

Version V1.23-20230627



# Nuwa App User Manual

©2023 Tersus GNSS Inc. All rights reserved.



Sales enquiry: [sales@tersus-gnss.com](mailto:sales@tersus-gnss.com)

Technical Support: [support@tersus-gnss.com](mailto:support@tersus-gnss.com)

More details, please visit [www.tersus-gnss.com](http://www.tersus-gnss.com)

## Revision History

Revision	Description	Date	Owner
1.0	Issued for Release	2018/08/08	LC
1.1	Added detailed description for device info and satellite info interfaces; Added predefined CRS for users to import; Added Geoid CRS option; Update section 4.7 Base Shift; Added chapter for TC20 controller; Added section 7.4 Issues and Solutions; Other minor changes and fixes.	2018/12/28	LC
1.2	Updated section 1.2 Installation; Added section 1.3 Update Nuwa; Updated cover photo; Updated section 7.2.2 File Downloading and section 7.2.3 Data Post Processing	2019/04/03	LC
1.3	Updated section 3.1 Connect.	2019/05/29	LC
1.4	Updated screenshots in section 2.2 and 4; Added Oscar configuration in section 3.3 & 3.4; Added electronic bubble in section 3.5, 4.1 to 4.3; Updated section 5.2 to Azimuth Distance; Updated pictures in section 6.3 & 6.4 TC20 controller; Updated section 4.1 adding linework function.	2019/11/06	LC
1.5	Updated section 2.2.5 adding plane grid; Added SIMA format for import and export; Updated linework function for continued linework; Updated line stakeout function; Added report file function for detail point acquisition; Added L5 SNR display; Added display button for electronic bubble.	2019/12/02	LC
1.6	Added static record duration for static survey; Added NMEA output for Oscar; Added Point On Line Staking for line stakeout.	2020/01/03	LC
1.7	Added <u>Tilt Survey and Stakeout</u> .	2020/02/28	LC
1.8	Added registration file name rules.	2020/03/03	LC
1.9	Added DXF base map and shutting down Oscar when exiting Nuwa app.	2020/04/08	LC
1.10	Updated section 2.6 Import.	2020/04/23	LC
1.11	Updated Tersus logo; Updated registration process; Added <u>Road</u> and <u>Road Stakeout</u> functions; Re-structure section 2.4 Point and section 2.5 Line.	2020/10/15	LC

1.12	<p>Added the functions of sharing point information via QR code and taking photos for the survey point;</p> <p>Added more formats for import and export;</p> <p>Added the selection of coordinate format display;</p> <p>Added simulation connection;</p> <p>Added call sign configuration for Oscar internal radio;</p> <p>Added functions of battery change, device log and satellite system setting when connecting Oscar;</p> <p>Added QR code registration; Staking line and line stake out classify to four circumstances;</p> <p>Added US feet; Added Greek, Bulgarian and Traditional Chinese; DXF base map has point stakeout and line stakeout; Road stakeout has options of by interval and by nearby;</p> <p>Added tools of <u>Earthwork</u>, <u>Angular Bisector</u>, and <u>Grid to Ground</u>.</p>	2021/03/26	LC
1.13	<p>Added PPK survey mode;</p> <p>Added APN setting function and Device debug function in Oscar's device information.</p>	2021/04/27	ZCG
1.14	<p>Added <u>Area Stakeout</u> module;</p> <p>Added <u>CAD Stakeout</u> module;</p> <p>Added tools of <u>Line Segmentation</u>.</p>	2021/07/02	ZCG
1.15	<p>Added selection point from map;</p> <p>Added Control Point survey mode;</p> <p>Added road cross-section point survey;</p> <p>Added tools of <u>Points Avg</u>.</p>	2021/08/03	ZCG
1.16	<p>Added control point check point survey;</p> <p>Added PPK auto survey;</p> <p>Added firmware version check and upgrade function in Oscar's device information;</p> <p>Updated <u>Earthwork</u>.</p>	2021/09/27	ZCG
1.17	<p>Added the description of the new icons in the survey and stakeout interface;</p> <p>Added the line close function;</p> <p>Added the nearest point stakeout function;</p> <p>Added the auto center and auto zoom functions;</p> <p>Added Wifi setting and Lock device in Oscar's device information.</p>	2021/11/12	ZCG
1.18	<p>Updated <u>Quick Start</u>.</p> <p>Updated <u>NMEA Output</u>.</p>	2021/12/20	ZCG
1.19	<p>Added <u>Code</u>.</p> <p>Updated <u>Survey</u>.</p>	2022/03/11	ZCG
1.20	<p>Added <u>DB List</u>.</p>	2022/08/01	ZCG

	Updated <u>Other Import</u> . Updated <u>Surface Stakeout</u> .		
1.21	Added <u>User Agreement</u> . Added <u>Cloud Setting</u> . Updated <u>Main Interface</u> . Updated <u>Site Calibration</u> .	2023/01/05	ZCG
1.22	Added Luka GNSS Receiver related instructions. Updated <u>Point Stakeout</u> , added AR mode description.	2023/03/23	ZCG
1.23	Updated <u>Main Interface</u> , added Base Info. Updated <u>Add new road</u> , added road preview function.	2023/06/27	ZCG



## Table of Content

<b>Revision History .....</b>	<b>ii</b>
<b>Table of Content .....</b>	<b>v</b>
<b>List of Figures .....</b>	<b>ix</b>
<b>Tersus Nuwa App User Agreement .....</b>	<b>1</b>
<b>1. Nuwa Brief Introduction .....</b>	<b>4</b>
1.1 Introduction .....	5
1.2 Installation .....	6
1.3 Update Nuwa .....	8
1.4 Main Interface .....	10
1.5 Quick Start .....	16
<b>2. Project .....</b>	<b>21</b>
2.1 Project .....	22
2.1.1 New .....	22
2.1.2 Import .....	23
2.1.3 Open .....	24
2.1.4 Delete .....	25
2.1.5 Edit Project Property .....	25
2.2 CRS (CooRdinate System) .....	27
2.2.1 New CRS .....	28
2.2.2 Import CRS .....	35
2.2.3 Edit CRS .....	38
2.2.4 Delete CRS .....	38
2.2.5 Plane Grid and Geoid .....	39
2.3 Code .....	41
2.4 Point .....	43
2.4.1 Survey Point .....	43
2.4.2 Control Point .....	48

2.4.3 Staking Point .....	52
2.4.4 DB List .....	56
2.5 Line .....	57
2.5.1 Survey Line .....	57
2.5.2 Staking Line .....	64
2.6 Road .....	68
2.6.1 Add new road .....	68
2.6.2 Edit road .....	73
2.6.3 Delete road .....	74
2.6.4 Import/Export road .....	74
2.7 Import .....	74
2.7.1 Coordinate Import .....	75
2.7.2 Other Import .....	78
2.8 Export .....	80
2.8.1 Coordinate Export .....	81
2.8.2 Other Export .....	82
2.9 Settings .....	85
2.10 Cloud Setting .....	86
<b>3. Device .....</b>	<b>90</b>
3.1 Connect .....	91
3.2 Data Terminal .....	98
3.3 Base .....	101
3.3.1. Set David as a Base .....	102
3.3.2. Set Oscar / Luka as a Base .....	106
3.4 Rover .....	110
3.4.1. Set David as a Rover .....	110
3.4.2. Set Oscar / Luka as a Rover .....	113
3.5 NMEA Output .....	117
3.6 Device .....	118

3.6.1 David's device information .....	118
3.6.2 Oscar / Luka 's device information .....	119
<b>4. Survey .....</b>	<b>126</b>
4.1 Survey .....	127
4.2 Point Stakeout .....	135
4.3 Line Stakeout .....	137
4.4 Tilt Survey and Stakeout .....	142
4.4.1 Tilt Initialization .....	142
4.4.2 Tilt Survey .....	144
4.4.3 Tilt Stakeout .....	146
4.5 Static Survey .....	147
4.5.1 Static data download for David .....	148
4.5.2 Static data download for Oscar / Luka .....	152
4.5.3 Data post-processing .....	154
4.6 Site Calibration .....	156
4.7 Survey Config .....	161
4.7.1 Common Config .....	161
4.7.2 Display Config .....	165
4.8 Base Shift .....	167
4.9 Road Stakeout .....	169
4.10 Surface Stakeout .....	171
4.11 CAD Stakeout .....	173
<b>5. Tools .....</b>	<b>177</b>
5.1 Area Perimeter .....	179
5.2 Azimuth Distance .....	179
5.2.1 Point to Point Distance .....	180
5.2.2 Point to Line Distance .....	180
5.3 Offset Point .....	181
5.3.1 Offset point .....	181

5.3.2 Offset point from line .....	182
5.4 Rotation Point .....	183
5.5 Two Points Intersection .....	184
5.6 Four Points Intersection .....	185
5.7 Intersection Angle .....	186
5.8 Earthwork .....	186
5.9 Angular Bisector .....	189
5.10 Grid to Ground .....	189
5.11 Line Segmentation .....	191
5.12 Points Avg .....	192
5.13 Parameters .....	193
<b>6. TC20 Controller and application .....</b>	<b>196</b>
6.1 Overview of TC20 Controller .....	196
6.2 Outlook of TC20 Controller .....	197
6.3 Accessories of TC20 Controller .....	198
6.4 General Operations .....	199
6.4.1 Insert SIM card and Micro SD card .....	199
6.4.2 Micro SD card .....	202
6.4.3 Using of Touch Screen .....	203
<b>7. Technical Appendix .....</b>	<b>204</b>
7.1 Issues and Solutions .....	204
<b>8. Terminology .....</b>	<b>210</b>
<b>9. File Format .....</b>	<b>211</b>

## List of Figures

Figure 1.1	Nuwa in Google Play Store .....	6
Figure 1.2	Nuwa in Google Play Store – install .....	6
Figure 1.3	Nuwa in Google Play Store – open .....	7
Figure 1.4	Nuwa copied in an android device .....	7
Figure 1.5	Nuwa icon on desktop .....	7
Figure 1.6	Update Nuwa in Google Play Store – 1 .....	8
Figure 1.7	Update Nuwa in Google Play Store – 2 .....	8
Figure 1.8	Version in Settings page .....	9
Figure 1.9	Software Update notification .....	9
Figure 1.10	Nuwa Main Interface .....	10
Figure 1.11	Edit Mode .....	10
Figure 1.12	Satellite Info – Position .....	12
Figure 1.13	Satellite Info – Skymap .....	13
Figure 1.14	Satellite Info – CN0 L1 .....	14
Figure 1.15	Satellite Info – CN0 L2 .....	14
Figure 1.16	Satellite Info – CN0 L5 .....	15
Figure 1.17	Satellite Info – Sat Tab .....	15
Figure 1.18	Base Info .....	16
Figure 1.19	Create Project .....	17
Figure 1.20	Connect .....	17
Figure 1.21	Base Configure .....	18
Figure 1.22	Rover Configure .....	18
Figure 1.23	Survey .....	19
Figure 1.24	Point Stakeout .....	19
Figure 1.25	Line Stakeout .....	19
Figure 2.1	Functions under Project .....	21
Figure 2.2	Create Project interface .....	22

Figure 2.3	New project created .....	23
Figure 2.4	Project folders in an Android device .....	24
Figure 2.5	Sketch file containing the project info .....	24
Figure 2.6	Open an existing project .....	25
Figure 2.7	Delete Project .....	25
Figure 2.8	Project List .....	26
Figure 2.9	Project Property .....	26
Figure 2.10	Share Project Info .....	27
Figure 2.11	Coordinate System List .....	28
Figure 2.12	Create a new CRS .....	28
Figure 2.13	Ellipsoid list .....	29
Figure 2.14	Projection interface .....	29
Figure 2.15	Projection list .....	30
Figure 2.16	Datum transformation options .....	31
Figure 2.17	Bursa Parameters .....	31
Figure 2.18	Plane adjustment interface .....	32
Figure 2.19	Plane adjustment options .....	32
Figure 2.20	4 Parameters .....	32
Figure 2.21	Height fitting interface .....	33
Figure 2.22	Parameters fitting options .....	33
Figure 2.23	Height Fitting – Parameters Fitting .....	33
Figure 2.24	Scan QR code to get CRS info .....	34
Figure 2.25	CRS info obtained by scanning QR code .....	35
Figure 2.26	Predefined CRS .....	35
Figure 2.27	Continent options .....	36
Figure 2.28	Preview of predefined CRS .....	36
Figure 2.29	Example of CRS import .....	37
Figure 2.30	Edit Coordinate System .....	38
Figure 2.31	Delete CRS .....	38

Figure 2.32	Plane Grid list .....	39
Figure 2.33	Plane Grid download list .....	39
Figure 2.34	Geoid list .....	40
Figure 2.35	Geoid download list .....	40
Figure 2.36	Explore Geoid folder in the android device .....	40
Figure 2.37	Refresh to view the Geoid list .....	41
Figure 2.38	Code List .....	42
Figure 2.39	Add Code .....	42
Figure 2.40	Survey Point Interface .....	43
Figure 2.41	Add Survey Point .....	44
Figure 2.42	Edit Survey Point .....	44
Figure 2.43	View details of Survey Point .....	45
Figure 2.44	Point Query interface .....	47
Figure 2.45	Pop-up notice before deletion .....	48
Figure 2.46	Control Point interface .....	48
Figure 2.47	Import Data info .....	49
Figure 2.48	Data format list .....	49
Figure 2.49	Import Survey Point .....	50
Figure 2.50	Add Control Point .....	50
Figure 2.51	Edit Control Point interface .....	51
Figure 2.52	Control Point interface .....	51
Figure 2.53	Point Query interface .....	52
Figure 2.54	Delete Control Point .....	52
Figure 2.55	Staking Point interface .....	53
Figure 2.56	Import source for Staking Point .....	53
Figure 2.57	Import from Survey Point .....	54
Figure 2.58	Control Point interface .....	54
Figure 2.59	Edit Staking Point .....	55
Figure 2.60	Query Staking Point .....	55

Figure 2.61	Point Database List interface .....	56
Figure 2.62	Line interface .....	57
Figure 2.63	Add Survey Line interface .....	57
Figure 2.64	Select two points from Survey Point library – 1 .....	58
Figure 2.65	Select two points from Survey Point library – 2 .....	58
Figure 2.66	Survey Line added .....	59
Figure 2.67	Survey Line in Survey interface .....	59
Figure 2.68	Edit the Survey Line Line2 .....	60
Figure 2.69	Add PT5 to the line end .....	61
Figure 2.70	The new Line2 in survey interface .....	61
Figure 2.71	Add PT5 before PT6 .....	61
Figure 2.72	The new Line2 in survey interface .....	61
Figure 2.73	Delete PT5 in Line2 .....	62
Figure 2.74	Line2 after deleting PT5 .....	62
Figure 2.75	Line Query interface .....	62
Figure 2.76	Survey line interface .....	63
Figure 2.77	Tick the line to be deleted .....	63
Figure 2.78	Four types of staking line .....	64
Figure 2.79	Add line method 1 .....	64
Figure 2.80	Add line method 2 .....	64
Figure 2.81	Add polyline .....	65
Figure 2.82	Add arc method 1 .....	66
Figure 2.83	Add arc method 2 .....	66
Figure 2.84	Add circle method 1 .....	67
Figure 2.85	Add circle method 2 .....	67
Figure 2.86	Road List interface .....	68
Figure 2.87	Add Road interface .....	69
Figure 2.88	Intersection method interface .....	70
Figure 2.89	Element method interface .....	70



Figure 2.90	Pile Point Detail .....	72
Figure 2.91	Preview Alignment .....	73
Figure 2.92	Preview Cross Section .....	73
Figure 2.93	Change method when editing road .....	74
Figure 2.94	Import interface .....	75
Figure 2.95	Import Type .....	76
Figure 2.96	Target Point Library .....	76
Figure 2.97	Data Format options .....	77
Figure 2.98	File Format options .....	77
Figure 2.99	Import Line interface .....	78
Figure 2.100	Example content in the .lnb file .....	78
Figure 2.101	Other Import interface .....	79
Figure 2.102	File format for other import .....	79
Figure 2.103	Import as Vector Map .....	80
Figure 2.104	Target point options .....	80
Figure 2.105	Export Interface .....	81
Figure 2.106	Data Format options .....	81
Figure 2.107	User defined data .....	82
Figure 2.108	Create data format .....	82
Figure 2.109	Manage data format .....	82
Figure 2.110	Other Export interface .....	83
Figure 2.111	File Format for other export .....	83
Figure 2.112	Export XML file .....	84
Figure 2.113	Preview of the XML file in text mode .....	84
Figure 2.114	Settings interface .....	85
Figure 2.115	Check if shut down Oscar .....	86
Figure 2.116	Login interface in Cloud Setting .....	87
Figure 2.117	Registration interface .....	87
Figure 2.118	Sync projects after login .....	88

Figure 2.119	Data on Tersus Cloud .....	89
Figure 2.120	Projects on Tersus Cloud .....	89
Figure 3.1	Functions under Device .....	90
Figure 3.2	Device functional group .....	91
Figure 3.3	Connect interface – David .....	91
Figure 3.4	Connect interface – Oscar .....	92
Figure 3.5	Connect interface – Luka .....	92
Figure 3.6	Two connection types for David .....	93
Figure 3.7	Bluetooth searching .....	93
Figure 3.8	Bluetooth is pairing .....	94
Figure 3.9	Bluetooth paired .....	94
Figure 3.10	Connect interface – Oscar .....	95
Figure 3.11	Connect interface – Luka .....	95
Figure 3.12	Connect interface – NMEA .....	95
Figure 3.13	Antenna Manage interface .....	96
Figure 3.14	Parameters for New Antenna .....	96
Figure 3.15	Antenna parameters explanation .....	97
Figure 3.16	Simulation connection interface .....	97
Figure 3.17	Data Terminal interface .....	98
Figure 3.18	Data Terminal outputs hex data .....	99
Figure 3.19	Create File Name .....	99
Figure 3.20	Start recording log data .....	100
Figure 3.21	Stop recording log data .....	100
Figure 3.22	Common Command .....	101
Figure 3.23	David base auto start – Radio .....	103
Figure 3.24	Baud rate options .....	103
Figure 3.25	David base auto start – Ntrip .....	104
Figure 3.26	David base auto start – TCP .....	104
Figure 3.27	David base auto start – TCS .....	104

Figure 3.28	Ntrip Site Manager .....	104
Figure 3.29	David base manual start – Radio .....	105
Figure 3.30	David base manual Start – Network .....	106
Figure 3.31	Oscar / Luka base auto start – 4 data link options .....	107
Figure 3.32	Oscar / Luka base auto start – internal radio .....	108
Figure 3.33	Oscar / Luka base auto start – receiver network options .....	109
Figure 3.34	Oscar / Luka base auto start – Ntrip network .....	109
Figure 3.35	Oscar / Luka base auto start – TCP network .....	109
Figure 3.36	Oscar / Luka base auto start – TCS network .....	109
Figure 3.37	Oscar / Luka base auto start – PDA network options .....	110
Figure 3.38	Create Rover Configuration for David – Radio .....	111
Figure 3.39	Create Rover Configuration for David – Ntrip Network .....	111
Figure 3.40	Protocol type options .....	112
Figure 3.41	Edit Rover Configuration .....	112
Figure 3.42	Create Rover configuration for David – TCP Network .....	113
Figure 3.43	Create Rover configuration for David – TCS network .....	113
Figure 3.44	Create Rover Configuration for Oscar / Luka – Internal Radio .....	114
Figure 3.45	Oscar / Luka rover data link options .....	114
Figure 3.46	Oscar / Luka rover using receiver network – protocol options .....	115
Figure 3.47	Oscar / Luka rover using PDA network – protocol options .....	115
Figure 3.48	NMEA Output .....	117
Figure 3.49	Baud rate options .....	117
Figure 3.50	Frequency options .....	117
Figure 3.51	David's device info .....	118
Figure 3.52	Example of David's registration file .....	119
Figure 3.53	Oscar's device info .....	120
Figure 3.54	eBubble before adjusting .....	122
Figure 3.55	eBubble after adjusting .....	123
Figure 3.56	Example of registration file .....	124

Figure 4.1	Functions under Survey .....	126
Figure 4.2	Survey – Drawing mode .....	127
Figure 4.3	Survey – Text mode .....	127
Figure 4.4	Map options .....	130
Figure 4.5	DXF file list .....	130
Figure 4.6	Prompt to stakeout the point .....	130
Figure 4.7	Switch to point stakeout .....	130
Figure 4.8	Prompt to stakeout the line .....	131
Figure 4.9	Switch to line stakeout .....	131
Figure 4.10	Enter an existing line name .....	132
Figure 4.11	Continue the existing line options .....	132
Figure 4.12	Information option list – part 1 .....	133
Figure 4.13	Information option list – part 2 .....	133
Figure 4.14	Point Stakeout interface .....	135
Figure 4.15	Add stakeout point .....	136
Figure 4.16	Direction on the live scene .....	137
Figure 4.17	3D display of target .....	137
Figure 4.18	Configure straight line stakeout .....	138
Figure 4.19	Stakeout a straight line .....	138
Figure 4.20	Configure polyline stakeout .....	138
Figure 4.21	Stakeout a polyline .....	138
Figure 4.22	Configure arc stakeout .....	139
Figure 4.23	Stakeout an arc .....	139
Figure 4.24	Configure arc stakeout .....	140
Figure 4.25	Stakeout a circle .....	140
Figure 4.26	Enable Tilt in device info .....	143
Figure 4.27	Setting antenna height when enabling tilt compensation .....	143
Figure 4.28	Detailed information of tilt compensation .....	144
Figure 4.29	Tilt status is ON .....	145

Figure 4.30	Point stakeout when tilt compensation is on .....	146
Figure 4.31	Static Survey interface .....	147
Figure 4.32	Duration options .....	147
Figure 4.33	Static data recording .....	148
Figure 4.34	Preparation for Static Data Process .....	149
Figure 4.35	Connections of David, computer and power bank .....	149
Figure 4.36	TersusDownload interface .....	150
Figure 4.37	Download speed options .....	150
Figure 4.38	File selected for download .....	151
Figure 4.39	View antenna height in the RINEX file .....	152
Figure 4.40	Connect Receiver to a computer .....	152
Figure 4.41	Static data recorded by Receiver .....	153
Figure 4.42	Tersus Rinex Converter interface .....	153
Figure 4.43	The Rinex files after conversion .....	154
Figure 4.44	TERSUS Geomatics Office interface .....	154
Figure 4.45	Import Files in TERSUS Geo Office .....	154
Figure 4.46	Default configuration of the observation data .....	155
Figure 4.47	Calculation Type options .....	156
Figure 4.48	Height Fitting options .....	157
Figure 4.49	Application example for site calibration .....	157
Figure 4.50	Add point for site calibration .....	158
Figure 4.51	The 1 <sup>st</sup> pair of points for calculation .....	158
Figure 4.52	The 2 <sup>nd</sup> pair of points for calculation .....	159
Figure 4.53	Two pairs of points for calculation .....	159
Figure 4.54	Calculation Result .....	160
Figure 4.55	Site calibration results applied to current project .....	160
Figure 4.56	Slide left to view residual results .....	161
Figure 4.57	Updated project property after site calibration .....	161
Figure 4.58	Survey Config - Detail .....	162

Figure 4.59	Survey Config – Continuous .....	162
Figure 4.60	Survey Config – Display Config .....	166
Figure 4.61	Survey Point Color .....	166
Figure 4.62	Advanced Config for Display Config .....	167
Figure 4.63	Base Shift interface – 1 .....	168
Figure 4.64	Base Shift interface – 2 .....	168
Figure 4.65	Road stakeout interface .....	169
Figure 4.66	Road data is loading .....	169
Figure 4.67	Road stakeout setting .....	170
Figure 4.68	Road stakeout setting .....	171
Figure 4.69	Surface List .....	172
Figure 4.70	Import surface data .....	172
Figure 4.71	Surface stakeout .....	173
Figure 4.72	Select CAD file .....	174
Figure 4.73	CAD stakeout .....	175
Figure 5.1	Functions under Tools .....	178
Figure 5.2	Area Perimeter interface .....	179
Figure 5.3	Azimuth Distance – Point to Point .....	180
Figure 5.4	Azimuth Distance – Point to Line .....	180
Figure 5.5	Offset Point interface .....	181
Figure 5.6	Offset Point calculation result .....	181
Figure 5.7	Offset point from line .....	182
Figure 5.8	Offset point from line calculation result .....	182
Figure 5.9	Rotation Point interface .....	183
Figure 5.10	Rotation Point Calculation result .....	183
Figure 5.11	Two Point Intersection – Angle .....	184
Figure 5.12	Two Point Intersection – Distance .....	184
Figure 5.13	Four Point Intersection interface .....	185
Figure 5.14	Four Point Intersection result .....	185

Figure 5.15	Intersection Angle calculation .....	186
Figure 5.16	Select all surface points to be calculated .....	187
Figure 5.17	Select the boundary points .....	187
Figure 5.18	File name and storage path for the earthwork .....	188
Figure 5.19	Earthwork calculation result .....	188
Figure 5.20	Intersection Angle calculation .....	189
Figure 5.21	Grid to Ground interface .....	190
Figure 5.22	Calculate the correction factors .....	190
Figure 5.23	Point detail after applying the calculation .....	191
Figure 5.24	Line Segmentation .....	192
Figure 5.25	Points Avg .....	193
Figure 5.26	Parameters Calculation .....	194
Figure 5.27	Add Point for calculation .....	194
Figure 5.28	Parameters Calculation Result interface .....	195
Figure 6.1	TC20 Lithium battery .....	198
Figure 6.2	TC20 Charger Adapter .....	198
Figure 6.3	TC20 Charger Adapter Plugs .....	198
Figure 6.4	TC20 Controller hand strap .....	199
Figure 6.5	Stylus Pen for TC20 .....	199
Figure 6.6	Mini USB cable .....	199
Figure 6.7	Remove the back cover .....	200
Figure 6.8	Take off the back cover .....	200
Figure 6.9	Put the SIM card in the holder .....	201
Figure 6.10	Insert Micro SD card .....	201
Figure 6.11	Insert the back cover .....	202
Figure 6.12	Select USB function .....	203

## **Tersus Nuwa App User Agreement**

Copyright © 2023 Tersus GNSS Inc.

CAUTION! Please read this notice carefully before using software. Use of Nuwa App indicates acceptance of the terms and conditions of the User Agreement.

Thank you for using Tersus Nuwa App! This agreement is a legally binding contract between Tersus GNSS Inc. and you regarding the user of Tersus Nuwa App. Please read all the terms and conditions listed in the agreement carefully. Use of Nuwa App indicates that you have agreed to accept all of the terms of this Agreement. If you have any questions about the content of the terms of this Agreement, please contact Tersus GNSS Inc. If you do not agree to any of the terms and conditions of this Agreement, please do not proceed with the subsequent operations.

### **1. License**

Tersus provides users with free licenses for Tersus Nuwa App and related materials, for the purpose of product needs and improvement, when users use Tersus products. Tersus does not guarantee that the free license will not be changed. The license fee will be calculated according to the price published on Tersus official website [www.tersus-gnss.com](http://www.tersus-gnss.com). Before you pay the license fee as agreed, Tersus will reserve the right not to provide you with Tersus Nuwa App and related materials. Without the permission of Tersus, users are not allowed to resell it to a third party or use Tersus Nuwa App and related materials to obtain income through other means in any way.

### **2. Proprietary Rights**

The user agrees that Tersus Nuwa App and related materials shall belong to Tersus, and Tersus retains exclusive ownership of the trademarks and service marks represented by its company name and logo and all of the documentation related. The user agrees that all technologies, algorithms and processes contained in Tersus Nuwa App constitute commercial secrets, and the user will protect them. User may not reverse engineer, decompile or disassemble the software, nor alter images used in the software and the



documentation. The user are not allowed to copy, modify, and reproduce relevant information, no matter it is modified or translated into another language, unless the permission of Tersus is obtained. The user agrees that if the user violates this agreement, he will be liable for damages determined by the court.

### 3. Customer Service

According to the situation of users using Tersus Nuwa App, Tersus will continue to add features, improve performance and experience. Although it is the Tersus's customary practice to provide reasonable assistance and support in the use of Tersus products to customers, Tersus shall not be obligated to any user to provide technical assistance or support through this agreement, and may at Tersus's sole election charge a fee for customer service.

### 4. Update Policy

Tersus may regularly or irregularly, update Tersus Nuwa App to add functions or fix issues. Tersus is not obliged to provide updates or modifications to any user, nor do we guarantee that that updates or modifications are fully in line with expectations.

### 5. Disclaimer

Tersus will try best to make that the function of Tersus Nuwa App run normally and the data calculation is correct, but Tersus does not guarantee that all functions of the software meets the expectations, the data calculation is correct and the stability of the software runs stably. Tersus and distributors will not be liable for any indirect, special, incidental, consequential or exemplary damages caused in any way.

### 6. Termination

This agreement is hereby terminated by mutual agreement or by any breach of any one or more provisions of this agreement by either party. In such cases, all rights of Tersus shall remain in force and effect. Any protected information data of user maintained on database shall upon notice to the user and at the discretion of Tersus may be destroyed.

### 7. Copyright

Tersus Nuwa App and related materials (including, but not limited to, any images, photographs, animations, video, audio, music or text incorporated into the software), and all intellectual property rights associated with it, whether exists in a tangible media or in an

electronic media is owned by Tersus. You may not remove or alter any trademark, logo, copyright and other proprietary notice in or on the products.

#### 8. Other

Tersus has the right to amend all the contents of this agreement and product policy, and the right to interpret them within the scope of law.

This agreement will be effective once it is published, and Tersus has the right to modify the content of the agreement at any time, and the modified results will be published on the Tersus website. If you do not agree with the modifications made, you have the right to stop using Tersus Nuwa App. If the user continues to use, it is deemed that the user accepts the modifications.

The conclusion, implementation and interpretation of this agreement and the settlement of disputes shall be governed by the laws of China and subject to the jurisdiction of the Chinese courts. If any dispute arises between the parties regarding the content of this agreement or its implementation, the parties shall try to resolve it through friendly consultation; if consultation fails, either party may file a lawsuit in the court where Tersus GNSS is located.

## **1. Nuwa Brief Introduction**

- Introduction
- Installation
- Update Nuwa
- Main Interface

## 1.1 Introduction

Nuwa is a survey application software based on Android OS (Operating System), designed by and all rights reserved to Tersus Inc. Nuwa is simple, easy to use and has friendly UI (User Interface). It is designed to work with Tersus products including David GNSS receiver, Oscar GNSS receiver, Luka GNSS receiver, BX series OEM boards and other receivers which support NEMA-0183.

Main features of Nuwa App:

- Supports Bluetooth/USB connection and related operations for Tersus receivers.
- Powerful data management makes survey data management more convenient.  
Easy for data editing and import / export of several types of formats.
- Convenient to set up a base station or a rover, and supports setting to transmit and receive differential data through the radio, receiver network or PDA network.
- Optimized survey and stakeout, supports GNSS Linework and road stakeout, more functions, and more simple operation.
- Built-in a variety of ellipsoids and projections, various languages and national coordinate systems. Supports user-defined coordinate system which is more adaptable.
- Provide tools for indirect measurement for easier work.
- Supports new release detection and online upgrades.

## 1.2 Installation

There are two methods of installing Nuwa app in an android device.

- 1) Search Nuwa in Google Play Store, click [Install], install the application and open it after the installation is completed. The screenshots are as follows.




Figure 1.1 Nuwa in Google Play Store




Figure 1.2 Nuwa in Google Play Store – install




Figure 1.3 Nuwa in Google Play Store – open

- 2) Copy the .apk file to the storage of an Android device, click it to start installation. The Nuwa icon will be on the desktop after it is installed successfully.




Figure 1.4 Nuwa copied in an android device




Figure 1.5 Nuwa icon on desktop

## 1.3 Update Nuwa

There are three methods of updating Nuwa app in an android device.

- 1) Update Nuwa in Google Play Store which is shown below.




Figure 1.6 Update Nuwa in Google Play Store – 1




Figure 1.7 Update Nuwa in Google Play Store – 2

- 2) Update Nuwa by copying the latest .apk installation file to the storage of an android device. The process is the same with that in the above section of installation.
- 3) Update Nuwa in the 'Settings' page inside Nuwa app. In the condition that the android device is connected to internet and [Update Detection] is turned on, it automatically pops up an update prompt every time you open Nuwa and it can be seen that there is red 'new' on the right of version number if current Nuwa version is detected to be ready to update.




Figure 1.8 Version in Settings page

If [Update Detection] is not turned on, tap the row of version, it pops out a window indicating software update. Select [Update] to update the app automatically. Select [Later] to ignore this notification.




Figure 1.9 Software Update notification



## 1.4 Main Interface

Nuwa has four main functional groups: Project, Device, Survey and Tools. While Nuwa is running, slide left or right on the screen to enter other functional groups.




Figure 1.10 Nuwa Main Interface

On the main interface of Nuwa, click [More] or press and hold the icon on the screen to enter edit mode for icons. In this mode, click [-] to hide icons on the main interface, click [+] to add icons on the main interface, or long press and drag to modify the order of icons on the main interface. Click the red font [Click here to exit Edit Mode] at the top right, or press the return key to exit the edit mode.








Figure 1.11 Edit Mode

## ➤ Status Bar

Icon	Description
	Project Information, the current project name is displayed.
	Device information, when a device is connected, click it to check details about the receiver connected. Refer to section 3.6 for detailed description.
	Satellites status, when a device is connected, it displays satellite positioning status which includes: None, Single, DGPS, Float and Fixed. Click this icon to view satellite information which is shown in the figures below.
	Connection status, if there is no device connected, it displays Disconnected. Click this icon to enter connect interface, refer details in section 3.1. If there is a device connected, this icon displays the 2D and 3D accuracy of current connected device.

## ➤ Satellite Info

Four functional groups: Project, Device, Survey and Tools.

←

Satellite Info

Position

Skymap

CNO

Sat Tab

Fixed

2022-03-11 17:47:35

WGS84 Lat: 31.190405855N

WGS84 Lon: 121.593181773E

WGS84 H: 38.3940m

Local N: 21782337.1157m

Local E: 41033187.8620m

Local h: 38.3941m

Satellite: 35/45

Speed: 0.00m/s

Diff Delay: 1 (rtcm3)

Distance to base: 2.19(m)

Cutoff Angle(°) 10

Input

Set

Reset RTK to fix again

RTK Reset

HRMS	0.0034	HDOP	0.60
VRMS	0.0053	VDOP	0.90
RMS	0.0063	PDOP	1.10

Tilt Enable

Base Shifted : No

Datum Trans : No

Plane Adjustment : No

Height Fitting : No

Figure 1.12 Satellite Info – Position

In the figure above, 'Single' indicates the current solution status of the receiver. The solution status includes Fixed, Float, DGPS, Single, Base Manual and Base Auto.

Clicking the box of date and time can switch time zone, clicking 'WGS84 Lat' or 'WGS84 Lon' can switch display from options of Degree (DD.DDDDDD), DM (DD:MM.MMMM) and DMS (DD:MM:SS.SS), clicking 'WGS84 H' or 'Local N' or 'Local E' or 'Local h' can switch unit from options of km, m, inch, and feet.

'Satellite: 22/24' indicates that 22 satellites used and 24 satellites observed / tracked.

'Speed: 0.01m/s' is the moving speed of the receiving antenna.

'Diff Delay: 1' indicates that the differential delay is 1 second.

'Distance to base: 1.52m' means the distance between rover and base is 1.52m.

Elevation Mask Angle can be set between 0 and 90 degrees. Modifying the elevation mask angle does not show a change in the number of satellites observed and used.

HRMS, VRMS and RMS indicate the horizontal, vertical and total value of root mean square.

HDOP, VDOP and PDOP indicate the horizontal, vertical and position of dilution of precision.

'Tilt Enable': Tilt compensation can be turned on or off when connecting to Oscar Ultimate, Luka Ultimate and Luka Advanced. If it is on, information about the angle and its accuracy will be displayed here.

The last four rows of this interface present the status of base shift, datum transformation, plane adjustment and height fitting.




Figure 1.13 Satellite Info – Skymap

In the figure above, the sky map displays the elevation angle and azimuth of satellites of different satellite systems. A satellite at the center of the circle means its elevation angle is 90 degrees, a satellite on the circumference means its elevation angle is 0 degree. At the bottom of this interface, one or more constellations can be ticked to display.




Figure 1.14 Satellite Info – CN0 L1

In the figure above, it shows the CNR (Carrier Noise Ratio) of different satellites in specified constellation. Clicking the histogram area can switch the CN0 between L1, L2 and L5.




Figure 1.15 Satellite Info – CN0 L2




Figure 1.16 Satellite Info – CN0 L5

Type	Pm	Azi	Ele	L1	L2	L5	Lock
GPS	2	145	32	39	32	0	Used
GPS	5	62	43	41	40	0	Used
GPS	13	31	69	43	38	0	Used
GPS	15	266	67	44	43	0	Used
GPS	18	318	28	38	30	41	Used
GPS	29	249	36	40	37	0	Used
GLONASS	41	8	46	39	43	0	Used
GLONASS	47	750	40	41	47	0	Used
GLONASS	51	100	18	38	38	0	Used
GLONASS	55	173	19	36	34	0	Used
BeiDou	161	141	45	38	44	40	Used
BeiDou	162	237	36	35	42	38	Used
BeiDou	163	201	53	39	45	41	Used
BeiDou	164	123	34	35	41	38	Used
BeiDou	166	230	71	41	46	43	Used
BeiDou	168	102	77	42	47	44	Used
BeiDou	169	223	45	37	44	40	Used
BeiDou	171	742	53	42	48	46	Used
BeiDou	172	181	24	35	42	40	Used
BeiDou	173	331	72	43	46	43	Used
Galileo	4	318	71	43	48	46	Used
Galileo	9	250	29	37	42	40	Used
Galileo	11	301	61	39	44	41	Used
Galileo	12	167	55	38	45	43	Used
Galileo	19	44	30	32	37	33	Used

Figure 1.17 Satellite Info – Sat Tab

In the figure above, it shows the satellite information in table which including satellite type, PRN code, azimuth, elevation angle, CN0 value of L1, CN0 value of L2, CN0 value of L5 and satellite using status.

When connecting to the receiver and the receiver is set to rover mode, the Base Info

interface is displayed, which includes the base station WGS84 latitude and longitude coordinates and geodetic height, North-East and elevation coordinates. If the rover acquires correction data from another Tersus single base device (with radio link or network link), the base station power, correction data format and the satellite number will also be correctly displayed.




Figure 1.18 Base Info

#### ➤ Menu area

List all the menu items in the current functional group.

## 1.5 Quick Start

### 1. Create a new project

Go to [Project] -> [Project], click [New], input the project name, select a CRS or edit with a template CRS, click [OK] to create a project.




Figure 1.19 Create Project




Figure 1.20 Connect

## 2. Connect a device

Go to [Device] -> [Connect], select the device type, connect type, connect config and antenna type, and click [Connect].

## 3. Configure the base or the rover

A base transmits RTK corrections to a radio or to network. The position of the base must be input manually or auto start. Nuwa supports RTK uploading to a NTRIP host, which brings convenience for a number of applications.






Figure 1.21 Base Configure




Figure 1.22 Rover Configure

A rover receives RTK corrections from a radio or from network. NTRIP, TCP and TCS protocols are supported if corrections are received from network.

All the configuration can be managed, such as created, edited and deleted in Nuwa App. A device can be configured to work as a base or as a rover.

#### 4. Site Calibration and Base Shift

The site calibration is to find the mathematical conversion relationship (transition parameter) between WGS84 and the local plane Cartesian coordinate system. Site calibration includes the calculation of four-parameter plane transformation and the calculation of height fitting parameters. There are three methods for height fitting: Fixed Difference Correction, Plane Fitting and Surface Fitting.

In Auto Start mode, if a base is moved, re-installed or powered off, Base Shift is necessary to make the points have the same coordinates before and after the change. Main steps: Go to [Survey] -> [Base Shift], select GNSS points and known points, click [Calculate], the offsets parameters are calculated automatically. The user can apply the parameters on the points to be surveyed. Base Shift also influence coordinates value of other points with this base.

Steps 5 – 8 are action points in fields, select one or more in fields.

## 5. Survey

Go to [Survey] -> [Survey] to enter survey interface, which can be in text mode or drawing mode. The main difference between the two modes is whether the drawing is displayed.

The configuration refers to section 4.7.1 Common Config for more details.

Two collection modes: Auto Collect and Manual Collect, refer to section 4.1 Survey for details. All the detailed information about the survey points can be checked in the survey point library.

## 6. Point Stakeout

Go to [Survey] -> [Point Stakeout] to enter point stakeout interface. Stakeout points must be saved in the stakeout point library before. Select the points to be stakeout and find the target point according to the prompt information by Nuwa, refer to section 4.2 Point Stakeout for details.

## 7. Line Stakeout

Go to [Survey] -> [Line Stakeout] to enter line stakeout interface. Stakeout lines must be saved in the stakeout line library. Select the lines to be stakeout and find all the points on the target line according to the prompt information by Nuwa, refer to section 0

Line Stakeout for details.



Figure 1.23 Survey



Figure 1.24 Point Stakeout




Figure 1.25 Line Stakeout

## 8. Static Survey

Go to [Survey] -> [Static Survey] to enter static survey interface. Select the parameters, such as interval, cut off angle, antenna parameters and click [Start], refer to section 4.5 Static Survey for details.

## 9. Import and Export

Go to [Project] -> [Import] to enter import interface, which can be divided into Coordinate Import and Other Import. Coordinate import is to import points in a .csv file or .dat file. Other import is to import points in DXF or SHP files. Click [File Path] to select the file directory.

Go to [Project] -> [Export] to enter export interface. The supporting file formats include: csv, kml, shp, dxf, html, xml, sima, kmz, ncn and rw5. The data to be exported can be filtered by point type and collection time. Click [Export] after all the options are filled.

## 2. Project

- Project
- CRS (CooRdinate System)
- Code
- Point
- Line
- Road
- Import
- Export
- Settings




Figure 2.1 Functions under Project

## 2.1 Project

This section introduces how to create a new project, open / delete / edit an existing project.

### 2.1.1 New

A new project is necessary to manage all the data. On the Nuwa main interface as shown in Figure 1.10, click [Project] - > [New] to go to the following interface.




Figure 2.2 Create Project interface

[Project Name]: input the project name

[Creator]: input the name of the operator

[Creation date]: the date and time generates automatically.

[Project Template]: use an existing project settings

[Coordinate System]/ [Source Project]: select a coordinate system if project template is not turned on; select a source project if using a project template.

[PlaneGridNorth]: select plane grid in the list, or click More to download more grid file online.

[PlaneGridEast]: select plane grid in the list, or click More to download more grid file online.

[Geoid]: select geoid model in the list, or click More to download more geoid file online.

Note: (1) If the grid file or geoid file is already selected in the parameters of the selected coordinate system, the selected grid file or geoid file will be automatically filled in below when the new project is created.

(2) If the grid file or geoid file is selected here, they will be applied to this project after new project is successfully created.

(3) If the grid file or geoid file is selected here, but the file is actually not available in the controller InternalStorage\TersusSurvey related path, then it will automatically jump to the download interface to search and download the file. Only when the selected grid file or geoid file is downloaded, or when the file is deselected, can the project continue to be created.




Figure 2.3 New project created

After a project is created, it will prompt out a window asking whether close the current project and open the newly created project. The projects in the list are sorted in reverse chronological order. Refer to section 2.1.5 for more details about project property.

### 2.1.2 Import

In the Figure 2.3, an existing project can be imported from the storage of the android device by clicking [Import] on the bottom left of the interface.




Figure 2.4 Project folders in an Android device

When importing projects from other sources, click [Import], select the Project folder under TersusSurvey which is shown in Figure 2.4, and click [OK] and Nuwa imports all the projects in this folder.




Figure 2.5 Sketch file containing the project info

**Note: The imported project file should have a sketch file containing the project information (Project / Project-shm / Project-wal).**

### 2.1.3 Open

If there is need to operate in an existing project, find it in the project list and click it. Nuwa prompts to open the project, click [OK].




Figure 2.6 Open an existing project

### 2.1.4 Delete

Click [Multiselect] at the right side of Project List, select (single select, inverse select or select all) projects to be deleted. After the projects are selected, click [Delete] button to delete them. Nuwa prompts to confirm, click [OK] to complete the deletion.

**Note: The current Project cannot be deleted in Nuwa app.**




Figure 2.7 Delete Project

### 2.1.5 Edit Project Property

If a project is opened, the coordinate system can be edited, including ellipsoid, projection



method and coordination transformation.




Figure 2.8 Project List

Click the [Current Project] to enter Project Property interface.




Figure 2.9 Project Property

Click [Edit] to input the ellipsoid parameters, projection type and coordination transformation, refer to section 2.2.2 for details.



Figure 2.10 Share Project Info

Click [Share] to share the project parameters with others. The detailed usage refers to section 2.2.1.

## 2.2 CRS (CooRdinate System)

Nuwa app supports user-defined coordinate system. A user-defined coordinate system can be saved as a template. A CRS can be created, imported, edited and deleted in the CRS management interface.

On the Nuwa main interface as shown in Figure 1.10, click [CRS] to get the coordinate system list which is shown below.



Figure 2.11 Coordinate System List

## 2.2.1 New CRS




Figure 2.12 Create a new CRS

Click [New] to create a new CRS, input the coordinate system name, select the right ellipsoid, projection, datum transformation, plane adjustment, and height fitting as per the following screenshots:




Figure 2.13 Ellipsoid list

[Ellipsoid]: Select the correct ellipsoid parameters, including ellipsoid name, semi-major axis, inverse flattening, etc. For a predefined ellipsoid, it automatically fills the semi-major axis and inverse flattening after selecting the ellipsoid; if the ellipsoid that meets the requirements is not found in the predefined ellipsoid, and you have the parameters of the ellipsoid, you can [Add] an ellipsoid to the list, enter your parameters and select it; If the ellipsoid that meets the requirements is not found in the predefined ellipsoid and you do not have the parameters for this ellipsoid, please contact Tersus technical support.

**Note: The default ellipsoid is WGS84.**





Figure 2.14 Projection interface

[Projection]: Including Transverse Mercator, UTM, Lambert conformal conic 1SP, Lambert

conformal conic 2SP, and etc. When a receiver is connected with Nuwa, click the icon  to round the current longitude as the central meridian. The projection is listed as below, if the required projection is not found in the predefined projection list, please contact Tersus technical support.




Figure 2.15 Projection list

Origin latitude, central meridian and other parameters can also be configured in Projection interface which is shown above. Fill in these information according to the actual needs. Turn on [X → North] to indicate that the positive part of X axis is north, negative part is south. Turn on [Y → East] to indicate that the positive part of Y axis is east, negative part is west.




Figure 2.16 Datum transformation options

[Datum Transformation]: Datum transformation is necessary when the source ellipsoid is different from the target ellipsoid. There are three options: No parameter, Bursa Parameters and Molodensky Badekas Parameters.




Figure 2.17 Bursa Parameters

[Bursa Parameter]: Axis shift, rotation and scale would be introduced in the datum transformation. Bursa-Wolf seven-parameter model is used from local coordinate to WGS84 system. At least three known points are necessary for accurate transformation. Only X/Y/Z shifts are required only if three parameter transformation is needed.




Figure 2.18 Plane adjustment interface




Figure 2.19 Plane adjustment options

[Plane Adjustment]: Plane adjustment is for the transformation between two planes. There are two options for parameters calibration: No parameter and 4 parameters. The detailed information and usage of plane grid refer to section 2.2.5.




Figure 2.20 4 Parameters

[4 Parameters]: X/Y axis shift, rotation angle and scale are necessary to be input as above. These parameters can be calculated from site calibration, details refer to section 4.5.1.




Figure 2.21 Height fitting interface




Figure 2.22 Parameters fitting options

[Height Fitting]: Height fitting has two options: Geoid and Parameters Fitting. Parameters fitting includes no parameter and detailed parameters fitting.

[Geoid]: Geoid supports ggf, grd, gsf, osgb and mnt format files, the detailed information and usage of geoid files refer to section 2.2.5.

[Parameters Fitting]: currently three algorithms are supported: fixed difference correction, plane fitting and surface fitting. The parameters needed can be calculated from site calibration, details refer to section 4.5.2.





Figure 2.23 Height Fitting – Parameters Fitting

After setting all parameters to create a new coordinate system, click [OK] to complete the



configuration.

Click the scan icon  in the top right corner of Figure 2.12, open the camera to scan other surveyor's coordinate system parameters QR code to copy information for creating a new CRS.




Figure 2.24 Scan QR code to get CRS info

The following shows detailed steps:

- 1) The copied surveyor opens in turn: [Project] -> [Current Project] -> [Project Information], then displays the complete QR code;
- 2) The current surveyor opens the camera when creating new CRS to scan the QR code displayed as shown in Figure 2.24 above and can copy its coordinate system parameters. The QR code screenshot in photo album can also be scanned to obtain the CRS parameters.




Figure 2.25 CRS info obtained by scanning QR code

3) The coordinate system parameters are obtained as shown in the figure above.

## 2.2.2 Import CRS

Click [Import] on the bottom left of CRS interface which is shown in Figure 2.11, it shows predefined coordinate systems for users to choose.




Figure 2.26 Predefined CRS

In the figure above, the predefined coordinate systems are classified by continent and region.




Figure 2.27 Continent options

The continent option includes Africa, America, Asia, Europe, Oceania and World as shown in the figure above. Select a continent, a country or a region, then select a CRS and click [Preview].




Figure 2.28 Preview of predefined CRS

The above figure is a preview of 'Beijing 1954 3-degree GK CM 075E' coordinate system. Click [OK] and [Select] this CRS, the CRS file is imported to Coordinate System List as shown in the figure below.




Figure 2.29 Example of CRS import

If the user cannot find the coordinate system of their country or region, but has ellipsoid, projection, datum transformation and other related parameters, you can create a new coordinate system or contact Tersus technical support and we help you create one.

### 2.2.3 Edit CRS

Click an existing CRS and click [Edit] to enter the Edit Coordinate System interface, refer to the following screenshot:




Figure 2.30 Edit Coordinate System

### 2.2.4 Delete CRS

The default two CRS cannot be deleted. Click [Multiselect] to select the CRS to be deleted and click [Delete] to finish the deletion.




Figure 2.31 Delete CRS

## 2.2.5 Plane Grid and Geoid

Plane Grid and Geoid are adjustment methods for plane and height, which can improve survey accuracy.

Plane Grid includes plane grid north and plane grid east. Click [PlaneGridNorth] in Figure 2.18 Plane adjustment interface, it enters plane grid north list shown as below. Click [More] to enter download list, the plane grid files can be downloaded from online server. Click [Refresh] to view the current available plane grid files. The plane grid file supports .ggf, .grd, .gsf, and .osgb format. If customer cannot find suitable plane grid file, feel free to contact Tersus support via email [support@tersus-gnss.com](mailto:support@tersus-gnss.com).




Figure 2.32 Plane Grid list




Figure 2.33 Plane Grid download list

After downloading a required plane grid file, select it in the plane grid list and it returns to the plane adjustment interface.

Setting the PlaneGridEast is the same with the above method of setting PlaneGridNorth.

Geoid supports ggf, grd, gsf, osgb and mnt format files, it optimizes data loading, reduces waiting time for different devices, simplifies algorithm calculation process and saves system resources. In a CRS setting, click [Geoid] under Height Fitting tab enter Geoid list which is shown as below. The list shows the coverage latitude, longitude and resolution of

the corresponding geoid model. Click [More] to enter download list, the geoid files can be downloaded from online server.



Figure 2.34 Geoid list



Figure 2.35 Geoid download list

Click [Refresh] to view the current available geoid files. Contact Tersus Technical Support [support@tersus-gnss.com](mailto:support@tersus-gnss.com) to inquire more if customer cannot find suitable Geoid files. After downloading a required geoid file, select it in the geoid list and it returns to the height fitting interface.




Figure 2.36 Explore Geoid folder in the android device

Another method of importing geoid files: manually copy and paste the Geoid files under the Geoid folder of TersusSurvey as shown above, back to the Geoid list interface and click [Refresh] to view the available Geoid list as shown below.





Figure 2.37 Refresh to view the Geoid list

Select one suitable Geoid model and click [Select] to complete the Geoid configuration, and it returns to the height fitting interface.

## 2.3 Code

Nuwa now supports selecting code or entering code, and switch to survey a point feature or a line feature according to the type of the code. Here in the code module, manage the code of the current project.





id	Code	Type	Summary
0	ANCHOR	Point	An
1	B/BANK	Line	B/E
2	B/WALL	Line	B/v
3	C/L	Line	Cen
4	CAPPEDP	Point	Capped
5	CB	Point	Catcl
6	CHLFENCE	Line	Chainli
7	CN	Point	(
8	CONCP	Point	Conc I
9	D/W	Line	D
10	DECK	Line	D
11	DMH	Point	Drain I
12	DRAIN	Line	Drain

Figure 2.38 Code List

### 1) Add Code

Click the Add button, then enter the interface as below.




Figure 2.39 Add Code

Input the code to be added, select the type of the code as Point or Line, input the summary of the code, and click OK to add the code.

### 2) Edit Code

Select a code in the code list, click the Edit button, then enter the Edit Code interface.

Edit the code, the type of the code or the summary, then click OK to Edit the code.

### 3) Delete Code

Click Multiselect, then select the codes to be delete in the code list, click Delete to delete the codes.

#### 4) Import and Export Code

Click the Import button on the upper left to import codes to the current code list. Click the Export button on the upper right to export all the codes in the current code list.


## 2.4 Point

Point library includes survey point library, control point library and staking point library.

It is also supported for a project to contain multiple point library database files.

### 2.4.1 Survey Point

Click [Project] -> [Point] and see the survey point library as below.



id	Name	Point Type	Code
S2	Base_0	Base	
S9	PT1	Detail	Line0
S5	1	Input	
S6	Base_1	Base	
S7	Base_2	Base	
S8	PT2	Detail	Line0

Figure 2.40 Survey Point Interface

In the survey point library interface, slide in the left or right direction to check the point information, such as coordinates, collection time, and etc.

#### 1) Add survey point

Under the Survey Point interface, click [Add] to enter the Add Point interface.




Figure 2.41 Add Survey Point

Fill in the point name and code, choose the coordinate type (including two types: BLH and NEH), fill in the coordinate values, click [OK] to add a new survey point. The point type of the added survey point is called Input Point.

## 2) Edit survey point

In the survey point interface, choose a points to be edited, and click [Edit] to enter the Edit interface.





Figure 2.42 Edit Survey Point

**Note: The base point and calculated point cannot be edited; all info of the**

input point can be edited; only antenna info of the detailed point, continuous point and stake point can be edited.

### 3) View details of survey point



In the survey point interface, choose a point and click [Detail] to view details of this point.





Name	PT1	Code
N(m)		3452080.9721
E(m)		29861.0515
h(m)		15.2140
Lat		31.189989722N
Lon		121.593289336E
Height(m)		15.2140
ECEF-X(m)		-2861007.8862
ECEF-Y(m)		4651722.6362
ECEF-Z(m)		3283939.0637
Lat(LOCAL)		31.189989723N
Lon(LOCAL)		121.593289336E
H(LOCAL)(m)		15.2140
Base		Base_0
Base Lat84		31.190414160N
Base Lon84		121.593188450E
Base Alt84(m)		40.2785
Base Ant.Height		0.0000
Solution States		Fixed >
Collection End		2020-09-30 10:53:14
Coord Type		BLH(WGS84) >
DOP(P/H/V)		0.6/0.9/1.0
RMS(HRMS/VRMS)		0.0068/0.0106
Std(Lat/Lon)		0.0044/0.0052
Ant Height(m)		1.9940
Collection Start		2020-09-30 10:53:09
Epoch		5
Elevmask		15.0
Used Satellite Num		32
Observed Satellite Num		40
Constellation Num		5
Worst Diff Age		1.0
Best Diff Age		1.0
Antenna Height(Not Corrected)		1.8
Antenna Type		OSCAR
Survey Method		Pole
Photo		

OK


Figure 2.43 View details of Survey Point

On the upper right corner there are two icons: QR code icon  and camera icon .

The detailed descriptions are as below.

- a. Share the point via QR code. Click  icon to generate the QR code of this survey point. This QR codes contains the point name, code and coordinate information separated by a comma. Other surveyor can obtain these information by scanning this QR code.
- b. Photo of the survey point. Click  to take a photo using system camera. The photo will be displayed at the bottom of the point detail for preview. The photo is named with point name plus shooting time. The photos are stored under the folder of TersusSurvey/Projects/ProjectName.

#### 4) Graphic display


In the survey point interface, click the up-right  icon to enter graphic interface.

In graphic interface, zooming, panning and online maps are supported.

In graphic interface, the selection of points is supported. For example, in some tools, click the point selection button and enter the point library, then click the graphic display button and enter the graphic interface, you can click on the point of interest directly on the map to select it.

The control point library and staking point library also have graphic interface.

#### 5) Query survey point

In the survey point interface, click the up-right  icon to enter Point Query interface as below.




Figure 2.44 Point Query interface

Query condition details are as follows:

[Point Type]: Detail, continuous, input point, calculate or base.

[Name]: Point name to be queried.

[Code]: Code number.

[Base]: The name of the base.

[Start/Stop Time]: Start and stop time of the points

Click [OK] to search all the points meeting the query conditions.

#### 6) Delete survey point

In the survey point interface, click [Multiselect], select the points to be deleted and click [Delete] to complete the deletion.




Figure 2.45 Pop-up notice before deletion

**Note: The base point in the survey point library cannot be deleted.**

## 2.4.2 Control Point

In Nuwa app, the control points are used in parameter calculation and site calibration.



Figure 2.46 Control Point interface

### 1) Import control point

In the Control Point interface, click [Import] to import the control points.

It can be done in three ways: From File, From Survey Point and Manually Add.

Select [From File] to enter the import data interface.




Figure 2.47 Import Data info

Then click [Data format] and select a format in the pop-up list.





Figure 2.48 Data format list

Select file format and file path to import points. Then click [Import] to import the required points.

Select [From Survey Point] and then select the points in the Survey Point list.





Survey Point			
6 features		Multiselect	
id	Pt	Point Type	Code
1	Base_0	Base	
2	Base_1	Base	
3	PT1	Detail	
4	PT2	Detail	
5	PT3	Detail	
6	PT4	Detail	

Figure 2.49 Import Survey Point

Select [Manually Add] to enter the Add Control Point interface.



Add Control Point

Name

Input

Coord Type

NEH >

N(m)

Input

E(m)


Input

h(m)

Input


OK

Figure 2.50 Add Control Point

Choose the coordinate type (including two types: BLH and NEH), fill in the point name and the coordinate values, or click the upper right  icon to import the survey point directly.

## 2) Edit control point

In the control point interface, select a control point, click [Edit] to edit control point.



← Edit Control Point

Pt TRSA

Coord Type NEH >

N(m) 3452237.3289

E(m) 253647.8

h(m) 23.85

OK

Figure 2.51 Edit Control Point interface

### 3) Query control point



← Point


Survey Point Control Point Stakeout Point


1 features Multiselect

id	Name	N
1	C16	3462967.1757

Add Edit Import

Figure 2.52 Control Point interface

Click the up-right  icon to enter Control Point Query interface. The query conditions include name, code and start/stop time.



← Point Query

Target Points Control Points >

Query Condition

☐ Name Input

☐ Code Input

☐ Time

Start Time


Stop Time

Select All Inverse OK

Figure 2.53 Point Query interface

#### 4) Delete control point

Click [Multiselect] in the control point interface to enter the following interface. Select the points to be deleted and click [Delete] to complete the deletion.



← Point

Survey Point Control Point Stakeout Point

1 features Cancel

id	Pt	X
<input type="checkbox"/> 1	TRSA	3452237.3289

Select All Inverse Delete

Figure 2.54 Delete Control Point

### 2.4.3 Staking Point




Figure 2.55 Staking Point interface

### 1) Import staking point

In the staking point interface, click [Import] to import staking points.

It can be done in four ways: From Files, From Survey Point, From Control Point, Manually Add.





Figure 2.56 Import source for Staking Point

Choosing [From File] leads to the similar steps of importing Control Point.

Choosing [From Survey Point] leads to the figure below. One or more points can be selected and imported as Staking Points.




id	Name	Point Type	Code
<input type="checkbox"/> 1	Base_0	Base	
<input checked="" type="checkbox"/> 2	PT1	Detail	
<input checked="" type="checkbox"/> 3	PT2	Detail	
<input type="checkbox"/> 4	Base_1	Base	
<input checked="" type="checkbox"/> 5	PT3	Detail	
<input checked="" type="checkbox"/> 6	PT4	Detail	
<input checked="" type="checkbox"/> 7	PT5	Detail	
<input checked="" type="checkbox"/> 8	PT6	Detail	

Select All Inverse Delete Select

Figure 2.57 Import from Survey Point

Choosing [From Control Point] leads to the control point list. One or more points can be selected and imported as Staking Points.

Choosing [Manually Add] leads to the Add Staking Point interface.



← Add Stakeout Point

Name Input

Coord Type NEH >

N(m) Input

E(m) Input

h(m) Input

OK

Figure 2.58 Control Point interface

## 2) Edit staking point

In the staking point interface, select a staking point and click [Edit] to enter the editing interface.





Figure 2.59 Edit Staking Point

### 3) Query staking point

Click the up-right  icon to enter Staking Point Query interface. The query conditions include name, code and start/stop time.





Figure 2.60 Query Staking Point

### 4) Delete staking point

Click [Multiselect] in the staking point interface, select the points to be deleted and click [Delete] to complete the deletion.

## 2.4.4 DB List

It is supported for a project to contain one or more point library database files. All point library databases under the project use the same coordinate system parameters of the project for the coordinate conversion. And the data between point library DB are independent of each other. Click  on the top right to enter the DB list management interface to create a new point library database and select the point library database.




Figure 2.61 Point Database List interface

### 1) Add point database

Click [New], enter the name of the new point database file and click OK, the new point database will be created and opened automatically.

### 2) Open point database

Click on one of the point database and click OK in the prompt dialog to switch to the point database selected.

### 3) Delete point database

Click [Multiselect] in the DB List interface, select the database to be deleted and click [Delete] to complete deletion. The point database opened currently cannot be deleted. After the database file is deleted, all the points in the database will be deleted, so please delete it carefully.

## 2.5 Line

This section includes survey line and staking line.

### 2.5.1 Survey Line

#### 1) Add survey line

Click [Project] - > [Line] and see the Survey Line as below.



Figure 2.62 Line interface

Click [Add] under Survey Line to enter the following interface.




Figure 2.63 Add Survey Line interface

Fill in a line name or use the default name, input a code for comment purpose, click [Add]



in the bottom left to select two points in the survey point library as below.

Survey Point			
74 features		Multiselect	
id	Name	Point Type	Code
S1	Base_0	Base	
S2	PT1	Continuous	Line0
S3	PT2	Continuous	Line0
S4	PT3	Continuous	Line0
S5	PT4	Continuous	Line0
S6	PT5	Continuous	Line1
S7	PT6	Continuous	Line1
S8	PT7	Continuous	Line1
S9	PT8	Continuous	Line1
<div> Add Edit Detail Select </div>			

Figure 2.64 Select two points from Survey Point library – 1

Line Detail		
Name	Line0	
Code		
2 features		Multiselect
Name	Code	Length(m)
Base_0		-
PT1		1.1081
<div> Add BO Return </div>		

Figure 2.65 Select two points from Survey Point library – 2

Click [BO] to close the new survey line.

Click [Return] and the new survey line has been added as below.




Figure 2.66 Survey Line added

The added survey line can be viewed under [Survey] -> [Point Survey] shown as below.




Figure 2.67 Survey Line in Survey interface

## 2) View and edit survey line

In the Line interface, select the line to be edited. Then click [Detail] to enter the edit page shown as below.

←
Line Detail

**Name**
Line2

**Code**
test

2 features
Multiselect

Name	Code	Length(m)
PT3		-
PT6		0.0719

Add

Return

Figure 2.68 Edit the Survey Line Line2

If not selecting a point, click [Add] to add a point at the end shown as Figure 2.69; if selecting a point, then click [Add] to insert a point before the selected point shown as Figure 2.71. After adding the point, the length will be recalculated, and then enter the survey interface to find that the added point is connected to the line shown as Figure 2.70 and Figure 2.72.




Figure 2.69 Add PT5 to the line end




Figure 2.70 The new Line2 in survey interface




Figure 2.71 Add PT5 before PT6




Figure 2.72 The new Line2 in survey interface

Click [BO] to close the survey line.

Click [Multiselect] to select a point and click [Delete]. After the deletion, the length will be recalculated, and then enter the survey interface to find that the deleted point is no longer connected to the line. For example, after deleting PT5 in Line2, this point PT5 is no longer in Line2 shown as below.

**Note:** After deleting the point in the line, the point and its information will be retained in the point library. It exists as a point, but it is no longer connected to the line.




Figure 2.73 Delete PT5 in Line2





Figure 2.74 Line2 after deleting PT5

### 3) Query survey line

Click the  icon at the up-right corner, the line query interface is shown as below. Input the search items and tick the item, click [OK] to search the line.




Figure 2.75 Line Query interface

### 4) Delete survey line

In the Survey Line interface, click [Multiselect] to enter the following interface. Tick the line to be deleted, then click [Delete] to complete deletion.




Figure 2.76 Survey line interface




Figure 2.77 Tick the line to be deleted

## 2.5.2 Staking Line

### 1) Add staking line

Click [Add] under Stakeout Line to enter the following interface, there are four types of staking line: line, polyline, arc and circle.




Figure 2.78 Four types of staking line

#### a. Line




Figure 2.79 Add line method 1





Figure 2.80 Add line method 2

#### ● Two Points:

Input the name of the line, then click  to import the start point and end point.

- One point + Azimuth + Distance

Input the name of the line, then click  to import the start point from a point library.


Input the other information for the line.

Start Mileage: default is 0. The mileage of other points on the line will be obtained by adding the start mileage and the mileage from the starting point.

#### Point On Line Staking

- Turn on this function, you can set the pile interval and the stakeout will start from the starting point of the staking line to the end point at this interval.
- Turn off this function, the stakeout will be to the vertical cross point between the current position and the staking line (or the extension line).

#### b. Polyline



Name	Code	Length(feet)
0 features		

Figure 2.81 Add polyline

Add the points that form the polyline one by one, and click Return to save the polyline as the staking line.

Start Mileage: default is 0. The mileage of other points on the line will be obtained by adding the start mileage and the mileage from the starting point.



### c. Arc




Figure 2.82 Add arc method 1





Figure 2.83 Add arc method 2

- Three points: Select the starting point, the middle point and the end point to form the arc.
- Two points + Radius: Select the starting point and end point, enter the radius, select the turning direction and shape of the arc from the starting point to the end point, the software can automatically calculate the center coordinates of the circle to form the arc.

Start Mileage: default is 0. The mileage of other points on the line will be obtained by adding the start mileage and the mileage from the starting point.


#### d. Circle



The screenshot shows the 'Add Staking Line' screen with the following fields:

- Line Type:** Circle >
- Method:** Three points >
- Name:** StakeLine23
- Point1:** [Icon]
- Point2:** [Icon]
- Point3:** [Icon]
- Start Mileage(feet):** 0
- OK** button at the bottom.

Figure 2.84 Add circle method 1



The screenshot shows the 'Add Staking Line' screen with the following fields:

- Line Type:** Circle >
- Method:** Center points + Radius >
- Name:** StakeLine23
- Center Point:** [Icon]
- Radius:** Input
- Start Mileage(feet):** 0
- OK** button at the bottom.

Figure 2.85 Add circle method 2

- Three points: Select three points on the circle to form a circle.
- Center point + Radius: Select the center of the circle and enter the radius to form the circle.

Start Mileage: default is 0. The mileage of other points on the line will be obtained by adding the start mileage and the mileage from the starting point.

#### 2) View and edit staking line

In staking line interface, select a staking line, click [Detail] to enter the edit page and edit the line parameters shown as below.

#### 3) Query staking line

Query of a staking line is the same with query of a survey line, enter the line query interface, input the search items and tick the item, click [OK] to search the staking line.

#### 4) Delete staking line

Deleting a staking line is the same with deleting a survey line, in the staking line interface, click [Multiselect] and tick the staking line to be deleted, click [OK] to

complete the deletion.

## 2.6 Road

Road management is used to create or edit road data.



Figure 2.86 Road List interface

### 2.6.1 Add new road

The road contains a variety of feature factors. The current software supports the use of station equation, intersection method or element method to edit the road's alignment, vertical profile, cross section, super elevation, and widening. Click [Road] -> [New] to enter the Add Road interface. Enter the road name, start miles and parameters of the road.

←
Add Road

Name
Input

Start Miles(m)
0

Stopped Chain

Count:
>

Horizontal Alignment

Count:
Length
>

TYPE
>

Vertical Profile

Count:
>

Cross Section

Count(LF)
Count(RT)
>

:
:
>

Super Elevation

Count:
>

Pile Point Detail

Preview


Figure 2.87 Add Road interface

### Station equation

A station equation refers to the phenomenon that the stake number is not continued due to stationing changes or section measurement.

### Alignment

The horizontal alignment is a curve that describes the turning and trend of the road curve in the horizontal plane. It generally consists of straight lines, arcs, and transition curves. The transition curve used in the calculation of the software is the clothoid (also known as Cornu spiral or Euler spiral) commonly used in road design.



← Road Detail


TYPE Intersection Method >

4 features Multiselect

#	TYPE	Mileage	N(m)	
1	Broken	K32+0	3091723.240	4823
2	Crossover	K33+949.479	3090397.904	4837
3	Crossover	K38+638.354	3088006.893	4877
4	Broken	K41+127.178	3086055.749	4893

Add Edit

Figure 2.88 Intersection method interface



← Road Detail

TYPE Element Method >

9 features Multiselect

#	TYPE	Mileage	Start Radius	End
1	Line	K32+0	∞	
2	Transition Curve	K32+707.324	∞	800
3	Circle	K33+297.324	8000.0000	800
4	Transition Curve	K33+710.326	8000.0000	
5	Line	K35+710.326	∞	
6	Transition Curve	K37+47.5073	∞	700
7	Circle	K37+727.507	7000.0000	700
8	Transition	K39+522.172	7000.0000	

Add Edit

Figure 2.89 Element method interface

### Alignment - Intersection method

The intersection method is based on the intersection point in the alignment, and the coordinates are obtained through the intersection point and the route. The general intersection point method to construct an alignment consists of a starting polyline point, N intersection points and an ending polyline point. Enter the coordinates of the designed road at the starting and ending polyline points; the intersection needs to enter the coordinates of the designed intersection point, the length of the entry transition curve, the radius and the length of the exit transition curve. The software will automatically calculate the elements contained under the intersection and draw the road alignment.

The current software supports the conversion calculation from the intersection method to the element method; supports the input of the intersection method of the complete symmetric transition curve and the complete asymmetric transition curve; supports the intersection method input when the transition curve length is 0 or the arc length is 0; it does not support the input of incomplete transition curve; it does not support the intersection method input of special curve such as a turning curve.

### Alignment - Element method

The element method is a method to calculate the alignment coordinates from the node elements such as the starting point coordinates, azimuth angle, starting point stake number and ending point stake number of the road. Select the corresponding elements

when entering the element method, including straight lines, left-turning arcs, right-turning arcs, left-turning transition curves, right-turning transition curves, and then input the corresponding feature parameters of the elements, such as the length, start radius and end radius of the transition curve. The software will draw a road alignment according to the input line elements.

### **Vertical Profile**

A vertical profile refers to the curve that connects two adjacent wavebands on the vertical section of the line with the slope point as the intersection point. The vertical profile describes the change of the elevation coordinate of the middle stake point. The vertical profile in the software is calculated using a parabola.

### **Cross Section**

The cross section refers to the section perpendicular to the center line of the road at the center pile. The main components include motor vehicle lanes, non-motor vehicle lanes, sidewalks, hard shoulders, soil shoulders, central separation belts, and side partitions.

The cross section need to be established on the vertical profile.

The super-elevation and widening properties in the software need to be established on the basis of the standard cross section.

### **Super Elevation**

When a vehicle is driving on a curve, it will slip due to lateral force or centrifugal force. In order to offset the centrifugal force generated by the vehicle driving on the curve and ensure that the vehicle passes the curve safely and stably, a unidirectional cross-slope that is higher on the outside than the inside will be set on the cross section of the curved road section, which is the super-elevation property of the road. The superelevation of the road in the software is based on the standard cross-section, which will be reflected in the changes in the slope of the plates composed of different cross-sections, and will ultimately affect the change of the elevation coordinates of the side piles.

### **Widening**


When the vehicle is driving on a curve, the driving trajectory of each wheel is different. The radius of the driving trajectory of the rear wheel on the inner side of the curve is the smallest, and the radius of the driving trajectory of the front wheel near the outer side of

the curve is the largest. This phenomenon is more prominent when the radius of the driving curve is small. In order to ensure that the car does not encroach on the adjacent lanes when turning, the curved road sections need to be widened. The widening of the road in the software will be based on the standard cross-section, which will be reflected in the changes in the width of the plates composed of different cross-sections, and will ultimately affect the change of the side pile coordinates.

After the road parameters input is completed, use [Pile Point Detail] and [Preview] to check and confirm the road data.

### Pile Point Detail

Click [Pile Point Detail] to enter the interface, input the start mileage and set the interval to check the road, then set the storage path. Click [Query] to show the coordinates of the point on the road in list, and click [Export] to export the road data list to the designated folder.



#	Mileage	N(m)	E(m)	I
1	K32+0	3091723.240 0	482321.8770	0
2	K32+20	3091709.643 2	482336.5442	0
3	K32+40	3091696.046 4	482351.2114	0
4	K32+60	3091682.449	482365.8786	0

Figure 2.90 Pile Point Detail

### Preview

Click [Preview] to enter the interface, click [Horizontal Alignment] to show the graphics of the road route in the overhead direction, to judge whether the alignment parameters input are abnormal by the road shape; click [Vertical Profile] to show the elevation change along

the center-line of the road, and enter the mileage or drag the red line to query the elevation of specified mileage; click [Cross Section] to show the road cross-section changes, and enter the mileage or drag the bottom progress bar to display the cross section at the specified mileage.




Figure 2.91 Preview Alignment




Figure 2.92 Preview Cross Section

## 2.6.2 Edit road

In the road interface, choose a road file and click [Edit] to make edition of the existing road.

If the road alignment is created by the intersection method, then it is to edit using the intersection method by default; if the road alignment is created by the element method, then it is to edit using the element method by default. If the road is created by the intersection method, after using the software to switch to the element method, click [Edit], then the software will pop up a prompt asking whether to change from the intersection method to the element method. This mode modification is irreversible.







Figure 2.93 Change method when editing road


### 2.6.3 Delete road

Choose a road file in the road interface, click [Delete] to delete this existing road.

### 2.6.4 Import/Export road

Tersus road files are in .trd format and stored in the TersusSurvey\Road folder. If a road is created on the Nuwa software of another controller, you can copy the .trd file to this path and open the Nuwa software to load the road.

In the Road interface, click the icon , select the road file in LandXML or PHI format, and click [Import] to import the alignment.

In the Road interface, select the road, click the icon , set the storage path to export the cross-section survey data to the designated folder.

## 2.7 Import

There are two types of import: Coordinate Import and Other Import. Coordinate import is

to import files with .csv and .dat format. Other Import is to import files with .dxf, .shp and .sima format.

### 2.7.1 Coordinate Import

Under the Coordinate Import interface, select Type, Target Point library to be added, Data Format, File Format and the file path where the file is located, click [Import] to complete the import.




Figure 2.94 Import interface

The figure above shows the parameters that should be selected or filled for coordinate import.




Figure 2.95 Import Type

For point import, select [Point] for Type as shown above.




Figure 2.96 Target Point Library

The target point library has three options: control point, stakeout point and survey point as shown above.




Figure 2.97 Data Format options

The data format options for data import are listed in the figure above.




Figure 2.98 File Format options

There are two options for file format of imported points: .csv;.txt and .dat files.




Figure 2.99 Import Line interface

For line import, select [Line] for Type in Figure 2.94 and it goes to the import line interface as shown in Figure 2.98 above. The file format for line is .lnb file.

The line file is a text file with the .lnb extension in nature. The detailed content in the text file is shown as below. The information from left to right is: starting point name, starting point N, starting point E, starting point h, 0, ending point name, ending point N, ending point E, ending point h, 0, 0.

```
5K+250-1,3453407.198,496492.9505,0,0,5K+250-2,3453312.565,496460.4625,0,0,0
5K+300-1,3453388.743,496542.6277,0,0,5K+300-2,3453300.967,496507.4977,0,0,0
5K+350-1,3453368.497,496589.9064,0,0,5K+350-2,3453277.249,496550.8326,0,0,0
```

Figure 2.100 Example content in the .lnb file

## 2.7.2 Other Import

Under the Other Import interface, select the file format, type, target point and the file path, click [Import] to import the file. Now Nuwa supports importing DXF, SHP, SIMA, KML, KMZ, NCN and LandXML files. And the Type can be selected as vector base map when the file format is DXF, KML/KMZ, LandXML. The imported vector map can be selected and displayed in the Survey and Stakeout interface after import. When the Type is selected as point, the target point library can be selected as Survey Point, Control Point and Staking Point.




Figure 2.101 Other Import interface




Figure 2.102 File format for other import




Figure 2.103 Import as Vector Map




Figure 2.104 Target point options

## 2.8 Export

Correspondingly there are two types of export: Coordinate Export and Other Export. Coordinate Export is to export .csv files whose file name extension can be modified as .dat; Other Export is to export files with .kml, .shp, .dxf, .html, .xml, .sima, .kmz, .ncn and .rw5 format.

## 2.8.1 Coordinate Export

Under the Coordinate Export interface, select Point Type, Date range and Data Format, ensure the File Name and Storage Path is correct.




Figure 2.105 Export Interface

Thereafter click [Export] to complete the export.




Figure 2.106 Data Format options

For Data Format, the user-defined format can be created or managed. Click [User defined]



and it prompts out an option for data format: create data format and manage data format which are shown as below.




Figure 2.107 User defined data




Figure 2.108 Create data format




Figure 2.109 Manage data format

## 2.8.2 Other Export

Under the Other Export interface, file format can be KML, SHP, DXF, HTML, XML, SIMA, KMZ, NCN, RW5, RAW or LandXML. Type in the export file name and click [Export] to complete the file export.




Figure 2.110 Other Export interface




Figure 2.111 File Format for other export

If selecting XML for the file format, select start date and stop date of the Stop&Go survey to ensure the XML file recorded the correct stop points during the Stop&Go survey work.

Figure 2.112 Export XML file

Copy the XML file to a computer and open this XML file using a text reader software. Change the rover observation file name on the fifth row to the rover Rinex file name which is shown as below.

```
<?xml version="1.0" encoding="UTF-8"?>
- <GNSSProject xmlns:xsd="http://www.w3.org/2001/XMLSchema"
  xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance">
  <Collector Version="" Name="TERSUS"/>
  - <Rovers>
    - <Rover ObsFile="xxx.190">
      <Antenna Model="" Height="1.8180"/>
      <RefTime GPSSecond="443435" GPSWeek="2074"/>
      <Points/>
    - <Sites>
      - <Site Reference="" OnPozId="138" Code="Line10" Id="PT174">
        <Position Height="34.8386" Longitude="121.59318585" Latitude="31.19041192"/>
        - <TimeCoverage>
          <StartTime GPSSecond="443435" GPSWeek="2074"/>
          <EndTime GPSSecond="443435" GPSWeek="2074"/>
        </TimeCoverage>
        <StandardDeviation Height="0.0000" Longitude="0.0000" Latitude="0.0000"/>
      </Site>
      - <Site Reference="" OnPozId="138" Code="Line10" Id="PT175">
        <Position Height="34.8386" Longitude="121.59318585" Latitude="31.19041192"/>
        - <TimeCoverage>
          <StartTime GPSSecond="443436" GPSWeek="2074"/>
          <EndTime GPSSecond="443436" GPSWeek="2074"/>
        </TimeCoverage>
        <StandardDeviation Height="0.0000" Longitude="0.0000" Latitude="0.0000"/>
      </Site>
      - <Site Reference="" OnPozId="138" Code="Line10" Id="PT176">
        <Position Height="34.8386" Longitude="121.59318585" Latitude="31.19041192"/>
        - <TimeCoverage>
          <StartTime GPSSecond="443438" GPSWeek="2074"/>

```

change "XXX" to the rover rinex file name

Figure 2.113 Preview of the XML file in text mode

Import the base observation file, rover observation file and the edited XML file to EZSurv application, and EZSurv will identify these files successfully.

## 2.9 Settings

Settings interface is shown as below, the function descriptions is as follows.




Figure 2.114 Settings interface

[Coord Display]: can be selected from degree (DD.DDDDDDDDD), DM (DD:MM.MMMM) or DMS (DD:MM:SS.SS).

[Coord Order]: the coordinate display order can be NEh, ENh, xyh or yxh. The display order of north and east coordinates will be displayed in the software according to the selected coordinate type format.

[Length Unit]: can be selected from Km, meter, Inch, Feet or US feet.

[Area Unit]: can be selected from Mu, Square Km, Square Meter, Hectare and Acre.

[Normally On]: the screen would be always on if it is enabled.

[Update Detection]: Auto update detection is on if it is enabled.

[Version]: the current version of the Nuwa app.

[Zone]: select the time zone according to the current position.

[Language]: support Auto, Chinese, English, French, Spanish, German, Portuguese, Italian, Russian, Japanese, Korean, Malay, Arabic, Thai, Turkish, Greek, Bulgarian, and Traditional Chinese.

[Location Sharing]: if it is enabled, it will automatically jump to the android system setting interface. Select Nuwa for the mock location app, the location would be shared with other apps.

[Controller Voice]: if it is enabled, after configuring TTS engine and language in the controller system settings - language settings - Text-To-Speech (TTS) output, Nuwa will broadcast the voice when setting the base / rover mode and the solution status change.

When Nuwa app is connected with Oscar GNSS Receiver or Luka GNSS Receiver, you can choose whether to shut down the receiver if you try to exit Nuwa app.





Figure 2.115 Check if shut down Oscar

## 2.10 Cloud Setting

Settings and configuration to use Tersus Cloud.

Tersus GNSS Cloud service is a service that provides users of Tersus software with on cloud data storage, synchronization and management functions. You can register an account through email to use Tersus Cloud, or directly apply for an account from Tersus support team. Enter the server address *cloud.tersus-gnss.com*, and the correct user name


and password, then check to agree to the Legal Notice and Privacy Policy, to log in to Tersus Cloud.



The image shows a mobile app interface titled "Cloud Setting". At the top is a back arrow and the title. Below is the TERSUS GNSS logo. There is a text input field containing "cloud.tersus-gnss.com" with a cloud icon on the left and a close icon on the right. Below this are two more text input fields: "User Name" with a person icon and "Password" with a lock icon. There are two buttons: a dark "Login" button and a light "Register" button. At the bottom, there is a checkbox followed by the text "I have agreed to [Legal Notice](#) and [Privacy Policy](#)".

Figure 2.116 Login interface in Cloud Setting

If you do not have an account and need to register, click the [Register] button on the page or log in to the *cloud.tersus-gnss.com* page on the browser then click the register button. Enter your email address, click [Request verification link], then click the verification link in the email you receive and follow the operation guide to enter your password to complete the creation of your Tersus Cloud account.



The image shows a web browser address bar with "cloud.tersus-gnss.com/index.php/". Below is the TERSUS GNSS logo. There is a text input field with an email icon and the label "Email". Below this is a button labeled "Request verification link". At the bottom, there is a link labeled "Back to login". At the very bottom, there is text that reads "Tersus Cloud – Right to the Point" followed by "Legal notice · Privacy policy".

Figure 2.117 Registration interface

After logging in to Tersus Cloud, the interface is as follows. Click [Sync] to synchronize

the projects in the controller and on the cloud. After clicking [Sync], the software will automatically judge whether each project need to be uploaded or downloaded according to the update time of project. You can also manually edit the upload or download status of each project, to finish the synchronization.




Figure 2.118 Sync projects after login

After logging in to Tersus Cloud, you can enter the project list screen, click the icon in the upper tight corner to select the current project to upload or download a single project from the cloud. After logging in to Tersus Cloud, you can also enter the data import screen and choose to import data from the cloud, or enter the data export screen and choose to export data to the cloud.

You can log in to Tersus Cloud *cloud.tersus-gnss.com* through a browser. There, the data files exported from the controller to the cloud, or the data files for importing from the cloud are stored in */Oscar/Data* path. And the projects synchronized or uploaded from the controller are stored in */Oscar/Project* path.




Figure 2.119 Data on Tersus Cloud




Figure 2.120 Projects on Tersus Cloud



### 3. Device

- Connect
- Data Terminal
- Base
- Rover
- NMEA Output
- Device





Figure 3.1 Functions under Device

### 3.1 Connect

There are two ways to enter the Connect interface: Click [Device] -> [Connect] or click  on the up right corner in the status bar. Screenshots and descriptions are as follows.




Figure 3.2 Device functional group




Figure 3.3 Connect interface – David




Figure 3.4 Connect interface – Oscar




Figure 3.5 Connect interface – Luka

**[Device Type]:** can be selected from David, Oscar, Luka, NMEA<sup>1</sup> devices, or Simulation.

**[Connect Type]:** can be selected from USB or Bluetooth.

**[Connect Config]:** shows the device name to be connected

**[Antenna]:** can be selected from the antenna list. An antenna with user-defined parameters can be added and selected.

<sup>1</sup>**Note:** NMEA devices should be able to output one of following data: GGA / GSA / GSV / GST / RMC / RANGE.




Figure 3.6 Two connection types for David

- USB connection: David can be connected to an android device using a 'USB Type A Female to USB (Micro+Type C) OTG cable' in the package. The detailed connection refers to *User Manual for David GNSS Receiver*.
  - Bluetooth connection: David can be connected to an android device via wireless method – Bluetooth using 'COMM1-Bluetooth module' in the package.
- 1) Add Bluetooth to the list: select Bluetooth for the [Connect Type], click [Connect Config] and [Search], choose the Bluetooth module to be paired.




Figure 3.7 Bluetooth searching




Figure 3.8 Bluetooth is pairing



Figure 3.9 Bluetooth paired

- 2) Remove paired Bluetooth: long press the paired Bluetooth name in the Bluetooth list to remove this paired Bluetooth device in the list.




Figure 3.10 Connect interface – Oscar




Figure 3.11 Connect interface – Luka

Currently the connection type for Oscar / Luka is Bluetooth only, the other connection types are under development. Stay tuned for the updates. The Bluetooth connection of Oscar / Luka is the same with that of David. OSCAR is selected as default antenna for Oscar GNSS Receiver. And LUKA is selected as default antenna for Luka GNSS Receiver.




Figure 3.12 Connect interface – NMEA

Currently this connect interface is showing MatrixRTK as an example. In fact, other NMEA

devices which support NMEA0183 can also be connected. For NMEA devices, only Bluetooth is used for connect type.

Click [Antenna] to enter the Antenna Manage interface which is shown as below.




Figure 3.13 Antenna Manage interface

Click [New] in the left bottom corner to add new antenna parameters which is shown as below.




Figure 3.14 Parameters for New Antenna

[Antenna]: input the antenna name for the new antenna.

[Radius]: input the radius of the new antenna when measuring the slant height. Input 0.13 when using the height measure accessory provided by Tersus.

[Phase Center]: input the height from the antenna phase center to the antenna bottom.

[Bottom height]: input the height from the antenna circumference to the antenna bottom.

**Note: the unit for the above three parameters is meter (m).**

The following figure explains the above three parameters taking AX3702 antenna for example. R: Radius; P: Phase center; B: Bottom height.

### Antenna Phase Center




Figure 3.15 Antenna parameters explanation

When selecting Simulation for the device type, the interface is as below.




Figure 3.16 Simulation connection interface



The simulation connection be simulated at the place around the coordinates according to the input coordinates or the coordinates selected from the library. The simulation connection can be used for demonstration of survey, stakeout, and etc. However, some functions such as working mode configuration will be restricted.

## 3.2 Data Terminal

In the data terminal interface, the output loggings can be monitored as shown below. It is outputting ASCII data when David is connected with AX3702 GNSS antenna and it is working normally.




Figure 3.17 Data Terminal interface

Check the box on the left of [Hex] to enable the above window output hex data which is shown below.



Figure 3.18 Data Terminal outputs hex data

Check the box on the left of [Paused] to pause the output logging.

Check the box on the left of [Log] to start recording log data. The log data is saved in a .txt file. Create file name in the pop-up window as shown below.




Figure 3.19 Create File Name

Click [OK] to confirm the file name, it automatically starts recording log data and stores the data in the default folder /storage/emulated/0/TersusSurvey/GpsLogger/xxxxxx.txt.




Figure 3.20 Start recording log data

Uncheck the box on the left of [Log] is to stop recording log data.




Figure 3.21 Stop recording log data

Click [Clear] to clear the screen.

Click [Commands] to output common NMEA loggings (not available for connecting Oscar / Luka). Check the commands and click [OK], it will return to the command window with the typed commands which is shown in Figure 3.17. Then click [Send] to send the commands to communicate with Tersus receivers.




Figure 3.22 Common Command

The detailed description of log and command refers to *Log & Command Reference for Tersus BX GNSS OEM boards* which can be downloaded on Tersus website.

**Note:** *[Commands] and [Send] are not available when Nuwa is connected with Oscar / Luka.*

### 3.3 Base

Some default base configurations are provided for David and Oscar / Luka. Select a configuration file in the Work Mode List and click [Detail] to edit the base configuration. Click [Start] to complete the base configuration.

[Startup]: auto start or manual start

- Auto start: the position of the base is achieved automatically.
- Manual start: base coordinate is achieved by averaging collection, loaded from a point library or input manually.

[Data Link]: radio or network for **David**.

- Radio: the corrections are output to an external radio, serial baud rate should be selected accordingly.

- Network: the corrections are uploaded to a Ntrip server or TCP host. The IP address, port, password and mount point of the Ntrip server should be input manually; The IP address and port of the TCP host should be input.

Four options for data link of **Oscar / Luka**.

- External Radio: the corrections are transmitted via 25W radio.
- Internal Radio: the corrections are transmitted via internal 2W radio of Oscar or internal 1.5W radio of Luka. Oscar internal radio currently supports three transmit powers of 0.5W, 1W, and 2W, Luka internal radio currently supports two transmit powers of 0.5W and 1.5W, and supports five protocols, TransEOT, TT450, SOUTH, SATEL, and TRIMMK3, and two corresponding air baud rates 9600bps and 19200bps. Each protocol supports ten channels and customized frequency. Select 0~9 channel on Nuwa will automatically read the corresponding frequency to the channel.
- Receiver Network: the corrections are uploaded to Ntrip server or TCP host, or Tersus Caster Service (TCS) using Oscar / Luka network. The IP address, port, password and mount point of the host should be input manually.
- PDA Network: the corrections are uploaded to Ntrip or TCP host, or Tersus Caster Service (TCS) using a PDA device. The IP address, port, password and mount point of the host should be input manually.

[Baud Rate]: the serial baud rate can be selected from 9600 to 921600, the default is 38400bps for David and 115200bps for Oscar / Luka. The air baud rate for Oscar / Luka internal radio can be selected from 9600 and 19200.

[Differential Format]: CMR, CMR+, RTCM2.3, RTCM3.0 and RTCM3.2 are supported.

### 3.3.1. Set David as a Base

The detailed description for each configuration of **David** as a base is shown in below screenshots.

Click [New] to create a new base configuration. In the figure below, for auto start in radio mode, baud rate is 38400 by default and can be selected in the pop-up list below. The differential format is RTCM3.2 by default.




Figure 3.23 David base auto start – Radio





Figure 3.24 Baud rate options

The detailed information of how to use radio refers to *User Manual for David GNSS Receiver*.

In the figure below, for auto start in network mode, the host IP can be manually typed or selected by clicking the icon  on the right of row Host. It shows two Ntrip servers built by Tersus GNSS Inc. and can be selected depending on different area. Please contact

Tersus technical support for the two Ntrip servers. The site list can be added, edited and deleted. For Ntrip network, host IP, port, password and mount point should be input. The mount point can be customized, and it is generally recommended to enter **the last four digits of the device's SN** as the mount point to distinguish. For TCP network, host IP and port should be input. TCS is a unique protocol from Tersus, the software automatically obtains the SN of current device as base ID. Contact Tersus technical support for password and mount point information if you bought products from Tersus.




Figure 3.25 David base auto start – Ntrip




Figure 3.26 David base auto start – TCP




Figure 3.27 David base auto start – TCS



Name	IP	Port
Default	asiacaster1.tersus-gnss.com	2201
Default	usacaster1.tersus-gnss.com	2101



Figure 3.28 Ntrip Site Manager

Ntrip status viewing method when the base station is connected to Ntrip server:

Take asiacaster for example, open any browser on the computer (accessible to internet) and enter the following URL in the address bar:

<http://asiacaster1.tersus-gnss.com:2201/Ntrip.html?usr=username&pwd=password>

in which, the **username** and **password** should be obtained from Tersus GNSS Inc.

In the figure above, for manual start in radio mode, the base coordinate should be typed manually or obtained by clicking  the location icon or imported from the survey point library by clicking  the list icon. The other parameters setting is the same with that in auto start radio mode.




Figure 3.29 David base manual start – Radio

In the figure below, for manual start in network mode, the base coordinate setting is the same with the method mentioned above, the network host setting is the same with the method described for auto start in network mode.






Figure 3.30 David base manual Start – Network

### 3.3.2. Set Oscar / Luka as a Base

The detailed description for each configuration of **Oscar / Luka** as a base is shown in below screenshots.

Click [New] to create a new base configuration.

When the startup mode is *Auto start*, the "Keep coordinates after reboot" checkbox appears. If it is checked, receiver will keep the base station mode after reboot and the base station coordinates will be the same as before reboot. If it is unchecked, receiver will keep the base station mode, but the base station coordinates will be regenerated by single positioning.

When the startup mode is *Manual start*, the "Keep mode after reboot" checkbox appears. If it is checked, receiver will keep the base station mode and keep the base station coordinates. If it is unchecked, receiver will be in single mode after reboot.




Figure 3.31 Oscar / Luka base auto start – 4 data link options

- External Radio: the configuration method of base with external radio is similar with that of David base with radio stated above. The difference is that the default serial baud rate is 115200bps.
- Internal Radio: if choosing to use the internal radio, user needs to select proper air baud rate, transmitting power, protocol, channel and frequency. It also displays the modulation type and bandwidth. The call sign parameters can be configured for the internal radio. The customers in some countries or areas can configure call sign function according to requirement.

←

Create Base Config

Startup

Auto start >

Data Link

Internal Radio >

Air Baud Rate

9600 >

Power

Low(0.5W) >

Protocol

Transparent >

Modulation

GMSK

Bandwidth

25kHz

WorkChannel

0 >

Channel Freq

0.0

Differential Format

RTCM3.2 >

☐ Call Sign

Call Sign ID

Input

Call Sign Interval(Min)

Input

OK

Figure 3.32 Oscar / Luka base auto start – internal radio

- **Receiver Network:** if choosing to use receiver network to transmit corrections, there are three protocol options to select: Ntrip, TCP and TCS (Tersus Caster Service). Fill in the corresponding IP address, port, password, mount point and base ID if necessary to connect to the receiver network.




Figure 3.33 Oscar / Luka base auto start –




Figure 3.34 Oscar / Luka base auto start – Ntrip

receiver network options




Figure 3.35 Oscar / Luka base auto start – TCP

network




Figure 3.36 Oscar / Luka base auto start – TCS

network

network

- PDA Network: there are also three protocol options of PDA network to select: Ntrip, TCP and TCS (Tersus Caster Service). The required information to input for different protocol is different, refer to the screenshots above.






Figure 3.37 Oscar / Luka base auto start – PDA network options

For Oscar / Luka manual start in radio mode and network mode, the base coordinate should be typed manually or obtained by clicking  the location icon or imported from the survey point library by clicking  the list icon. The data link options configuration are the same with the method mentioned above in Oscar / Luka base auto start in radio and network modes.

### 3.4 Rover

Some default rover configurations are provided for David and Oscar / Luka. Select a configuration file in the Work Mode List and click [Detail] to edit the rover configuration. Click [Start] to complete the rover configuration.

#### 3.4.1. Set David as a Rover

The detailed description for each configuration of **David** as a rover is shown in below screenshots.

Click [New] to create a new rover configuration. In Figure 3.36 below, for rover configuration in radio mode, the baud rate is 38400 by default and can be selected from 9600 to 921600 in the pop-up list as shown in Figure 3.24.




Figure 3.38 Create Rover Configuration for David – Radio

In Figure 3.37 below, for rover configuration in network mode, the protocol type can be selected from Ntrip, TCP and TCS.




Figure 3.39 Create Rover Configuration for David – Ntrip Network






Figure 3.40 Protocol type options

When Ntrip network is selected, the host can be manually typed or selected by clicking the icon  on the right of the Host row as mentioned in Figure 3.28 above. The username and password should be obtained from Tersus technical support. The box on the right of Mount Point displays the mount point and differential format after clicking the refresh icon  to update the source table. The example is shown below. If the connected CORS broadcasts the RTCM1021/1023/1025 coordinate system data, after solving the data, Nuwa app will ask whether to replace the coordinate system parameter in the current project.




Figure 3.41 Edit Rover Configuration

When TCP is selected for protocol type, fill in the information of host and port according to customer requirements to complete the configuration.




Figure 3.42 Create Rover configuration for David – TCP Network

When TCS is selected for protocol type, fill in the information of host, fill in the base ID and it will obtain differential correction data from designated base station.



Figure 3.43 Create Rover configuration for David – TCS network

### 3.4.2. Set Oscar / Luka as a Rover

The detailed description for each configuration of **Oscar / Luka** as a rover is shown in below screenshots.



Click [New] to create a new rover configuration. It shows the rover configuration using the internal radio of Oscar / Luka as below. Choose appropriate baud rate, communication protocol, work channel and channel frequency. Click [OK] and type the configuration name to complete creating a rover configuration of Oscar / Luka.




Figure 3.44 Create Rover Configuration for Oscar / Luka – Internal Radio

The data link can be selected from an option list: Internal Radio, Receiver Network and PDA Network shown as below.




Figure 3.45 Oscar / Luka rover data link options

When Receiver Network is selected for rover communication, there are three protocol options to select: Ntrip, TCP and TCS (Tersus Caster Service). Fill in the corresponding

host, port, password, mount point and base ID if necessary to connect to the receiver network.




Figure 3.46 Oscar / Luka rover using receiver network – protocol options

When PDA Network is selected for rover communication, there are also three protocol options of PDA network to select: Ntrip, TCP and TCS (Tersus Caster Service).




Figure 3.47 Oscar / Luka rover using PDA network – protocol options

When selecting Ntrip as the protocol type, if the CORS service broadcasts RTCM1021 (ellipsoid and datum parameters), RTCM1023 (residual grid) or RTCM1025 (projection parameters), then check these check boxes, and after receiving these data and solving

them, Nuwa will ask to replace the coordinate system parameters in the current project. If checked (all are checked by default), but the data is not actually parsed, it will not affect the parameters.

### 3.5 NMEA Output

The NMEA output function is only available when Oscar receiver or Luka receiver is connected. NMEA data output via serial port and TCP are currently supported. The baud rate can be selected in the pop-out list from 9600 to 921600 bps. Parameters such as Host and Port of the TCP server and Header can be configured. The frequency of output NMEA data can be selected in the pop-out list.




Figure 3.48 NMEA Output




Figure 3.49 Baud rate options





Figure 3.50 Frequency options

## 3.6 Device

### 3.6.1 David's device information

When Nuwa is connected with David GNSS Receiver, click [Device] -> [Device] to view the detailed information of David.



The screenshot shows the 'Device' screen with a back arrow and the title 'Device'. It contains two main sections: 'Device Info' and 'Register Info'.

**Device Info**

Type	David
SN	10000118231000
Version	0441_debug
Battery	N/A
Disk Use	N/A
Mode	General
Tilt Enable	<input type="checkbox"/>
Device Debug	<input type="checkbox"/>
Electronic Bubble	<input type="button" value="Adjust"/>

**Register Info**

Register State	Effective registration
Expired Date	20201230
FilePath	/storage/emulated/0/TersusSurvey

Below the registration info, there is a list of hexadecimal values:

```

24D: 0F
64229730C0010F070200000F 3
BFC71
68A0F
A1: 39
  
```

At the bottom, there are three buttons: 'Reset', 'Register', and 'Refresh'.

Figure 3.51 David's device info

In the figure above, the SN row displays complete serial number for David, the battery and disk use are not available. Mode indicates working mode which includes General, Base, and Rover. Tile Enable and Electronic Bubble are not available and cannot be turned on.

When the David receiver has an unknown error, turning on Device Debug to record Tersus specific data to troubleshoot receiver which can help us better improve receiver's function.

**Note: This function and static survey cannot be turned on at the same time. Please manually turn off the static survey before using Device Debug.**

### Registration

When the registration is not effective, follow below steps to complete the registration.

- 1) Connect the TC20 controller to PC with a mini USB cable, and choose "Use USB for Transfer files" on the TC20 screen.
- 2) Click TC20 -> Internal storage -> TersusSurvey on the PC, then copy the license file (obtained from Tersus Technical Support) to the "TersusSurvey" folder.
- 3) Open Nuwa software, click [Register] in Device information interface. Click [Refresh] to update the registration status.

**Note:**

- The registration file is text format file saved as xxx.txt.
- David's registration file name is the same with the SN number. The example is as below.



Figure 3.52 Example of David's registration file

Clicking [Reset] resets the receiver into factory settings.

### 3.6.2 Oscar / Luka 's device information

When Nuwa is connected with Oscar GNSS Receiver or Luka GNSS Receiver, click [Device] -> [Device] to view the detailed information of Oscar / Luka.

←

Device

Device Info

Type	Oscar
SN	51801386
Version	fwver:V2.0.2RC5.020393.20220 111-1163 hwver:V2.1(2.1163)
Version Check	<div>Check</div>
Battery	73%
TEMP	37.19/39.05/32.36
Disk Use	(12089.88MB free) 4%
Clear Disk	<div>Clear</div>
Mode	General
Tilt Enable	<input type="checkbox"/>
Never Wrong	Extreme Reliable >
Voice	<input checked="" type="checkbox"/>
Change Battery	<input type="checkbox"/>
Electronic Bubble	<div>Adjust</div>
Satellite System	<div>Set</div>
Cellular	<div>Set</div>
Device Language	<div>Set</div>
Device Debug	<div>Set</div>
Wifi Setting	<div>Set</div>
Lock device	<div>Set</div>
Inner Log	<div>Sync</div>

Register Info

Reaister

Reset

Register

Refresh

Figure 3.53 Oscar's device info

In the figure above, only displays 8 digits number for receiver which is used for Bluetooth pairing, registration, TCS connection, and etc.

Click Version Check [Check], connecting to the server by PDA network or GSM module in receiver, to check whether the firmware needs to be upgraded. If the firmware needs to be upgraded, the word "new" will be displayed, and click "new" to download the latest version of firmware through receiver 4G / WIFI network and upgrade the firmware.

The battery row displays remaining battery level for receiver. The disk row shows receiver disk usage and remaining space. The mode row displays current working mode, which includes General, Base and Rover.

Tilt Enable is the tilt compensation applicable for Oscar GNSS receiver Ultimate version, Luka GNSS receiver Ultimate version and Luka GNSS receiver Advanced version. The detailed usage of this function refers to 4.4 Tilt Survey and Stakeout.

IMU Calibration is the tilt compensation applicable for Oscar GNSS receiver Ultimate version, Luka GNSS receiver Ultimate version and Luka GNSS receiver Advanced version. When the tilt enable is turned on, the error of the IMU and the pole can be calibrated by repeatedly tilting the pole at a point with known coordinates. This function may affect the accuracy of tilt measurement. Please only use it with caution after consulting Tersus, otherwise you will bear the consequences.

RTK Engine Mode:

[Rapid Fix]: With it, you can get stable fixed solutions much faster. The fixed threshold is slightly lower, and so is the confidence of the results.

[Extreme Reliable]: The results are very reliable, but it may take some time to get fixed solutions, especially in a challenging environment. The fixed threshold is high, and so is the confidence of the results.

[Balance]: It is the default setting, and the effect is somewhere in between the above two modes.

When Voice feature is turned on, receiver will voice over when the power is switched on and off, when Bluetooth is connected and disconnected, when the solution status is fixed and floating, and when the working mode changes.

When the battery change mode is turned on, turn off the receiver, replace the battery and restart the device, and it will maintain the working mode before shutting down; if the base



station is in auto start mode before shutting down, the original auto-start base station coordinates will be maintained; if the base station is started at a known point before shutting down, it will keep the mode of starting at the known point; if it was at rover mode before shutting down, it will keep the rover mode after changing battery.

### Electronic Bubble (eBubble)

This function is only available for Oscar GNSS Receiver and Luka GNSS Receiver. Make the body of the receiver stand on a leveled Tribrach before eBubble calibration.

Click **Adjust** on the right of electronic bubble to adjust bubble. On the screenshot below, the eBubble is not in the black circle and its color is red for warning purpose.




Figure 3.54 eBubble before adjusting

Click **Adjust** on the right, the eBubble is calibrated to the center inside the black circle and the bubble color turns blue.



Figure 3.55 eBubble after adjusting

Click Satellite System [Set], to select the system of satellite tracking for the receiver.

Click Cellular [Set], to view the status and configure the APN of network module in receiver.

Click Device Language [Set], to configure panel display language and voice language of receiver.

Click Device Debug [Set], to determine whether each module inside receiver needs to record the log information.

Click Wifi Setting [Set], to set Wifi module of receiver to OFF, AP mode or STA mode.

Click Lock device [Set], to set the password of receiver. After the password setting, a password should be entered for verification when connecting to the receiver. Click Unlock to cancel the password setting.

Click the Inner Log [Sync], after connecting the USB flash drive to the receiver through the OTG cable, to copy the logs recorded in receiver to the USB flash drive and then provide it to Tersus to verify and solve various problems that occurred in the field.

## Registration

When the registration is not effective, there are two methods to complete the registration. One is using USB cable and a computer.

- 1) Connect the TC20 controller to PC with a mini USB cable, and choose "Use USB for Transfer files" on the TC20 screen.
- 2) Click TC20 -> Internal storage -> TersusSurvey on the PC, then copy the license file (obtained from Tersus Technical Support) to the "TersusSurvey" folder.
- 3) Open Nuwa software, click [Register] in Device information interface. Click [Refresh] to update the registration status.

### Note:

- c) The registration file is text format file saved as xxx.txt.
- d) The registration file name consists of the first three digits and the last five digits of the SN number. The example is as below.




Figure 3.56 Example of registration file

The other method is registering using QR code.

Click the scan button at the top right of the device information interface and directly scan the QR code provided by Tersus to complete the registration.

Clicking [Reset] resets the receiver into factory settings.



## 4. Survey

- Survey
- Point Stakeout
- Line Stakeout
- Static Survey
- Site Calibration
- Survey Config
- Base Shift
- Road Stakeout
- Surface Stakeout
- CAD Stakeout




Figure 4.1 Functions under Survey

## 4.1 Survey

The Survey interface includes: status bar, input bar, background map, tools and information.




Figure 4.2 Survey – Drawing mode






























Figure 4.3 Survey – Text mode



## ➤ Status Bar

Icon	Description
	the main interface is shown in text mode or drawing mode, click this icon to switch between the two modes.
	Survey Configuration, refer to section 4.6 for more details.
	connection status with a Tersus GNSS receiver, refer to Connect for more details.
	satellite icon, with the number of satellites involved in solution on the right, e.g., 23 means 23 satellites are used.
	solution status, includes Single  , Float  , Fixed  , None  .
	data link type, includes Single mode  , Base mode  , Rover UHF mode  , Rover GSM mode  , Rover PDA Network mode  , with the number of Diff Age on the right. If the Diff Age is greater than the Diff Age Limit in survey config, the number is displayed in red.
	tilt status, includes tilt enable  and tilt disable  . The tilt compensation status shows on the right: OFF means the tilt compensation function is off, click it to jump to open it; N/S means the tilt compensation function is on, pending initialization; ON means the tilt compensation is available, and the accuracy meets the requirements.
	battery icon, with the number of the remaining battery power of GNSS receiver on the right. Currently it is not supported of displaying the battery of David as there is no embedded battery in David receiver.

## ➤ Input Bar

Icon	Description
	point name input box, the name for the next survey point.
	code input box, the code for the next survey point. Enter a code or click  to select a code in the code list. When selecting a code for point, such as Fence Post  , the next survey point will be used as a point feature; when selecting a code for line, such as EAVE  , then EAVE1 will be entered in the line name box, and the next survey point will be used as a point in the line feature, and the points belonging to the same line name will be connected to form the line.
	line name input box, the line name to which the next survey point belongs, enter or click  to select a line in the line list. When selecting a code for line, entering or selecting a line, the line survey starts, and the points belonging to the same line name will be connected to form the line.

### ➤ Background Map

Icon	Description
	view and edit the survey point library.
	click it to switch among none, OSM online map, Google online map, Google online map (China) and Google online aerial map.  After importing vector maps in Import module, or putting vector map files in DXF, LandXML, KML, KMZ format under the file path: internal storage\TersusSurvey\Maps, then you can choose the vector map you want to display in the list besides online map.

**Note: before loading a vector base map, ensure the coordinate**



**system parameters in the current project are consistent with the coordinate system parameters in the vector base map.**




Figure 4.4 Map options




Figure 4.5 DXF file list

After the dxf map is selected, Nuwa app will load the map. Select one point on the DXF base map, it prompts whether to stakeout the selected point. If you click OK, it switches to the point stakeout interface to stakeout this point.




Figure 4.6 Prompt to stakeout the point



Figure 4.7 Switch to point stakeout

Select a line on the DXF base map, it prompts whether to stakeout this line. If you click OK, it switches to the line stakeout interface to stakeout this line.




Figure 4.8 Prompt to stakeout the line








Figure 4.9 Switch to line stakeout

Icon	Description
	zoom in the map.
	zoom out the map.
	zoom with the current location at the center.
	place all the points in one view.

## ➤ Tools

Icon	Description
	electronic bubble: indicates leveling bubble calibration status. The bubble is blue when it is calibrated to the center inside the black circle, and is red when it is not calibrated to the center circle.
	Linework function: After clicking this icon, enter the line name and click [OK] to start line survey. In the line survey, the survey points collected will be connected into a line. The line is saved in the line list.

When the line survey is completed, click , choose to Close  or Non-close  the line, and then start to surveying the next line; or click  to change back to the point survey, then the next collecting survey points will not be connected to the line.

If entering the existing line name instead of a new one, it supports to continue the linework survey selecting from start or from end point.




Figure 4.10 Enter an existing line  
name








Figure 4.11 Continue the existing line  
options

	When selecting continuous for survey mode, click to start continuous points automatically survey.
	When selecting detail for survey mode, click to start detailed point survey.
	When selecting control for survey mode, click to start control point survey.
	When selecting control for survey mode, click to choose a control point and start checking survey for the point.

## ➤ Information Bar

Six information items are displayed, each can be chosen from the items in the following screenshots.




Figure 4.12 Information option list – part 1




Figure 4.13 Information option list – part 2

[North]: the North Coordinates of current position.

[East]: the East Coordinates of current position.

[Altitude]: the Altitude of current position.

[Lat]: the Latitude Coordinates of current position.

[Lon]: the Longitude Coordinates of current position.

[Height]: the ellipsoidal height of current position.

[Solution]: the status of RTK, including fixed, float, single, etc.

[Time]: current time.

[Speed]: current speed.

[Compass]: the azimuth of the controller.

[Ant.H]: the height of the receiver.

[RMS]: root mean square, precision indicators.

[DOP]: dilution of precision, the spatial geometric distribution of satellites.

[Target]: the name of the target in stakeout.

[Dn]: the distance between current position and the target in North direction.

[De]: the distance between current position and the target in East direction.

[Dh]: the difference in height between current position and the target.

[Offset]: the distance between current position and the target.

[Miles]: the miles of the target, from the start of the line.

[Remain miles]: the remain miles to the end of the line.

[TiltDirect]: the azimuth of tilt direction.

[TiltAngle]: the angle of tilt.

[Heading]: the heading of the receiver.

[Dis to Last]: the distance from the last survey point.

[Dis to Base]: the distance to Base reference station.

## 4.2 Point Stakeout





Figure 4.14 Point Stakeout interface

The above screenshot is the main interface of point stakeout, which is similar to that of point survey.




The main steps of point stakeout are as follows:

- Add stakeout point: click  to enter the stakeout point library which is shown in Figure 4.15 below, refer to section 0 for point library management.
- Select the point to be stakeout: select the point, then click [Select].

← Stakeout Point			
5 features		Multiselect	
id	Name	N	
L5	SPT1	3452290.9209	
L2	SPT2	3452290.9220	
L3	SPT3	3452290.9269	
L4	SPT4	3452290.9225	
L6	SPT9	3452248.6325	

Add Edit Import Select

Figure 4.15 Add stakeout point

- The offset between the current point and the target point is displayed on the screen.  
The arrow icons  and  are used to switch the stakeout points in the library. The icon  is used to switch to the nearest stakeout points in the library.
- If the display all staking point and point name are checked in Survey Config - Display Config, directly clicking on the point to be stake on the map can also used to switch the staking points.

In the point stakeout interface,

- The red flag indicates the location of the stakeout point.
- The red dotted line is the connection between the current point and the point to be staked.
- The small blue arrow is the point to be staked.
- The small blue arrow pointing towards the surveyor heading.
- The big blue arrow prompts the surveyor that the point to be staked is in the front/rear/left/right position.
- The blue number shows the distance from the point to be staked in different directions.

- After selecting the staking target, the icon <sup>AR</sup> is used to open AR mode. In AR mode, Nuwa will call the controller camera to mark the direction and distance to the target on the live scene; when it reaches the target point, Nuwa switches to a 3D display to show the direction and location of the target more clearly and intuitively.




Figure 4.16 Direction on the live scene





Figure 4.17 3D display of target

### 4.3 Line Stakeout

There are four circumstances of line stakeout: straight line stakeout, polyline stakeout, arc stakeout, and circle stakeout.

#### (1) Straight line stakeout

Click  to enter stakeout line library, plot the staking line on the map, and the software will mark the target point and the direction of the staking line directly according to the staking properties of the staking line (stake to pile interval or stake to vertical point).






Figure 4.18 Configure straight line stakeout



Figure 4.19 Stakeout a straight line

## (2) Polyline stakeout

Select to stake out to the pile point, to the node or to the nearest point on the polyline. Stake out to the pile point starts from the beginning of the polyline according to the pile interval, but stops at the node; stake out to the node will directly stake out the end points of each line segment of the polyline. Stake out to the points on the offset line by entering the offset value.




Figure 4.20 Configure polyline stakeout




Figure 4.21 Stakeout a polyline

### (3) Arc stakeout

Select to stake out to the pile point, to the center of a circle or to the nearest point on the arc. Stake out to the pile point is to stake out sequentially from the starting point of the polyline according to the pile interval; stake out to the circle center is to stake out directly to the center of this arc.




Figure 4.22 Configure arc stakeout



Figure 4.23 Stakeout an arc

### (4) Circle stakeout

Select to stake out to the pile point, to the center of a circle or to the nearest point on the circle. Stake out to the pile point is to stake out clockwise from the northernmost point on the circle according to the pile interval; stake out to the circle center is to stake out directly to the center of this circle.




Figure 4.24 Configure arc stakeout




Figure 4.25 Stakeout a circle

In the above screenshot of line detail,

[Line Type]: line is the only line type currently.

[Method]: two methods to add a stakeout line, details refer to section 2.5.1.

[Name]: the line name can be modified manually.

[Start Mileage]: the mileage at the starting point, used to calculate mileage at subsequent points.

[Point On Line Staking]: when this button is turned on, stake out points on the line (or offset line) according to the entered Interval and Offset; when this button is turned off, stake out directly to the line, that is, stake out to the vertical cross point of the current position and the selected line.

[Stakeout Interval (m)]: the interval distance of the points on the stakeout line, which means stake out a point every certain distance.

[Offset (m)]: the offset when staking out the points on the stakeout line. When it is negative, it is to the left of the line forward direction. When it is positive, it is to the right of the line forward direction.

➤ Select the stakeout line, click [Select].

- Stake out from the starting point (+ offset), stake out the next point every interval distance. The distance from the current position to the target position will be displayed on the screen


## 4.4 Tilt Survey and Stakeout

Tilt function is only applicable for Oscar GNSS receiver Ultimate version, Luka GNSS receiver Ultimate version and Luka GNSS receiver Advanced version.

### 4.4.1 Tilt Initialization

The tilt compensation is free of calibration. The tilt compensation will be initialized when the surveyor walks forward naturally for several meters after the receiver gets RTK fixed solution status. You can start tilt survey right after you walk to the survey point.

There are two methods to turn on or off tilt compensation. One is turning on or off tilt compensation on Device Info on the OLED via buttons. Another method is through Nuwa app. After the receiver is connect in Nuwa app, and it is configured working as a Rover.

Turn on the [Tilt Enable] on the device interface, or click  in the Survey interface to turn on the tilt compensation, and then confirm the antenna height.




Figure 4.26 Enable Tilt in device info





Figure 4.27 Setting antenna height when enabling tilt compensation

When tilt function is enabled, the tilt LED on the receiver OLED display lights on with steady red. When the solution status is single, it flashes red. When the solution status is RTK float, or the solution status is RTK fixed while tilt compensation is invalid, it changes to flashing green. When RTK solution status is fixed and the tilt compensation is available, the tilt LED turns steady green.

When the tilt compensation is valid, click  in the Survey interface to view the detailed information of tilt compensation including tilt status, tilt direction, tilt angle, heading and their quality index. Among them, the tilt direct indicates which direction is tilted, that is, the angle between the projection of the ranging pole on the ground and the north direction after tilting; the tilt angle indicates the degree of tilt, that is, the angle between the tilted

pole and the vertical direction; Heading indicates the surveyor's orientation (the facing of the back of the receiver, we consider the panel of the receiver is always facing the surveyor).



Figure 4.28 Detailed information of tilt compensation

#### 4.4.2 Tilt Survey

After turning on [Tilt Enable] and tilt initialization is finished, enter Survey interface and start tilt survey.

The tilt status is displayed at the top of the survey interface. When the tilt status is ON, it is considered that the tilt compensation accuracy is high and it is in a usable state. You can start survey using the tilted ranging pole. Please ensure that the antenna height setting is correct which will affect the tilt measurement results.




Figure 4.29 Tilt status is ON

When the status is displayed as N/A and blinking, it is considered that the accuracy of tilt compensation is reduced and it is in a state that is not recommended. At this time, the tilt indicator of the receiver OLED display turns flashing green. This may be caused by the surveyor standing for too long, rotating the ranging pole, or hitting the ranging pole to the ground. When the status is N/A, you need to redo the initialization. Generally, you do not need to stand still, just hold the ranging pole and walk forward to the next point, the initialization is complete automatically.

**Note:** during the tilt survey, please keep the receiver OLED display facing the surveyor as much as possible. Please do not rotate the pole or hit the pole to the ground, which will invalidate the initialization or affect the accuracy of the tilt compensation. In addition, during the tilt point survey, if it does not continue at the third epoch reached when it is set smoothing 5 epochs for surveying points, please check whether the tilt compensation is invalid. It is not allowed to continue to complete the survey in the case where the tilt initialization accuracy is low.



### 4.4.3 Tilt Stakeout

After turning on [Tilt Enable] and tilt initialization is finished, enter the Point Stakeout or Line Stakeout interface can start tilt stakeout. The tilt state is also added at the top of the stakeout interface to indicate the current tilt available state.

During the tilt stakeout process, if you enter the threshold range of the stakeout setting, the software will display a virtual tilt ranging pole along with the beep sounds. It is drawn according to the tilt direction angle. When the pole is tilted in a certain direction among east, west, south and north, the virtual tilt ranging pole on the interface will also tilt in a certain direction.





Figure 4.30 Point stakeout when tilt compensation is on

## 4.5 Static Survey



Static Survey

Interval 1HZ >

Duration Time(Minutes)

Cutoff Angle(°) 10

StationID 51800001

Rinex Format Rinex2.10 >

Antenna OSCAR


Type ☐ Vertical ☒ Slant ☐ Pole

Ant Height(m) 0.0

DataAutoSave ☐

Start

Figure 4.31 Static Survey interface



Static Survey

Interval 1HZ >

Duration Time(Minutes) 1440

Cutoff Angle(°) 1440

StationID 720

Rinex Format 360

Antenna 160

Type ☐ Vertical ☒ Slant ☐ Pole

Ant Height(m) 60

DataAutoSave ☐

Start

Figure 4.32 Duration options

[Interval]: selected from 20HZ, 10HZ, 5HZ, 1HZ, 5S, 10S, 15S, 30S and 60S.

[Duration Time (Minutes)]: static survey duration, the recording time can be selected in the drop down list or typed manually.

[Cutoff Angle]: the elevation mask angle, usually set to 15°.

[StationID]: the name of the surveying station.

[Rinex Format]: selected from Rinex2.10, Rinex3.02, and NONE.

[Antenna]: the antenna type.

[Type]: selected from vertical, slant or pole.

[Ant Height]: the height of the antenna.

[Record Antenna Type]: the default is off, which means the antenna type will be not recorded and the antenna height will be recorded as the height of phase center in Rinex header; when on, the antenna type will be recorded and the antenna height will be recorded as the height of the bottom of receiver in Rinex header.

[DataAutoSave]: if this function is turned on, when the static recording time reaches the set duration, the receiver closes the current file record, reopens a file to continue recording, and this cycles; the receiver will also reopen a file to continue recording static when restart. If this function is turned off, the receiver will stop static recording when the recording time reaches the set duration.




Figure 4.33 Static data recording

After all the parameters are confirmed, click [Start] to start data collection. The static data is recording as shown in the above figure.

**Note: Static Survey and Device Debug cannot be used at the same time. Please turn off Device Debug as shown in Figure 3.53 manually before recording static data.**

## Static data download and post-processing

### 4.5.1 Static data download for David

#### Device preparation

- A David GNSS receiver
- A DC-2pin to USB power cable
- A COMM2-7pin to USB & DB9 cable
- A power bank
- A computer running TersusDownload tool



Figure 4.34 Preparation for Static Data Process

After the static survey in fields is completed, connect the David receiver to the computer according to the following figure and power on the David receiver. The USB port is mapped to a serial port (COM5 in the following example) in the computer, which can be checked in the Device Manager.



Figure 4.35 Connections of David, computer and power bank

It is recommended to type UNLOGALL in the command window of Tersus GNSS Center software before executing below steps. Open the TersusDownload on the computer, select the serial port to communicate with the David receiver.




Figure 4.36 TersusDownload interface

Select the download speed. Select 'use current baudrate' when using USB port to download files as shown below. Select baud rate 460800bps if a serial port is used to download files.




Figure 4.37 Download speed options

After completing the above steps, click [Start] and it pops out below window. Select the DownloadPath, select the files to be downloaded, click [Download] to start downloading:




Figure 4.38 File selected for download

In this interface, click the number in red box 1 to edit Station ID if necessary, or it can be edited in Figure 4.31 in section 4.4 Static Survey. Check the box in the left of red box 2 to enable or disable auto create RINEX file after download.

!	The downloading rate is about 2MB/min, the downloading time can be estimated based on it.
!	It is recommended to ensure the computer has available CPU and memory when downloading files.

Open the RINEX file using notepad or other text viewing software, the antenna height is vertical height which is from the phase center of the antenna to the point on the ground. The value of the antenna height can be found as shown below.

3.02 OBSERVATION DATA M (MIXED)										RINEX VERSION / TYPE									
Tersus										PGM / RUN BY / DATE									
Test										MARKER NAME									
Tersus										MARKER NUMBER									
Tersus										OBSERVER / AGENCY									
Tersus										REC # / TYPE / VERS									
Tersus										ANT # / TYPE									
Tersus										APPROX POSITION XYZ									
Tersus										ANTENNA: DELTA H/E/N									
Tersus										INTERVAL									
Tersus										SYS / # / OBS TYPES									
Tersus										SYS / # / OBS TYPES									
Tersus										SYS / # / OBS TYPES									
Tersus										TIME OF FIRST OBS									
Tersus										TIME OF LAST OBS									
Tersus										END OF HEADER									
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus																			
Tersus										</									



After completing the connection, the computer prompts a USB device, open it to view the files as below. Copy the folders and paste them to the computer.




Figure 4.41 Static data recorded by Receiver

**Note:** When configuring static survey, if configure using buttons only, or configure using Nuwa with selecting None for Rinex format, the receiver only records trs format files. It is necessary to convert trs files to Rinex files before data post-processing.

Open Tersus Rinex Converter software, choose source file path, save path, source format, Rinex version, and click [Process] to complete the format conversion.




Figure 4.42 Tersus Rinex Converter interface

The Rinex files can be found in the save path as below.



C:\Users\Miki\Desktop\20191105\

Name	Date modified	Type	Size
rinex2	11/5/2019 3:40 PM	File folder	
rinex3	11/5/2019 3:40 PM	File folder	
trs	11/5/2019 3:40 PM	File folder	
51800001309G53.19c	11/5/2019 3:48 PM	19C File	8 KB
51800001309G53.19g	11/5/2019 3:48 PM	19G File	4 KB
51800001309G53.19l	11/5/2019 3:48 PM	19L File	6 KB
51800001309G53.19n	11/5/2019 3:48 PM	19N File	8 KB
51800001309G53.19o	11/5/2019 3:48 PM	19O File	153 KB
51800001309G53.19p	11/5/2019 3:48 PM	19P File	24 KB

Figure 4.43 The Rinex files after conversion

### 4.5.3 Data post-processing

Open TERSUS Geo Office software:




Figure 4.44 TERSUS Geomatics Office interface

After a project is created, click [Import] -> [Import Files]





Figure 4.45 Import Files in TERSUS Geo Office

Click [Select Files] to load the Rinex files created in section 7.2.2.

After the above step of importing, the default configuration of the observation data is correct. There is no need to modify the configurations of antenna height, antenna type, and etc. The default configuration of the imported files is shown as follows.



The screenshot shows a software window titled 'Test\_Test.zsd' with three tabs: 'Basic', 'Antenna', and 'Receiver'. The 'Antenna' tab is active. It contains two main sections: 'Antenna phase center' and 'Ant Height'.

**Antenna phase center section:**

- 'Ant Type:' is set to 'TRSAX3702' with a dropdown arrow.
- 'Apply to(A)' button is highlighted.
- 'This' dropdown menu is set to 'This'.
- 'Is find antenna correction:' is set to 'No'.

**Ant Height section:**

- 'Measure to:' is set to 'Antenna Bottom' with a dropdown arrow.
- 'Apply to(M)' button is highlighted.
- 'This' dropdown menu is set to 'This'.
- 'Antenna Height(m):' is set to '1.0375'.
- 'Apply to(H)' button is highlighted.
- 'This' dropdown menu is set to 'This'.
- 'True Height(m):' is set to '1.0375'.


Figure 4.46 Default configuration of the observation data

Refer to the user manual of Tersus Geo Office for more details on data post processing.

## 4.6 Site Calibration

Site Calibration is to find the mathematical conversion relationship (transition parameter) between WGS84 and the local plane Cartesian coordinate system. Site calibration includes the calculation of four-parameter plane transformation and the calculation of height fitting parameters.

After adding point pairs or importing point pairs, select the calculation method. If it is a point pair used for horizontal and vertical calculations, check both H and V. If it is a point pair only for horizontal, just check H; and if it is a point pair only for vertical, just check V.



← Site Calibration

**Height Fitting** Fixed difference correction >

\*Need at least 1 paired pt for local param calculation\*  
\*Need at least 1 paired pt for Fixed Difference\*

2 features Multiselect

Method	Source Coord	Target Coord
<input checked="" type="checkbox"/> H <input checked="" type="checkbox"/> V	B:31.1988913900 L:120.7163481500 H:3.1940(m)	N:3453071.6760(m) E:496716.0530(m) H:1.9740(m)
<input checked="" type="checkbox"/> H <input type="checkbox"/> V	B:31.2023208400 L:120.7291900000 H:4.0250(m)	N:3453451.6210(m) E:497939.9990(m) H:2.0540(m)

Add Edit Calculate

Figure 4.47 Calculation Type options

There are three methods for height-fitting: fixed difference correction, plane fitting and surface fitting, which require 1, 3 and 6 point pairs for vertical calculations.




Figure 4.48 Height Fitting options

This section introduces an example of a calculation with one point pair for horizontal and vertical calculations and another point pair only for horizontal calculation.







Figure 4.49 Application example for site calibration

Click [Add] to add point for source coordinate and target coordinate.

Figure 4.50 Add point for site calibration

The source coordinate can be typed manually or obtained by clicking  the location icon or imported from the survey point library by clicking  the list icon.

The target coordinate can be typed manually or imported from the control point library by clicking  the list icon.

In this example, two pairs of points are type manually for calculation, which are shown below.

Figure 4.51 The 1<sup>st</sup> pair of points for calculation





Figure 4.52 The 2<sup>nd</sup> pair of points for calculation

Click [OK] and two pairs of points are shown below. The first point pair is for horizontal and vertical, and the second is for horizontal.



**Height Fitting** Fixed difference correction >

*\*Need at least 1 paired pt for local param calculation\**  
*\*Need at least 1 paired pt for Fixed Difference\**

2 features Multiselect

Method	Source Coord	Target Coord
<input checked="" type="checkbox"/> H	B:31.1988913900	N:3453071.6760(m)
<input checked="" type="checkbox"/> V	L:120.7163481500	E:496716.0530(m)
	H:3.1940(m)	H:1.9740(m)
<input checked="" type="checkbox"/> H	B:31.2023208400	N:3453451.6210(m)
<input type="checkbox"/> V	L:120.7291900000	E:497939.9990(m)
	H:4.0250(m)	H:2.0540(m)

**Add Edit Calculate**

Figure 4.53 Two pairs of points for calculation

Click [Calculate] and the data is calculated with the result shown below.

← Result:

**Local Para Result:**  
Dx(m): 162.8482    Dy(m): 531607.1696  
Rotation Angle(s): 469.41227277  
Scale: 0.99997653698

**Height Fitting Result:**  
A0: -1.2200000001341105    A1: 0.0  
A2: 0.0    A3: 0.0  
A4: 0.0    A5: 0.0

Max.HRMS    0.0000

Cancel    Detail    Apply

Figure 4.54 Calculation Result

Click [Apply] to apply the site calibration result to the current project coordinate system, and it prompts that ‘Apply result successfully!’.

← Site Calibration

**Height Fitting**    Fixed difference correction >

\*Need at least 1 paired pt for local param calculation\*

\*Need at least 1 paired pt for Fixed Difference\*


2 features    Multiselect

Method	Source Coord	Target Coord
<input checked="" type="checkbox"/> H	B:31.1988913900	N:3453071.6760(m)
<input checked="" type="checkbox"/> V	L:120.7163481500	E:496716.0530(m)
	H:3.1940(m)	H:1.9740(m)
<input checked="" type="checkbox"/> H	B:31.2023208400	N:3453451.6210(m)
<input type="checkbox"/> V	L:120.7291900000	E:497939.9990(m)
	H:4.0250(m)	H:2.0540(m)

Add    Apply result successfully!    Calculate

Figure 4.55 Site calibration results applied to current project

Slide left of the title bar to view the values of Residual results as shown below. Since there are not enough point pairs to provide redundant observations in this example, the residual value is 0.



**Site Calibration**

**Height Fitting** Fixed difference correction >

*\*Need at least 1 paired pt for local param calculation\**  
*\*Need at least 1 paired pt for Fixed Difference\**


2 features Multiselect

Method	Target Coord	Residual
<input checked="" type="checkbox"/> H <input checked="" type="checkbox"/> V	N:3453071.6760(m) E:496716.0530(m) H:1.9740(m)	H:0.0000 V:0.0000
<input checked="" type="checkbox"/> H <input type="checkbox"/> V	N:3453451.6210(m) E:497939.9990(m) H:2.0540(m)	H:0.0000 V:0.0000

**Add Edit Calculate**

Figure 4.56 Slide left to view residual results

The results applied to the current project coordinate system can be checked in Project Property interface below.



**Project Property**

**Coord System** Project Info

Use datum trans: No

Dx(m): 0.0000	Rx(s): 0.000000
Dy(m): 0.0000	Ry(s): 0.000000
Dz(m): 0.0000	Rz(s): 0.000000
Scale(ppm): 0.000000000	

Use four parameters: Yes

Dx(m): 162.8482  
Dy(m): 531607.1696  
Rotation Angle(s): 469.41227277  
Scale: 0.99997654

Use PlaneGridNorth: No  
PlaneGridNorth Name: N/A  
Use PlaneGridEast: No  
PlaneGridEast Name: N/A

Use height fitting: Yes

A0: -1.2200000001341105	A1: 0.0
A2: 0.0	A3: 0.0
A4: 0.0	A5: 0.0

Use Geoid: No  
Geoid Name: N/A

**Edit**


Figure 4.57 Updated project property after site calibration

## 4.7 Survey Config

During data collection, restrictions are given to solution type and HRMS limits, hence only the data meeting the restrictions can be saved. More details are as follows:


### 4.7.1 Common Config





Survey Config	
Common Config	Display Config
Solution Limit	Fixed >
HRMS Limit	0.03
VRMS Limit	0.05
Diff Age Limit	5
Base Move	0.05
Survey Mode	Detail >
PPK Survey	<input type="checkbox"/>
Auto Survey	<input type="checkbox"/>
Report File	<input type="checkbox"/>
Survey Epochs	5
Survey prompt tone	<input checked="" type="checkbox"/>
Survey with confirmation	<input checked="" type="checkbox"/>
Auto Center	<input checked="" type="checkbox"/>
Stakeout prompt tone	<input checked="" type="checkbox"/>
Auto zoom	<input checked="" type="checkbox"/>
Stakeout tolerance	0.01
Stakeout prompt type	North and south direct.. >
Antenna	OSCAR
Type	<input type="radio"/> Vertical <input type="radio"/> Slant <input checked="" type="radio"/> Pole
Ant Height(m)	1.800

Figure 4.58 Survey Config - Detail



Survey Config	
Common Config	Display Config
Solution Limit	Fixed >
HRMS Limit	0.03
VRMS Limit	0.05
Diff Age Limit	5
Base Move	0.05
Survey Mode	Continuous >
Auto Collect	<input checked="" type="radio"/> Time <input type="radio"/> Distance
Time Interval(s)	1   ✕
Survey prompt tone	<input checked="" type="checkbox"/>
Survey with confirmation	<input checked="" type="checkbox"/>
Auto Center	<input checked="" type="checkbox"/>
Stakeout prompt tone	<input checked="" type="checkbox"/>
Auto zoom	<input checked="" type="checkbox"/>
Stakeout tolerance	0.01
Stakeout prompt type	North and south direct.. >
Antenna	OSCAR
Type	<input type="radio"/> Vertical <input type="radio"/> Slant <input checked="" type="radio"/> Pole
Ant Height(m)	1.800

Figure 4.59 Survey Config – Continuous

[Solution Limited]: includes Single, DGPS, SBAS, Float and Fixed. The solution accuracy (from high to low) is: Fixed > Float > SBAS > DGPS > Single. Select different solution limits, the default HRMS, VRMS limit will change accordingly.

[HRMS Limited]: horizontal RMS limit. Data would not be collected if its HRMS is greater than this limit.

[VRMS Limited]: vertical RMS limit. Data would not be collected if its VRMS is greater than this limit.

[Diff Age Limited]: when the solution status is not single, no data will be collected if the current differential delay exceeds this threshold.

[Base Move]: If the base moves over this limit, there will be a new base point and the rover coordinates will be recalculated according to the new base.

[Survey Mode]: can be selected from detail, continuous and control.

## 1. Detail Point

[PPK Survey]: as known as Stop and Go survey mode, the high-precision position of the rover is obtained by post-processing. The steps are as follows.

- a. Start recording Rinex files for base, as the static data of the base for post-processing.
- b. Start recording Rinex files for Rover, as the kinematic data of the rover for post-processing. Otherwise, in the subsequent steps, Nuwa will prompt to start the Rinex file recording and jump to the relevant page.
- c. Enter the survey configuration interface, open the PPK survey, and set the survey epochs appropriately.
- d. Enter the survey interface, start to move the antenna. When reaching the point of interest, stop the antenna, then click the survey button. Enter the name of the point of interest and confirm the antenna value, and click OK to wait for the survey to be completed. Then continue to move the antenna to the next point of interest.
- e. When all Stop and Go measurements are completed, stop the Rinex file recording. Copy the two Rinex files to the Windows desktop and import them to the TGO post-processing software.
- f. The TGO software will automatically distinguish the static file of the base and the kinematic file of the rover, as well as the points of interest, and form a baseline. Click to process the baseline to calculate the points of interest and generate the PPK processing report.

[Auto Survey]: the auto survey can be turned on when PPK survey is on. The survey will be started automatically when reaching the point of interest and centering the bubble.

[Report File]: the report file function can be turned on, the coordinate of the survey epoch will be saved as a .txt file under project folder.

[Survey Epochs]: the survey epoch can be modified. The survey epoch can be positive integer such as 2, 3, 5 or 10. Normally set to 5s.

## 2. Continuous Point

[Auto Collect]: the data can be collected according to Time or Distance.

If Time is selected, ensure to input the time interval.

If Distance is selected, ensure to input the distance interval.

### 3. Control Point

There are three modes in control point survey, the horizontal and vertical control point, the horizontal control point and the vertical control point.

[Reset Count]: can be modified, and can be any positive integer. The default setting is 2, which means once RTK reset will be performed after starting to collect control points. If the setting is 3, twice RTK reset will be performed after starting.

[Repeat Count]: can be modified, and can be any positive integer. The default setting is 2, which means 2 measurements will be performed after each RTK reset and re-fixed.

[Survey Epochs]: can be modified, and can be any positive integer. The default value is 10, which means that 10 epochs will be observed for each measurement.

[H Diff Limit]: can be modified, as the maximum difference in plane coordinates of the measurements. During the procedure, if the difference exceeds, the procedure will be aborted.

[V Diff Limit]: can be modified, as the maximum difference in elevation coordinates of the measurements. During the procedure, if the difference exceeds, the procedure will be aborted.

[H Diff Check]: can be modified, as the maximum horizontal difference between check point and the selected control point. During the check point survey procedure, if the difference exceeds, the procedure will be aborted.

[V Diff Check]: can be modified, as the maximum vertical difference between check point and the selected control point. During the check point survey procedure, if the difference exceeds, the procedure will be aborted.

[Report File]: the report file function can be turned on, the difference between each epoch and final average result will be saved as a HTML report under project folder.

[Record Base Point]: the record base point function can be turned on, which will save the new base point to the point database before the control point measurement starts and after RTK reset.

[Name Increment]: can be modified, the point name will be automatically increased according to the set name increment.

[Survey Prompt Tone]: can be enable or disabled.

[Survey with confirmation]: When it is turned on, the confirmation dialog box will pop up when a detail point is collected, check or modify the point name, code and antenna information; if it is turned off, the collected point is saved directly to the point library.

[Auto Center]: When it is turned on, the survey graphic interface will be centered to the current position every 5 seconds.

[Stakeout Prompt Tone]: can be enable or disabled.

[Auto Zoom]: When it is turned on, the stakeout graphic interface will be zoomed to the target point and the current position every 3 seconds.

[Stakeout tolerance]: the distance threshold of the stakeout tone. For example, set 0.05 means the stakeout tone beeps every 1 seconds if distance is less than 0.05m.

[Stakeout Prompt Type]: can be North and South direction or Forward and Backward.

[Cad Unit]: can be modified to m or mm, for drawings in the CAD Stakeout module.

[Antenna]: Antenna name.

[Type]: height type, can be vertical, slant or pole.

[Ant Height (m)]: value of the antenna height according the specified measuring type.

#### 4.7.2 Display Config




Figure 4.60 Survey Config – Display Config

Select the Display Point Type, Display Point Name, Display Point Code, Display all staking point, Display Electronic Bubble or Rotate map when staking according to the application requirement.

Select Survey Style: Simple or Detailed.



Figure 4.61 Survey Point Color

Click [Survey Point Colour] to select a colour on the outer ring for the survey points and click the inner pie to confirm the colour.




Figure 4.62 Advanced Config for Display Config

Click [Advance] to filter the displayed points.

## 4.8 Base Shift

In 'Auto Start' mode for base station, if the base is moved, re-erected or restarted at an unknown point, base shift should be performed to ensure the points collected by the current base station is consistent with that before the base is moved or powered off. Briefly, find a known point, measure the coordinates of this point, then use this point to calculate the offset of the base shift, apply the base shift to all the survey points under the current base coordinates to make the reference coordinate system of the base remains the same as the previous base station.

The detailed steps are as follows:

Click [Base Shift] to enter the following interface, Figure 4.61 shows the calculation result for the base shift; Figure 4.62 shows the source of the base shift calculation. Click the list icon on the right of GNSS Point to select a survey point which is measured at the known point and click the list icon on the right of Known Point to select a known point in the control point library (details of control point refers to section 2.4 Point). Click [Calculate] and the base shift is calculated automatically. Click [Apply] to apply the base shift to all the points surveyed and to be surveyed under the current base station.




Figure 4.63 Base Shift interface – 1




Figure 4.64 Base Shift interface – 2

At this time, select the base point in the survey point library to view the details. It can be found that the current NEh shift amount is recorded in the base point information, and the NEh coordinates of all the survey points under this base station change accordingly.

If you need to reset (cancel) the base shift, just enter [base shift], and manually modify the three parameters of north shift, east shift and height shift to 0. At this time, return to the survey point library to view the details of the base point. The NEh shift amount in the base

point information is automatically changed to 0, and all survey points NEh coordinates under the base station are restored to the coordinates before the base shift.

## 4.9 Road Stakeout

According to the digital designed road created in the road management module, after the software is connected to the high-precision positioning GNSS receiver, enter the road stakeout interface to stake out the designed road stake points and other feature points.


Click [Survey] -> [Road Stakeout], click the  icon to select a road file, the road is drew on the map after the road file is loaded, and then you can start the stakeout. It may take some time for the software to load the newly-built road or modified road for the first time. Once the loading is completed, this road is selected again for stakeout without waiting.



Figure 4.65 Road stakeout interface




Figure 4.66 Road data is loading

### Alignment Stakeout

After the loading is completed, select the type as Interval.



It is divided into the options of by interval and by nearby. By interval means starting from the starting mileage point, stake out step by interval according to the set interval. The mileage value of the nearest point on the road to the current position will be obtained after clicking the position icon, so that it is convenient to start the road stakeout from that point immediately. Stakeout by nearby will calculate the nearest point on the road to the current position as the target point at any time, and with the current position moving, the mileage and offset of the corresponding point on the road will change.

Staking to the middle pile, left pile and right pile are allowed in alignment stakeout. The coordinates of the middle pile are calculated according to the alignment and vertical profile, when cross section, super elevation and widening are added to the calculation of the coordinates of the left or right pile.

Then follow the software instructions to move the high-precision GNSS receiver to the design point to complete the stakeout.




Figure 4.67 Road stakeout setting

### Cross-section Point Survey

After the loading is completed, select the type as Cross.

The cross-section point survey will start from the cross-section at the starting mileage. When the current mileage cross section point survey is completed, click on the previous or next to jump to another mileage according to the set interval. The mileage value of the nearest point on the road to the current position will be obtained after clicking the position icon, so that it is convenient to start cross-section point survey from the mileage at that point immediately.

In the process of cross-section point survey, the software draws the cross-section at the current mileage and, as the current position moves, the software shows the H-offset, V-offset and Cut or Fill values according to the cross-section.





Figure 4.68 Road stakeout setting

## 4.10 Surface Stakeout

According to the imported 3dface in DXF files, surface data in LandXML files or created TIN by the custom points selection, when the current position enters within the triangle surface area, the software interpolates the design height of the current position based on

the triangle surface data, and indicates the fill or cut value.

The main steps of surface stakeout are as follows:

- Enter the surface list: click  to enter the surface list after connecting to GNSS receiver.




Figure 4.69 Surface List

- Add stakeout surface: click the icon to select DXF files to import 3dface data or LandXML files to import surface data, or click [New] to select points from the point library to create TIN data.




Figure 4.70 Import surface data


- Edit stakeout surface: select the imported TIN data to edit the offset value, or select the created TIN data to edit the offset value and the points that make up the TIN data.

- Select the surface to be stakeout: select the surface in the list, and click [Select] to start surface stakeout.



Figure 4.71 Surface stakeout

When the position is within the surface area, the software automatically interpolates the design height value based on the 3dsurface data, and calculates the cut / fill value by subtracting the current height from the design height. When the design height is smaller than the current height, the height deviation is negative and it needs to be cut, the indication is red. When the design height is larger than the current height, the height deviation is positive and it needs to be filled, the indication is blue.

If you need to change the stakeout surface, click the  button and select another surface in the list.




## 4.11 CAD Stakeout

CAD stakeout module is used to import CAD files in DXF or DWG format and directly select points and lines on CAD drawings for stakeout.

Click [Survey] -> [CAD Stakeout], select a CAD file in DXF format or DWG format, as shown in the figure below. If there is a recently opened CAD file, it will be displayed in Recent files and can be opened directly by clicking on it.



Figure 4.72 Select CAD file

After opening the CAD file, it jumps to the main CAD stakeout interface, the CAD drawing is loaded and displayed, as shown below. Use the point selection tool  to select the point on the drawing to stake the point. Click point or line on the drawing directly and then click  or  to stake the point or the line.




















Figure 4.73 CAD stakeout

Icon	Description
	Zoom by current position.
	Zoom all.
	Point selection, click on it and the point selection tool will appear on the main screen, press the tool and move to capture the POI, then the point stakeout starts.
	Stake point collect, stake the POI and the stakeout ends.
	List button, to display all nodes on the selected line as a list.
	Layer management, control the display, locking and freezing of different layers.
	Tool set.
	Distance measurement, select two points on the drawing and calculate

	the distance.
	Area measurement, select points on the drawing and calculate the area and perimeter.
	Find, enter text to search and locate the text.
	Switch the background color, which is currently allowed to be black or white.
	Explode, select a block or polyline and explode it.
	Default state, waiting for the point or line to be selected.
	Point stakeout, click the button to start staking the selected point.
	Line stakeout, click the button to start staking the selected line.
	Stakeout stop, click it to return to the default state.

In the CAD Stakeout interface,

- The red flag indicates the location of the stakeout point.
- The red dotted line is the connection between the current point and the point to be staked.
- The small blue arrow is the point to be staked.
- The small blue arrow pointing towards the surveyor heading.
- The big blue arrow prompts the surveyor that the point to be staked is in the front/rear/left/right position.
- The blue number shows the distance from the point to be staked in different directions.

## 5. Tools

- Area Perimeter
- Azimuth Distance
- Offset Point
- Rotation Point
- Two Points Intersection
- Four Points Intersection
- Intersection Angle
- Earthwork
- Angular Bisector
- Grid to Ground
- Line Segmentation
- Points Avg
- Parameters






Figure 5.1 Functions under Tools

## 5.1 Area Perimeter

This tool is used to calculate area and perimeter. The points can be imported from the point library by clicking the list icon on the upper right corner. The unit is meter for perimeter and square meter for area.




Figure 5.2 Area Perimeter interface

[Graphic]: shows the closed polygon formed by the points.

[Calculate]: calculates the area and perimeter of the closed polygon.

[Multiselect]: enters point edit interface to inverse or delete.

**Note:** The calculation results are all plane results (point elevation does not participate in the calculation). It is suitable for all sections in this chapter except section 5.3 Offset Point.

## 5.2 Azimuth Distance

There are two kinds of azimuth distance calculation: point to point, and point to line. The points can be imported from the point library.

### 5.2.1 Point to Point Distance




Figure 5.3 Azimuth Distance – Point to Point

Import point A and point B from the point library.

[Calculate]: calculate the distance between the two points and the azimuth.

[Clear]: clear the result.

### 5.2.2 Point to Line Distance




Figure 5.4 Azimuth Distance – Point to Line

Import points from the library to calculate the distance from point A to line BC.


[Calculate]: calculate the distance.

[Clear]: clear the result.

## 5.3 Offset Point

### 5.3.1 Offset point

Given the azimuth of point A & P, AP's horizontal length L and height H, calculate the coordinate of P. The steps are as follows:



**Offset Point**

Offset Point From Line

Know: The azimuth angle of point A is known, the horizontal distance L and the Height difference H (N is north direction)

Calculate: Point P

Point A


L(m) Input

H(m) Input

Azimuth(°) Input

Clear Calculate

Figure 5.5 Offset Point interface



**Result**

Point Name PT5

Code >

X 24.9657

Y 1.3084

Z 55.00

Cancel Save

Figure 5.6 Offset Point calculation result

[Calculate]: calculate the coordinate of point P.

[Clear]: clear the current result.

### 5.3.2 Offset point from line

Given the coordinates of point A and B, the distance L from B to C or from A to C, the offset D from AB line and the height difference H, calculate the coordinate of point P.

Figure 5.7 Offset point from line


Figure 5.8 Offset point from line calculation result

[Calculate]: calculate the coordinate of point P.

[Clear]: clear the current result.


## 5.4 Rotation Point

Given the coordinates of point A, B and the rotation angle (clockwise), calculate the coordinate of point B after rotation.



The screenshot shows the 'Rotation point' interface. At the top, there is a back arrow and the title 'Rotation point'. Below this is a diagram showing a point A, a point B, and a point P. A line segment connects A and B. A line segment connects A and P. An arc indicates the angle between the line segments AB and AP. The text 'Know: Two-point coordinates of A B and the angle of clockwise rotation around A point' is displayed. Below the diagram, the text 'Calculate: Coordinates of point B after rotation' is shown. The interface includes input fields for 'Point A' (with value 'TRSA'), 'Point B' (with value 'TRE2'), and 'Rotation angle(°)' (with value '36'). At the bottom, there are 'Clear' and 'Calculate' buttons.

Figure 5.9 Rotation Point interface



The screenshot shows the 'Result' interface. At the top, there is a back arrow and the title 'Result'. Below this is a table with the following data:

Point Name	PT1
Code	>
X	1071400.4418
Y	-1786459.5177
Z	0.00

At the bottom, there are 'Cancel' and 'Save' buttons.

Figure 5.10 Rotation Point Calculation result

[Calculate]: calculate the coordinate of point B after rotation.

[Clear]: clear the result.

## 5.5 Two Points Intersection

There are two types of models listed below:

- Model 1: Given the coordinates of point A and B, the angle  $\alpha$  between line AB and AP, the angle  $\beta$  between line AB and PB, calculate the coordinate of point P.
- Model 2: Given the coordinates of point A and B, the length of line AP and BP, calculate the coordinate of point P.

Two Point Intersection

Know: The coordinate of A, B, the angle between A and B, the distance between A and P and the distance between B and P. Calculate: Point P

Point A

Type: Angle >

$\alpha(D)$ : Input

Point B

Type: Angle >

$\beta(D)$ : Input

Clear Calculate

Figure 5.11 Two Point Intersection – Angle

Two Point Intersection

Know: The coordinate of A, B, the angle between A and B, the distance between A and P and the distance between B and P. Calculate: Point P

Point A

Type: Distance >

Dis: Input

Point B

Type: Distance >

Dis: Input

Clear Calculate

Figure 5.12 Two Point Intersection – Distance

[Calculate]: calculate the coordinate of the intersection P.

[Clear]: clear the result.

## 5.6 Four Points Intersection

Given the coordinates of point A, B, C and D, calculate the coordinate of the intersection point P between line AB and line CD.



← Four Point Intersection

Know:Point A,B,C,D  
Calculate:Intersection coordinates between AB and CD

Point A Pt1


Point B PT2

Point C Hai

Point D Mi

Clear Calculate

Figure 5.13 Four Point Intersection interface



← Result

Point Name PT1

Code >

X 129.9216

Y 448.1081

Z 0.00

Cancel Save

Figure 5.14 Four Point Intersection result

[Calculate]: calculate the coordinate of the intersection P.

[Clear]: clear the result.



## 5.7 Intersection Angle

Given the coordinates of point A, B and C, calculate the angle  $\angle ABC$



← Intersection Angle

Know: Point A,B,C  
Calculate: Angle

Point A PT1

Point B PT2

Point C Mi

Calculate Result

Angle 41.4°

Clear Calculate

Figure 5.15 Intersection Angle calculation

[Calculate]: calculate the angle  $\angle ABC$ .

[Clear]: clear the result.

## 5.8 Earthwork

The detailed earthwork process is as below.

- (1) Select all surface points to be calculated for earthwork from the point library, and add them to the list of All Points.




Figure 5.16 Select all surface points to be calculated

- (2) Select the boundary points from the list of All Points, and set them as BP to add them to the list of Boundary Points. Sort the boundary points in order by moving up and down.




Figure 5.17 Select the boundary points

- (3) Click [Process], the software will first ask the path to save the surface file to be generated.




Figure 5.18 File name and storage path for the earthwork


- (4) The software will generate a triangulation network from the selected surface points through specific rules.
- (5) Input the reference height, the software will calculate the volume formed between each triangulation network and the reference height, and calculate the fill and excavation amount in total.



Figure 5.19 Earthwork calculation result

## 5.9 Angular Bisector

Given the coordinates of point A, B and C, and the length of BP in which P is a point on the angular bisector of the angle  $\angle ABC$ , calculate the coordinate of point P.



The screenshot shows a mobile app interface titled "Rotation point". At the top, there is a diagram of a triangle ABC with a point P on the bisector of angle ABC. Below the diagram, the text reads: "Know: Point A, B, C and BP, P is a point on the angular bisector of angle ABC. Calculate: Point P". The interface includes input fields for "Point A", "Point B", and "Point C", each with a menu icon to its right. Below these is a field for "BP(M)" with an "Input" label. At the bottom, there are two buttons: "Clear" and "Calculate".

Figure 5.20 Intersection Angle calculation

[Calculate]: calculate the coordinate of point P.

[Clear]: clear the result.

## 5.10 Grid to Ground

Since the GNSS measurement gets the plane grid coordinates by projection, there are deformation caused by the projection and the deformation caused by the curvature of the earth. If the length between points A and B measured by GNSS receiver will be different from the length between points A and B measured by optical instruments such as total station, so when the measurement area is large, it is necessary to consider this tool to realize the correction of grid coordinates to ground coordinates.

By selecting a point as the datum and clicking Calculate, the software will calculate the correction factor based on the location of the datum, and then click Apply to apply the correction factor to the project. If you find that the software calculates the scale factor incorrectly, or if you learn the correct scale factor in some other form, you can modify it

manually.




Figure 5.21 Grid to Ground interface




Figure 5.22 Calculate the correction factors

After clicking Apply, return to the point library to see, the point details of the measured points in the point library add the display of ground N, E and h coordinates, and the distance between these points and the datum under the ground coordinates are worth to reformat.

← Detail	
Name	Sh~.B.4
Code	B
N(feet)	11326083.4886
E(feet)	185454.8659
h(feet)	54.4495
Combined Factor	1.00001971
Ground N	11326083.4886
Ground E	185454.8659
Ground h	54.4495
Lat	31.189458683N
Lon	122.593036298E
Height(feet)	411.1535
ECEF-X(feet)	-9651583.7983
ECEF-Y(feet)	15095802.9184
ECEF-Z(feet)	10774100.1364
Lat(LOCAL)	31.189437106N
Lon(LOCAL)	122.593036298E
H(LOCAL)(feet)	54.4494
Base	
Base Lat84	0.000000000N
Base Lon84	0.000000000E
Base Alt84(feet)	0.0000
Base Ant.Height	0.0000
Solution States	None >
Collection End	2020-12-15 15:08:28
Coord Type	NEH >
DOP(P/H/V)	0.0/0.0/0.0
RMS(HRMS/VRMS)	0.0000/0.0000
Std(Lat/Lon)	0.0000/0.0000
Ant Height(feet)	0.0000
Photo	
OK	

Figure 5.23 Point detail after applying the calculation

## 5.11 Line Segmentation

Given AB line, calculate the equivalent points or equidistant points on line AB.




Figure 5.24 Line Segmentation

[Segment method]: By number of segments or by interval length

[Code]: Calculation points code

[First Point Name]: Calculation points name and naming rule

[Calculate]: Calculate points

[Save]: Save the calculation points to the point library

## 5.12 Points Avg

This tool is used to calculate the average points. Points can be imported from the point library by clicking the list icon on the upper right corner or by clicking the Add button. Click the Calculate button to calculate the average result for all selected points and display the difference between the selected points and the average result.

Points Avg					
Coord List					Multiselect
id	Name	Code	$\Delta H$	$\Delta V$	
S1	1		0.707	0.500	0.1
S2	2		0.707	0.500	1.1

Add	Calculate
-----	-----------

Figure 5.25 Points Avg

### 5.13 Parameters

Seven Parameter and Three Parameter methods are introduced in this section.

**Seven Parameter:** this method can cover long distance range, generally more than 50 km. At least three known points are required in local datum and in WGS84 system before calculating.

**Three Parameter:** at least one known point is required. This method can cover short distance range; the accuracy is determined by working area and decreased with the distance.

The following is an example of Seven Parameter. Click [Project] -> [Parameters] to enter the following interface.






Figure 5.26 Parameters Calculation

Select seven parameter for Calculate Type, click [Add] on the bottom left to input the known points.





Figure 5.27 Add Point for calculation

For the Source Coordinate, input Latitude, Longitude and Height by manual input, collected from a Tersus receiver or selected from the survey point list. For the Target Coordinate, input the local values from manual input or selected from the control point list.

- Manual input

Input the point position according to the format required. The latitude/longitude format can be changed by clicking the icon on the right.

- Point library

Click [  ] to load points from point library. Points can be added by clicking [Add] in the Point interface.

- Smooth Acquisition

Click [  ] to start smooth acquisition through Tersus receiver.

After points are added, click [Calculate] on the bottom right to do the parameter transformation. The result is shown as below screenshot:

← Result:		
Dx(m)	-30.007731	
Dy(m)	-43.482974	
Dz(m)	-70.657506	
Rx(s)	-1.266068	
Ry(s)	-2.440565	
Rz(s)	1.498273	
Scale(ppm)	3.6787135455	
Max.HRMS	1.5829	NO.: 3
<div> <div>Cancel</div> <div>Apply</div> </div>		

Figure 5.28 Parameters Calculation Result interface

**Note: Before this calculation, please make sure that the project parameters (ellipsoid, projection, etc.) are used correctly.**

After the calculation is completed, click [Apply] to apply to the datum transformation parameters of the current project coordinate. When Max.HRMS is too large, the software will prompt a notice of whether continue to apply if the value is too large; if you click [Cancel], it will not be applied to the datum transformation parameters.

## 6. TC20 Controller and application

### 6.1 Overview of TC20 Controller

The Tersus TC20 Controller is a rugged smart phone with design of 4.3" touch screen and an alphanumerical keypad. Equipped with powerful processor, it is perfect to adapt with Tersus Survey software. With professional IP67 rating, it is robust and reliable for harsh operating conditions.

#### Features:

- Rugged smart phone 4.3" display
- 4G GSM unlocked Android 6.0
- Quad-Core 1.3GHz CPU
- 2GB RAM + 16GB ROM
- 8 MP Auto Focus camera
- IP67 certified grade, water/shock/dust proof
- 6500 mAh battery
- A-GPS supported
- Wi-Fi, Bluetooth, NFC
- Two color options: red and yellow

***Note: Although the TC20 controller uses chemical and impact resistant materials, precision instruments require careful use and maintenance and should be kept as dry as possible. In order to improve the stability and life cycle of the TC20 controller, avoid exposing the TC20 controller to extreme environments such as moisture, high temperatures, low temperatures, corrosive liquids or gases.***



TC20 must be in the specified temperature range -20 ° C ~ 55 ° C when used and stored.

## 6.2 Outlook of TC20 Controller

**Power on:** Press and hold the power button for 3 seconds

**Power off:** Press and hold the power button for 3 seconds, select 'power off' in the menu option.



Figure 6.1 Four sides of TC20 controller

**Menu Key:** Select to show the available menu in current screen.

**Home Key:** Return to home screen. To view recent application, press and hold the home key.

**Back Key:** Return to previous screen.

**Volume Key:** Adjust the volume of the ringtone.

**Reset Key:** Shut down the phone when the device is abnormal.

**Camera key:** Short press to enter camera in home screen. Long press it to open torch.

## 6.3 Accessories of TC20 Controller

TC20 Lithium Battery (3.7V/6500mAh)



Figure 6.1 TC20 Lithium battery

TC20 Charger Adapter (5V/1A) with one USB port



Figure 6.2 TC20 Charger Adapter




Figure 6.3 TC20 Charger Adapter Plugs

A: American, B: British, C: Chinese, E: European, N: Australian

Put the plug in in the back of the adapter to assemble the TC20 Charger.

The hand strap below is for easy handling of TC20 controller.



Figure 6.4 TC20 Controller hand strap

The stylus pen below is for easy touch of screen on TC20 controller.



Figure 6.5 Stylus Pen for TC20

The mini USB cable below is to charge TC20 controller or transfer files between TC20 controller and a computer.



Figure 6.6 Mini USB cable

## 6.4 General Operations

### 6.4.1 Insert SIM card and Micro SD card

1. **Remove the back cover:** Loosen the screws on the back side - to rotate the screws anti-clockwise until open the back cover as shown in Figure 6.8.



Figure 6.7 Remove the back cover

2. **Take off the back cover:** Remove the back cover by lifting it up from the bottom part as shown in Figure 6.9 and take out the battery.



Figure 6.8 Take off the back cover

3. **Put the SIM Card in the holder:** Put the SIM card into the slot touching the SIM contacts of the phone as shown in Figure 6.10.



Figure 6.9 Put the SIM card in the holder

4. **Insert Micro SD card:** Open Micro SD card holder and insert Micro SD card into the slot, then close Micro SD card holder as shown in Figure 6.11.




Figure 6.10 Insert Micro SD card

5. **Insert the back cover:** Insert the back cover and rotate screws clockwise to lock the back cover as shown in Figure 6.12.





Figure 6.11 Insert the back cover

***Note: Please power off the phone before plug in or pull out the SIM card.***

#### 6.4.2 Micro SD card

1. Connect USB, turn on USB storage.

It automatically pops up USB connected interface after connecting USB, and then click [Transfer Files] to turn on USB storage to use the files in the Micro-SD card.




Figure 6.12 Select USB function

### 6.4.3 Using of Touch Screen

**Single Click:** To select an icon. For example, click dial to open the keypad which will be displayed on the screen.

**Double Click:** To zoom-in or zoom-out. For example, to zoom-in or out of a photo, click twice when viewing a photo or browsing on the internet.

**Hold:** Click and hold the screen, icon or input box to get more operation options.

- 1) Long-Time Click a picture in the gallery list interface, the status bar prompts to select a picture, you select to share or delete.
- 2) Long-Time Click the blanks of home screen to add home screen shortcut.
- 3) Long-Time Click the blanks of home screen wallpaper sources can be selected.

**Drag the screen:** You can drag the screen to view more applications which are not displayed in one screen.

**Stylus Pen:** you can use stylus pen for the touch screen after turning on the function via Settings -> Accessibility -> Handwriting Pen.

## 7. Technical Appendix

### 7.1 Issues and Solutions

#### Issues about David GNSS Receiver

##### **1. Bluetooth / USB cannot be connected with David.**

Solutions:

- (1) Check if other devices have connected to Bluetooth (COMM1-Bluetooth module only supports Android phones);
- (2) Check if the Bluetooth model matches the David GNSS receiver, the David-R model matches the BT420R model of Bluetooth module, and the David model matches the BT420A model of Bluetooth module;
- (3) Check if the David GNSS receiver is powered on normally. If the receiver's LED is bright but cannot search for the Bluetooth name, please delete the matched Bluetooth in the phone and search again. If you still cannot find the Bluetooth device name, please contact the supplier for assistance;
- (4) Reconnect USB and allow USB device to connect when USB cannot be connected;
- (5) If the radio base station mode is used, check the power supply. At this time, only the 12V battery can be used for power supply. Do not use 5V power bank for power supply.

##### **2. David GNSS receiver cannot be located.**

Solutions:

- (1) Check if the GNSS antenna is properly connected;
- (2) Check if the GNSS antenna cable and connector are intact or damaged.
- (3) Ensure that the GNSS antenna is placed in an open outdoor environment;
- (4) Check if David's LED light is in normal startup state.

##### **3. The rover with 2W radio kit cannot obtain a fixed solution.**

Solutions:

- (1) Check if the radio 'T/R' LED is in the receiving state with blue light. If it is not in the

receiving state, press and hold the 'CHAN' and 'PWR' buttons for about 1 second to switch to the receiving state.

(2) Check whether the number of channels and the transmission protocol of the rover are consistent with that of the base radio;

(3) Check whether the baud rate of the serial port of the 2W radio and the base radio is normal. The baud rate of the serial port of the 2W radio and the 30W radio is 38400bps, and the baud rate of the serial port of the 1W radio is 115200bps.

#### **4. The rover network mode cannot obtain a fixed solution.**

Solutions:

(1) Check if the network of the rover is normal, and whether the controller (an android device) can connect to the network normally;

(2) Check if the rover's user name and password are correct, pay attention to case sensitivity, and there is no '@' character at the beginning of the rover's password;

(3) Check if the rover's MountPoint is consistent with that of the base. It is recommended to use the default base serial number as MountPoint;

(4) Check if the base has sent corrections data normally.

#### **5. The base radio constantly restarts.**

Solutions:

(1) In the base radio mode, only 12V battery can be used for power supply, and 5V power bank cannot be used for power supply;

(2) Check if the battery is low power or insufficient voltage.

#### **6. The local coordinate deviation of the rover is large.**

Solutions:

(1) Check if the coordinate system of the project in Nuwa application is configured correctly;

(2) If site calibration or parameter calculation is not performed, the base needs to be configured by manual start, and the known point coordinates of the base configuration

should be consistent with the known point of the actual installation;

(3) If site calibration or parameter calculation is performed, check whether the coordinate of the control point is incorrectly entered, whether the coordinate deviation of the control point and the distribution of the control point is uniform, and whether the scale is close to 1 in the parameter calculation result.

## **7. It prompts that the coordinate deviation is large when configuring base.**

Solutions:

- (1) If the input is WGS84 coordinates, check whether the input coordinates are the same point, and the coordinate difference cannot be greater than 30m;
- (2) If the input is local coordinates, check whether the configured coordinate system is consistent with the coordinates that need to be input.

## **8. The time for the rover to get a fixed solution is too long.**

Solutions:

- (1) Check the number of satellites for the rover, the satellite distribution (whether the occlusion is serious), and the satellite signal-to-noise ratio (whether the maximum signal-to-noise ratio is greater than 50);
- (2) Check if the antenna connection is loose;
- (3) Check whether the correction data of the base is normal, and whether it includes correction data of GPS, GLONASS, and BeiDou systems.

## **Issues about Oscar / Luka GNSS Receiver**

### **1. The receiver cannot search satellite signals.**

Solutions:

- (1) Change test environment, restart the receiver in an open space;
- (2) Reset the Oscar GNSS module by holding the FN button and pressing the power button five times.

## **2. The internal radio cannot transmit data**

Solutions:

- (1) Check whether the receiver can search satellite signals normally;
- (2) Check whether the whip antenna is properly installed;
- (3) Check whether the radio protocol and channel are configured correctly and are consistent with that of rover.

## **3. Cannot log in CORS**

Solution:

Check whether the 4G SIM card is installed and used normally.

## **4. Nuwa cannot connect with Oscar / Luka**

Solutions:

- (1) Check whether the receiver is powered on;
- (2) Re-search and pair Bluetooth;
- (3) Update Nuwa to the latest version.

## **5. There is no correction data when the receiver as a rover and using Ntrip network**

Solutions:

- (1) Check whether IP address, port, user name and password are correct;
- (2) Check network connection, try to compare with PDA network and ensure SIM card contacts with card slot properly;
- (3) Obtain source table to check receiver network, make sure there is no abnormal of CORS service;
- (4) If there is an extra receiver, try logging into the same configurations and make comparisons;
- (5) If you still cannot log in, consult your CORS service provider.

## **6. How to export static observation data?**

Solutions:

- (1) Connect receiver with a computer through a mini USB cable.
- (2) The computer detects the receiver as an external disk.
- (3) Open the Record folder, find the trs file and Rinex file in its storage according to recording date.
- (4) Copy the static observation data and paste them to the designated folder in your computer.

## **7. How to calibrate the E-Bubble of receiver?**

Solutions:

- (1) Firstly, install the receiver on the tribrach of a tripod. Adjust the tribrach to enable the bubble to the center.
- (2) Next step, select <Adjust> in the Nuwa under Device Info -> E-Bubble to complete the calibration.

## **8. How to apply Geoid model file correctly?**

Solutions:

- (1) Prepare the Geoid file at first and placed in the path of Internal storage\TersusSurvey\Geoid.
- (2) Next step, launch Nuwa and go to select Project - Current Project and edit Coordinate System. Find the Height Fitting-Adjust Method and select Geoid.
- (3) Last, select the file under Geoid List and apply it.

## **9. How to configure serial port output NMEA log?**

Solutions:

There are two ways to realize the NMEA sentences output which you'd like to.

- (1) Nuwa can configure to output NMEA by the NMEA option. It can be specified the Baud Rate, the kind of sentence.
- (2) Variable bonus, it can be directly configured on the panel. NMEA can be turned on

through Device Info -> Serial.

**10. A base receiver is working well, the rover receiver cannot get correction data,  
how to fix this?**

Solutions:

- (1) Check whether the radio antenna connects well with receiver. Carefully check whether the interface is tightened.
- (2) Check whether the air baud rate, Protocol, Bandwidth, Frequency match right with that of the base receiver.
- (3) Switchover the radio frequency to avoid the possible interference from nearby devices.

**11. The rover works at a short distance (not normal distance) at the radio mode?**

Solutions:

- (1) Check whether the rover connects a radio antenna.
- (2) Adjust the radio of base at the high power gear.
- (3) Check the environment if there exists radio interference along the propagation line.



## 8. Terminology

Abbreviation	Definition
CNR	Carrier Noise Ratio
CRS	Coordinate System
GNSS	Global Navigation Satellite System
HDOP	Horizontal Dilution of Precision
HRMS	Horizontal Root Mean Square
OS	Operating System
PDA	Personal Digital Assistant
PDOP	Position Dilution of Precision
RINEX	Receiver Independent Exchange format
RMS	Root Mean Squares
RTCM	Radio Technical Commission for Maritime Services
RTK	Real-Time Kinematic
SNR	Signal Noise Ratio
UI	User Interface
UTC	Coordinated Universal Time
UTM Projection	Universal Transverse Mercator Projection
VDOP	Vertical Dilution of Precision
VRMS	Vertical Root Mean Square

## 9. File Format

[.apk]: android app installation file

[.csd]: coordinate system file

[.csv]: excel file

[.dat]: data file

[.dxf]: CAD data file developed by Autodesk

[.ggf]: Geoid file

[.kml]: landmark file developed by Google

[.lnb]: line file

[.shp]: shape file developed by ESRI

[.txt]: text file

**Proprietary Notice**

All Information in this document is subject to change without notice and does not reflect the commitment on Tersus GNSS Inc. No part of this manual may be reproduced or transmitted by all means without authorization of Tersus GNSS Inc. The software described in this document must be used in terms of the agreement. Any modification without permission from Tersus GNSS Inc. is not allowed.