

Tersus GNSS BX316D kit

Base & Rover kit with 2W radio

Base & Rover Basic

2 x BX316D RTK receiver	2 x 2pin power cable	2 x 20pin external cable	2 x USB Type A to USB Mini cable
2 x UART to USB converter	3 x AX4E02 GNSS antenna	3 x TNC-J to SMA cable 3m (GNSS antenna cable)	1 x carrying case

Base & Rover 2W Radio Option

2x 2W/410-470MHz radio	2x 2W/410-470MHz radio antenna	1x Bullet-DC to Alligator Clips
1x USB to 2pin BX316D power + 2W-Radio-power and COM cable	1x Bullet-DC to 2pin BX316D power + 2W-Radio-power and COM cable	