

Nuwa Version (2.3.0.0) Release

December 9, 2021

Overview

Tersus GNSS Inc. ("Tersus") is glad to release the Nuwa for GNSS receiver. Nuwa version (2.3.0.0) is available to download at www.tersus-gnss.com/software/david-receiver and support documents are available at www.tersus-gnss.com/document/software.

Features

- Assists with Bluetooth/USB connection
- Configure base/rover setup
- Visualized interface for receiver operations
- Data management (import/export)

Change from Previous Versions

Issue	Type	Version
Added the function of taking a photo in survey confirmation box.	Enhancement	
Added the function of offset in line stakeout.	Enhancement	
Added the function of displaying the list of the nodes after selecting the line in CAD stakeout.	Enhancement	
Added the configuration of static IP in WIFI configuration when connecting to Oscar.	Enhancement	
Added the function of TCP push in NMEA output when connecting to Oscar.	Enhancement	
Added the display of correction data format when connecting to Oscar.	Enhancement	
Added South Africa HTML export format.	Enhancement	
Added the option of whether to export height value when exporting DXF file.	Enhancement	2.3.0.0
Added x-y-h and y-x-h coordinate display type.	Enhancement	
Added Denmark predefined coordinate system	Enhancement	
Added Qatar predefined coordinate system.	Enhancement	
Added Slovak predefined coordinate system.	Enhancement	
Added support for gsb format Plan Grid files.	Enhancement	
Optimized the log records.	Bug Fix	
Optimized the calculation of plane grid and geoid, added offset value check.	Bug Fix	
Optimized the survey database storage logic.	Bug Fix	
Fixed the issue that DD:MM:SS in exporting csv files may not show correctly in excel.	Bug Fix	
Optimized the application of RTCM1021-1027.	Bug Fix	

Untimized the display of Russian language Rus F		
Optimized the display of Russian language. Bug F	-IX	
Added the function of importing data between		
the point lists of Survey Point, Control Point or Enhance	ncement	
Staking Point.		
Added the function of saving the coordinates		
of the base to the point list in the manually Enhan	ncement	
base mode.		
Optimized the display of icons and texts in		
Survey interface.	ncement	
Optimized the interaction of code input and		
displayed the code list in the survey Enhan	ncement	
confirmation box.		
Added the configuration of Auto Center during		
survey in the Survey Config.	ncement	
Added the option of closing and non-closing		
when complete the line work in survey.	ncement	2.2.9.0
Added the function to stake the nearest point		
in the Point Stakeout module.	ncement	
Added the display of dx dy dz to the target in		
staking confirmation box, using different colors Enha	ncement	
according to whether exceed the tolerence.		
Added the configuration of Auto zoom during		
stakeout in the Survey Config.	ncement	
Added the calculation and display of the		
Remain miles in the Line Stakeout and Road Enha	ncement	
Stakeout.		
Added the data export of cross-section in Road		
Stakeout.	ncement	
Added the configuration for Auto in Cutoff Enha	ncement	

Angle setting when connecting to Oscar.		
Added Wifi Setting when connecting to Oscar.	Enhancement	
Added Lock device setting when connecting to		
Oscar.	Enhancement	
Added the reminder of Oscar expiration time.	Enhancement	
Added Malaysia predefined coordinate system.	Enhancement	
Added Romania predefined coordinate system.	Enhancement	
Added Finland predefined coordinate system.	Enhancement	
Added Salvador predefined coordinate system.	Enhancement	
Modified the Column Header is checked by		
default in Export, and displayed the column	Enhancement	
header according to language setting.		
Added the function of Oscar firmware version	Enhancement	
check.	Ennancement	
Added the selection of control point survey	Enhancement	
type.	Ennancement	
Added PPK auto survey.	Enhancement	
Optimized the interaction of point selection in	Falanana	
Point Stakeout.	Enhancement	
Optimized the interaction of file opening in	Ful- and and	
CAD Stakeout.	Enhancement	2.2.8.0
Optimized the rules of point selection rules in		
Earthwork.	Enhancement	
Optimized the saving logic of points in	Enhancement	
Parameters and Point correction.	Enhancement	
Added the Encode selection in Import.	Enhancement	
Optimized the solution of RTCM1021-1027	Enhancement	
parameters.	Enhancement	
Added Polish display.	Enhancement	

Updated Vietnamese display.	Enhancement	
Fixed the problem that points import in BLH format may fail.	Bug Fix	
Fixed the problem that preview function in Import may fail.	Bug Fix	
Fixed the problem that importing illegal grid files may cause a crash.	Bug Fix	
Fixed the problem that antenna type may fail to read when connecting to David.	Bug Fix	
Fixed the problem of point name deleting in the text survey interface.	Bug Fix	
Fixed the problem that the stakeout indication may be offset when the map rotation opening.	Bug Fix	
Fixed the problem that the data may not be refreshed in Line Stakeout.	Bug Fix	
Fixed the problem that closing layers may not be successful in CAD Stakeout.	Bug Fix	
Fixed the problem that setting antenna height may not be successful in Static Survey.	Bug Fix	
Added predefined coordinate system of South Africa, Peru, Oman, Libya.	Enhancement	
Added the function of setting the repeat count after each RTK Reset, and the saving of each result in the control point survey mode.	Enhancement	2270
Increased the maximum number of code characters to 30.	Enhancement	2.2.7.0
Allowed swithing staking point by directly click it on the map when staking points.	Enhancement	
Increased the function of cross-section	Enhancement	

stakeout in the road stakeout module.		
Optimized the logic of road stakeout by		
interval and by nearest in the road stakeout	Enhancement	
module.		
Increased the search function when selecting		
points in Parameters Calculation, Point	Enhancement	
correction and Base Shift.		
Added the map view when selecting the point		
library in COGO and other functions.	Enhancement	
Added Points average calculation tool.	Enhancement	
Fixed the problem of new project failure when	D	
selecting some coordinate systems.	Bug Fix	
Fixed the problem of the incorrect stakeout		
prompt when selecting South African	Bug Fix	
coordinate systems.		
Fixed the problem that the default name of		
stake point may not be automatically stepped	Bug Fix	
in the stakeout function.		
Fixed a possible error in the calculation of road	Dug Fiv	
intersection method.	Bug Fix	
Fixed the problem that the stake point will		
incorrectly be added to the point libarary in	Bug Fix	
the area stakeout module.		
Fixed the problem of incomplete display of		
some information in the interface of Bluetooth	Bug Fix	
pairing and location information.		
Added the mouse selection tool, the explode		
tool, the background switching function, and	Enhancement	2.2.6.0
optimized the button display in the CAD		

stakeout module.		
Added the graphical display of the filling and		
cutting instructions in the surface stakeout.	Enhancement	
Added the function of entering the point name		
to select the point when add a stakeout line or	Enhancement	
in COGO.		
Added Oscar host network module status		
display.	Enhancement	
Added Oscar host language setting.	Enhancement	
After selecting the coordinate system when		
creating a new project , added the step of	Enhancement	
confirming the coordinate parameters.		
Added line segmentation tool.	Enhancement	
Added Peru predefined coordinate system and	Enhancement	
added Vietnamese language.	Elmancement	
Solved the problem that the road intersection	Bug Fix	
method may be calculated incorrectly.	Bug I IX	
Solved the problem that the six parameters of		
height parameters fitting may be calculated	Bug Fix	
incorrectly and saved with insufficient	Bug IIX	
accuracy.		
Optimized the QR code of project parameters		
sharing, solved the problem of failure of	Bug Fix	
scanning QR code.		
Optimized the display of Turkish language	Bug Fix	
Added CAD Stakeout module.	Enhancement	
Added Area Stakeout module.	Enhancement	2.2.5.0
Added the function of keeping the base mode after reboot in manual start base.	Enhancement	2.2.3.0

		T
Added the function of keeping coordinates	Enhancement	
after reboot in auto start base.		
Added some customization requirements.	Enhancement	
Fixed the problem that the intersection		
method may be incorrectly calculated and	Bug Fix	
plotted when using some road data.		
Optimized the rule of reading files when	Bug Fix	
importing data.		
Fixed the problem that file sharing through		
wechat and other tools may fail after data	Bug Fix	
export.		
Modified the default projection of CGCS2000,		
BJ54 predefined coordinate system to 3-degree	Bug Fix	
zone.		
Added Israel predefined coordinate system.	Enhancement	
Optimized the text display of DXF base map.	Enhancement	
Added the function of setting unit when	- Cabanaanant	
importing and exporting DXF.	Enhancement	
Increased the import and export of txt format.	Enhancement	
Added survey configuration saving logic.	Enhancement	
Added support for Rinex 3.04 when connecting	Enhancement	
to Oscar.	Linancement	2.2.4.0
Added Stop and Go function when connecting	Enhancement	
to Oscar.	Limancement	
Added the function of clearing disk and the		
function of debug configuration when	Enhancement	
connecting Oscar.		
Solved the problem of startup crash caused by	Bug Fix	
failing to obtain permissions when installing	Dug I IA	

software on some Android 8 and 10 phones	
Software on some Android 8 and 10 phones	
Solved the problem of crash when using some	
functions on some Android 10 and 11 cell Bug	ıg Fix
phones.	
Fixed the problem of detail point survey	
program on the text survey interface.	ıg Fix
Fixed the display issues in the survey program	- Fix
due to the display configuration.	ıg Fix
Fixed the problem that the positioning icon of	
the stakeout interface is shifted under some	ıg Fix
display resolutions, and optimize the display of	ag i iv
release interface and release prompt sound.	
Fixed the problem of incorrect calculation of	
the target point in road stakeout after applying Bug	ıg Fix
base shift.	
Fixed the problem of possible jamming when	ıg Fix
adding antennas.	ag rix
Added building polyline, arc and circle for line	hansoment
stakeout.	hancement
Added funtion of selecting a line for stakeout	
on the DXF base map, optimized function of Enl	hancement
selecting the point for stakeout.	
Added Grid to Ground tool.	hancement
Added road stakeout real-time mileage	2.2.3.0
stakeout, optimized the offset display.	hancement
Added control point survey mode.	hancement
Added Traditional Chinese language option.	hancement
Added Gauss 3-Degree Zone projection.	hancement
Added Columbia Medellin predefined Enl	hancement

coordinate system, France RGF93 Lambert-93		
predefined coordinate system.		
Added support of modifying pole height in	Enhancement	
tilt-on state.	Elliancement	
Fixed the issue that the registration status	D . F:	
displayed for David may be incorrect.	Bug Fix	
Fixed the issue that importing data of ECEF		
coordinates may fail.	Bug Fix	
Added length unit support of US feet.	Enhancement	
When creating a new project, added the	Enhancement	
selection portal of plane grid and geoid.	Emancement	
Added support for Ireland 35 parameter		
conversion model, add Ireland geoid of gri	Enhancement	
format.		
Added support for French geoid of MNT	Enhancement	
format.	Limancement	
Added the predefined coordinate system of	l .	
Philippines.	Enhancement	
During connecting with David, added the		2.2.2.0
function of decoding and applying	Sahaaaaaa	
RTCM1021/1023/1025 when receiving CORS	Enhancement	
data through the controller network.		
Added function of getting the nearest point		
and its mileage on the design road when	Enhancement	
staking a road.		
Optimized the application after unit setting,		
effective for import and export and other	Bug Fix	
functions.		
Optimized the processing of the deviation	Bug Fix	

	T	
between the device positioning and the central		
meridian of the project, it will no longer		
correct the central meridian automatically, but		
ask whether to jump to the project parameters		
interface for manual correct.		
Optimized the interaction of the stakeout		
interface, it automatically obtains 5Hz position	D. o Fin	
data refresh frequency when entering stakeout	Bug Fix	
interface.		
Solved the issue that David may crash when		
connected by USB in the previous version.	Bug Fix	
Added photo taking function after point		
measurement.	Enhancement	
Added QR code sharing function for survey		
point.	Enhancement	
Added display and export of ECEF-XYZ		
coordinate and BLH (Local) coordinate.	Enhancement	
Added NCN format import and export,		
KML/KMZ format import and export.	Enhancement	
Added base station point export.	Enhancement	
Added the display form of ENh coordinate.	Enhancement	2.2.1.0
Added simulation connection function.	Enhancement	
Added the function of registration by scanning		
code.	Enhancement	
Added function of setting satellite system.	Enhancement	
Added Oscar log download function and		
battery change mode setting.	Enhancement	
Added function of automatically connect Oscar		
when starting software.	Enhancement	

Added Oscar internal radio call sign setting function. Added differential delay threshold limit. Added display of 2D/3D error in the whole interface. Added are arrived a sweden predefined coordinate system. Optimized GSF geoid support. Optimized French resources. Fixed the problem that the coordinates are not refreshed in time between start and stop. Added David30 device support. Added Swedish predefined coordinate system. Added notice of installing the radio antenna when starting up the Oscar internal radio base mode. Fixed the display of modulation when setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Enhancement Enhancement Enhancement Bug Fix 2.2.0.0 2.2.0.0 Bug Fix 2.2.1.10.0 Enhancement Enhancement Enhancement Enhancement Bug Fix 2.2.1.10.0 Enhancement Bug Fix			
Added display of 2D/3D error in the whole interface. Added earthwork calculation tool. Added anglular bisector calculation tool. Enhancement Corrected Sweden predefined coordinate system. Optimized GSF geoid support. Optimized French resources. Fixed the problem that the coordinates are not refreshed in time between start and stop. Added David30 device support. Added Swedish predefined coordinate system. Added notice of installing the radio antenna when starting up the Oscar internal radio base mode. Fixed the occasional delay in coordinates mode. Fixed the display of modulation when setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Enhancement Enhancement Enhancement Bug Fix 2.2.0.0 2.1.10.0		Enhancement	
Interface. Added earthwork calculation tool. Added anglular bisector calculation tool. Corrected Sweden predefined coordinate system. Optimized GSF geoid support. Optimized French resources. Fixed the problem that the coordinates are not refreshed in time between start and stop. Added David30 device support. Enhancement Added Swedish predefined coordinate system. Added notice of installing the radio antenna when starting up the Oscar internal radio base refreshing when connecting with Oscar. Updated the display of modulation when setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Enhancement Enhancement Enhancement Bug Fix 2.2.0.0 2.1.10.0	Added differential delay threshold limit.	Enhancement	
Added earthwork calculation tool. Added anglular bisector calculation tool. Corrected Sweden predefined coordinate system. Optimized GSF geoid support. Optimized French resources. Fixed the problem that the coordinates are not refreshed in time between start and stop. Added David30 device support. Enhancement Added Swedish predefined coordinate system. Added notice of installing the radio antenna when starting up the Oscar internal radio base mode. Fixed the occasional delay in coordinates refreshing when connecting with Oscar. Updated the display of modulation when setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Enhancement Enhancement Bug Fix 2.2.0.0 2.1.10.0		Enhancement	
Corrected Sweden predefined coordinate system. Optimized GSF geoid support. Optimized French resources. Fixed the problem that the coordinates are not refreshed in time between start and stop. Added David30 device support. Added Swedish predefined coordinate system. Added notice of installing the radio antenna when starting up the Oscar internal radio base mode. Fixed the occasional delay in coordinates refreshing when connecting with Oscar. Updated the display of modulation when setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Bug Fix 2.2.1.10.0		Enhancement	
System. Optimized GSF geoid support. Dytimized French resources. Fixed the problem that the coordinates are not refreshed in time between start and stop. Added David30 device support. Added Swedish predefined coordinate system. Added notice of installing the radio antenna when starting up the Oscar internal radio base mode. Fixed the occasional delay in coordinates refreshing when connecting with Oscar. Updated the display of modulation when setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Bug Fix 2.2.1.10.0	Added anglular bisector calculation tool.	Enhancement	
Optimized French resources. Fixed the problem that the coordinates are not refreshed in time between start and stop. Added David30 device support. Enhancement Added Swedish predefined coordinate system. Enhancement Added notice of installing the radio antenna when starting up the Oscar internal radio base mode. Fixed the occasional delay in coordinates refreshing when connecting with Oscar. Updated the display of modulation when setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Bug Fix 2.2.0.0 Enhancement 2.1.10.0	·	Bug Fix	
Fixed the problem that the coordinates are not refreshed in time between start and stop. Added David30 device support. Enhancement Added Swedish predefined coordinate system. Added notice of installing the radio antenna when starting up the Oscar internal radio base mode. Fixed the occasional delay in coordinates refreshing when connecting with Oscar. Updated the display of modulation when setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Enhancement Bug Fix 2.2.0.0 Enhancement Bug Fix	Optimized GSF geoid support.	Bug Fix	
refreshed in time between start and stop. Added David30 device support. Enhancement Added Swedish predefined coordinate system. Enhancement Added notice of installing the radio antenna when starting up the Oscar internal radio base mode. Fixed the occasional delay in coordinates refreshing when connecting with Oscar. Updated the display of modulation when setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Bug Fix 2.2.0.0 Enhancement Enhancement 2.1.10.0	Optimized French resources.	Bug Fix	
Added Swedish predefined coordinate system. Added notice of installing the radio antenna when starting up the Oscar internal radio base mode. Fixed the occasional delay in coordinates refreshing when connecting with Oscar. Updated the display of modulation when setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Enhancement Enhancement 2.1.10.0	·	Bug Fix	
Added notice of installing the radio antenna when starting up the Oscar internal radio base mode. Fixed the occasional delay in coordinates refreshing when connecting with Oscar. Updated the display of modulation when setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Enhancement Enhancement 2.1.10.0	Added David30 device support.	Enhancement	
when starting up the Oscar internal radio base mode. Fixed the occasional delay in coordinates refreshing when connecting with Oscar. Updated the display of modulation when setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Enhancement Enhancement 2.1.10.0	Added Swedish predefined coordinate system.	Enhancement	
refreshing when connecting with Oscar. Updated the display of modulation when setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Bug Fix Bug Fix 2.2.0.0 Bug Fix Bug Fix 2.1.10.0	when starting up the Oscar internal radio base	Enhancement	
setting the Oscar internal radio mode. Fixed the issue that getting the central meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Bug Fix Bug Fix Enhancement 2.1.10.0	·	Bug Fix	2.2.0.0
meridian by clicking the button and getting the central meridian automatically when connecting the device are logically different. Added the predefined coordinate system of Tianjin 2000. Bug Fix Enhancement 2.1.10.0		Bug Fix	
Tianjin 2000. Enhancement 2.1.10.0	meridian by clicking the button and getting the central meridian automatically when	Bug Fix	
Added the predefined coordinate system of Enhancement		Enhancement	2.1.10.0
	Added the predefined coordinate system of	Enhancement	

Netherlands RDNAP2008, and support for the ASCII format horizontal grid and vertical grid under this coordinate system. Added the projection parameter setting, the button that the central meridian is automatically obtained according to the current position. Added the function of survey point editing, allowing to modify the point name and antenna information of the measured point. Added the function of checking coordinates via road mileage. Added the display of modulation type and channel bandwidth when connecting to Oscar and using the internal radio. Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, if the vertical point is on the extension line, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and re-enter line stakeout will continue stakeout according to the stake number before exiting.
Added the projection parameter setting, the button that the central meridian is automatically obtained according to the current position. Added the function of survey point editing, allowing to modify the point name and antenna information of the measured point. Added the function of checking coordinates via road mileage. Added the display of modulation type and channel bandwidth when connecting to Oscar and using the internal radio. Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, if the vertical point is on the extension line, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and the re-enter line stakeout will continue stakeout Enhancement Enhancement Enhancement Enhancement Enhancement
Added the projection parameter setting, the button that the central meridian is automatically obtained according to the current position. Added the function of survey point editing, allowing to modify the point name and antenna information of the measured point. Added the function of checking coordinates via road mileage. Added the display of modulation type and channel bandwidth when connecting to Oscar and using the internal radio. Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, added the drawing display of the extension line, added the memory of stake number, and the re-enter line stakeout will continue stakeout Enhancement
button that the central meridian is automatically obtained according to the current position. Added the function of survey point editing, allowing to modify the point name and antenna information of the measured point. Added the function of checking coordinates via road mileage. Added the display of modulation type and channel bandwidth when connecting to Oscar and using the internal radio. Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, added the drawing display of the extension line, added the memory of stake number, and re-enter line stakeout will continue stakeout Enhancement
Added the function of survey point editing, allowing to modify the point name and antenna information of the measured point. Added the function of checking coordinates via a road mileage. Added the display of modulation type and channel bandwidth when connecting to Oscar and using the internal radio. Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, and added the drawing display of the extension line, and added the memory of stake number, and the re-enter line stakeout will continue stakeout Enhancement
Added the function of survey point editing, allowing to modify the point name and antenna information of the measured point. Added the function of checking coordinates via a channel bandwidth when connecting to Oscar and using the internal radio. Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, added the drawing display of the extension line, added the memory of stake number, and the re-enter line stakeout will continue stakeout Enhancement
Added the function of survey point editing, allowing to modify the point name and antenna information of the measured point. Added the function of checking coordinates via road mileage. Added the display of modulation type and channel bandwidth when connecting to Oscar and using the internal radio. Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, and the drawing display of the extension line, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and the re-enter line stakeout will continue stakeout Enhancement Enhancement Enhancement Enhancement Enhancement
Enhancement Added the function of checking coordinates via road mileage. Added the display of modulation type and channel bandwidth when connecting to Oscar and using the internal radio. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, if the vertical point is on the extension line, added the memory of stake number, and added the memory of stake number, and re-enter line stakeout will continue stakeout Enhancement
Added the function of checking coordinates via road mileage. Added the display of modulation type and channel bandwidth when connecting to Oscar and using the internal radio. Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, added the drawing display of the extension line, added the memory of stake number, and added the memory of stake number, and re-enter line stakeout will continue stakeout Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement
Added the function of checking coordinates via road mileage. Added the display of modulation type and channel bandwidth when connecting to Oscar and using the internal radio. Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, added the drawing display of the extension line, added the memory of stake number, and re-enter line stakeout will continue stakeout Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement
Added the display of modulation type and channel bandwidth when connecting to Oscar and using the internal radio. Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and re-enter line stakeout will continue stakeout Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement
Added the display of modulation type and channel bandwidth when connecting to Oscar and using the internal radio. Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, added the drawing display of the extension line, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and re-enter line stakeout will continue stakeout Enhancement Enhancement Enhancement Enhancement Enhancement
channel bandwidth when connecting to Oscar and using the internal radio. Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, added the drawing display of the extension line, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and the re-enter line stakeout will continue stakeout Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement
Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, if the vertical point is on the extension line, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and the re-enter line stakeout will continue stakeout Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement
Added the network link of TCS protocol when connecting with David. Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, added the drawing display of the extension line, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and the re-enter line stakeout will continue stakeout Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement Enhancement
Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, if the vertical point is on the extension line, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and added the memory of stake number, and the re-enter line stakeout will continue stakeout
Added the display of the distance from the previous survey point in the survey interface. Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, if the vertical point is on the extension line, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and re-enter line stakeout will continue stakeout Enhancement Enhancement Enhancement Enhancement
Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and the extension line in the stakeout will continue stakeout.
Added the display of stakeout collection points in the stakeout interface. When staking out the line to the vertical point, if the vertical point is on the extension line, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and re-enter line stakeout will continue stakeout
When staking out the line to the vertical point, if the vertical point is on the extension line, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and re-enter line stakeout will continue stakeout
When staking out the line to the vertical point, of the vertical point is on the extension line, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and re-enter line stakeout will continue stakeout Enhancement Enhancement
If the vertical point is on the extension line, added the drawing display of the extension line. When staking out the line to the stake point, added the memory of stake number, and re-enter line stakeout will continue stakeout
Enhancement Enhancement Enhancement When staking out the line to the stake point, added the memory of stake number, and re-enter line stakeout will continue stakeout
when staking out the line to the stake point, added the memory of stake number, and re-enter line stakeout will continue stakeout
When staking out the line to the stake point, added the memory of stake number, and re-enter line stakeout will continue stakeout
added the memory of stake number, and Enhancement re-enter line stakeout will continue stakeout
re-enter line stakeout will continue stakeout
re-enter line stakeout will continue stakeout
according to the stake number before exiting.

Fixed the problem that the antenna type is empty in the survey configuration after Oscar is connected via NFC when the software is not started.	Bug Fix	
Fixed the problem that it will stuck in the startup for a long time if there is a network problem when starting the PDA Network working mode.	Bug Fix	
Added data editing for cross section, super elevation, and widening of road module and side stakeout function for road stakeout module.	Enhancement	
Added the display of vertical point or stake point mileage during line stakeout.	Enhancement	
Added the distinguishing display of positive and negative offset during line stakeout.	Enhancement	
Added the predefined coordinate system of Xi'an 80.	Enhancement	
Fixed the crash problem after connecting to Oscar, turning on the static recording and quickly starting the rover radio mode.	Bug Fix	2.1.9.0
Fixed the crash problem when importing illegal csv files.	Bug Fix	
Fixed the lagging problem when there are too many points in the Survey interface.	Bug Fix	
Fixed the problem that when the threshold of point stakeout is set too large, clicking the full image to display will lead a crash.	Bug Fix	
Fixed the problem that the software still	Bug Fix	

displays the coordinate and solution status in		
the last second of the search when the satellite		
is not searching suddenly.		
Fixed the problem that the offset may be	Dug Eiv	
calculated incorrectly during the line stakeout.	Bug Fix	
Fixed the problem that the central meridian is	Dug Fiv	
reset to 0 in Spanish mode.	Bug Fix	
Fixed the problem that garbled characters are		
displayed when opening the exported csv file	Bug Fix	
in Office Excel by default in Chinese mode.		
Added support for Stations Equation, Vertical		
Profiles and Start Mileage in the road function,	Enhancement	
and road stakeout performs three-dimensional	Ennancement	
stakeout of center stake.		2100
Added support for export in DXF format whose	Education	2.1.8.0
name or code contains Chinese characters.	Enhancement	
Modified the predefined coordinate system of	Dug Fiv	
Turkey.	Bug Fix	
Road management and road stakeout are		
added to the software. The current version		
supports the editing of Alignment by		
intersection method and element method,	Enhancement	
conversion of intersection method to element	Enhancement	
method, and road stake out function. Other		2.1.7.0
functions will be implemented in subsequent		
versions.		
Added Survey with confirmation button to the		
survey configuration. After turning if off, the	Enhancement	
survey point data will be saved directly without		

confirmation box.		
Added the display of QZSS satellites in the sky map and satellite table.	Enhancement	
Software optimization: retain the user's common configuration habits; SNR is adjusted to CNO; Portuguese pre-defined coordinate system name adjustment.	Enhancement	
Fixed the crash issue of clicking the offset point tool to enter the point library to select the point when the project is not opened.	Bug Fix	
Fixed the crash issue of switching to Turkish to perform point survey.	Bug Fix	
The Chinese version of the software is renamed to "Tianshuo Measurement", and the Chinese display is optimized in the software.	Enhancement	
Added the function of rotating the map view when staking out, check this function in the display config interface of staking out.	Enhancement	
Added the function of importing points to the survey point library from coordinate files; add the function of importing points to the control point library or the stakeout point library from DXF, SHP, SIMA files.	Enhancement	2.1.6.0
Added the L value negative input and calculation in the offset point from line tool.	Enhancement	
Optimized Bulgarian display.	Enhancement	
Fixed the problem that the software automatic calculates the UTM number incorrectly when it is located in the Western Hemisphere.	Bug Fix	

	1	
Fixed the problem that mtext is not displayed	Bug Fix	
when importing some DXF basemaps.		
Fixed the problem that prompy might not be		
correct when selecting forward and backward	Bug Fix	
stakeout prompt type.		
Fixed the problem that when the tilt function is		
turned on, the rover mode is stopped and the	Bug Fix	
coordinates are no longer refreshed.		
Support DXF import as the base map, and add		
function of selecting points on the DXF base	Enhancement	
map to the staking point library.		
Add the export of the collected line when	Enhancement	
exporting DXF.	Emiancement	
Support SIMA format import with empty		
elevation data, add the encoding setting when	Enhancement	
selecting SIMA import and export, to avoid the	Enhancement	
situation of garble code.		
When connecting with Oscar, it can be chosen		
to shut down the Oscar receiver at the same	Enhancement	2.1.5.0
time when exiting Nuwa app.		
When configuring David at base mode, add the	Enhancement	
'save config' statement.	Linancement	
When performing point stakeout and line		
stakeout, add the search function for staking	Enhancement	
point and staking line.		
Add the checkbox 'Display All Staking Point' in		
the display config of the point stakeout	Enhancement	
interface.		
Adjust part of the statement display for	Enhancement	

English, Chinese, Japanese, and Greek.		
Add predefined Mexican coordinate system.	Enhancement	
Solve the crash of selecting empty project as		
the source project if there is no project in the	Bug Fix	
арр.		
Added Bulgarian displayed.	Enhancement	
Added Irish pre-defined coordinate systems.	Enhancement	
Fixed the problem of low success rate of David		
connection.	Bug Fix	
Fixed a crash of the tilt enable button when		
connecting with Oscar Ultimate, if the Android	Bug Fix	
phones do not support GIF view.		2440
Fixed the problem that when connecting Oscar		2.1.4.0
Ultimate and turning on the tilt enable, and	D . 5	
then switching to connect David, the tilt	Bug Fix	
button was still on.		
Fixed the crash of clicking the confirm button		
on ths soft keyboard on TC20 after modifying	Bug Fix	
the point name in stakeout.		
Added tilting initialization instructions,		
optimize tilting interaction, and add tilting	Established	
initialization, measurement and lofting	Enhancement	
instructions in user manual.		
Added Malaysia RSO projection.	Enhancement	2120
Added Offset Point From Line in the Offset		2.1.3.0
Point tool, to determine the Point on the	Enhancement	
extension Line or the Point after Offset on the	Emidicement	
extension Line.		
Added the elevation difference, slope ratio and	Enhancement	
	·	

so on the calculation results in the Azimuth		
Distance tool.		
Added the Greek display in Nuwa.	Enhancement	
Added Slovenia predefined coordinate system.	Enhancement	
Added Morocco predefined coordinate system.	Enhancement	
Added Belgium predefined coordinate system.	Enhancement	
Added Netherlands predefined coordinate system.	Enhancement	
Added Guatemala predefined coordinate system.	Enhancement	
Added Columbia predefined coordinate system.	Enhancement	
Added Austria predefined coordinate system.	Enhancement	
Solved the problem that when connecting with David, the parameters of compass could not be read, and the stakeout indicating arrow was invalid.	Bug Fix	
Solved the problem that the DXF file exported by Nuwa may can't be imported into autocad.	Bug Fix	
Solved the problem that coordinates may not be refreshed after tilt off.	Bug Fix	
Fixed the problem of parameter calculation or point correction, in which the error details of each pair of points cannot be seen.	Bug Fix	
Optimized Japanese display.	Bug Fix	
Optimized Spanish display.	Bug Fix	
The input control is optimized. A one-click clear button is added to the input box. The latitude and longitude input box supports	Enhancement	2.1.0.9

intelligent input and real-time format		
switching.		
Added CGCS2000 predefined default coordinate system.	Enhancement	
In the connection interface the Bluetooth name and MAC address display in newline.	Enhancement	
When connecting Oscar receiver and setting		
the base station mode, added CMR and RTD differential formats.	Enhancement	
When connecting Oscar receiver and setting static, added configuration record duration, and add recorded duration display.	Enhancement	
When connecting Oscar receiver and setting		
the built-in network base station mode, added	Enhancement	
Ntrip protocol support.		
When connecting Oscar receiver, added NMEA serial output configuration.	Enhancement	
, ,		
When connecting Oscar receiver, added disk usage display and remaining capacity display.	Enhancement	
Added heading display when connected to David plus.	Enhancement	
Adjusted the size of the point name on the Survey interface.	Enhancement	
Added SHP basemap import function.	Enhancement	
Added satellite map display on the online map		
of Survey interface.	Enhancement	
Added the function of stakeout to the vertical	Enhancement	
point on the line for Line stakeout.		
Modified the point type of the collection point	Enhancement	

Fix Fix	
Fix	
Fix	
Fix	
Fix	
Fix	
ancement	
ancement	
ancement	
2.1.0.8 ancement	
ancement	
	Fix Fix ancement ancement ancement 2.1.0.8

Redo the line stakeout function. Stakeout to the point on the line according to the interval and the offset.	Enhancement	
Added the report file function in detail point survey, turn on the function and the coordinate of every epoch will be saved into a .txt file.	Enhancement	
Added the display of L5 SNR.	Enhancement	
Added button to cancel the display of electronic bubble.	Enhancement	
Added the stakeout pointing arrow text description.	Enhancement	
Solved the crash problem when opening the Survey interface on some phones with higher display resolution.	Bug Fix	
The height value in the location share function is calculated to the coordinates of ground points according to the antenna settings in Nuwa.	Bug Fix	
Added Molodensky Badekas datum transform model.	Enhancement	
Added Singapore predifined coordinate system SVY21.	Enhancement	
Added Australia predifined coordinate system GDA2020.	Enhancement	2.1.0.6
Optimized the Survey interface, the survey button will change automatically and the survey configuration will change according to the selection of Survey Mode(Detail or	Enhancement	

Continous).	
Optimized the Survey Config interface, the	
HRMS limited value and VRMS limited value	Enhancement
will change according to the Solution Limited.	
Display optimization of the Survey Config	
interface. The Config in the Survey and the	
Stakeout function module only displays	Enhancement
relevant items; all configuration items are	
retained in the Survey Config.	
Adjusted the longitude and latitude	
coordinates display, put N, S, E, W after the	Enhancement
number.	
Opened to use TCS through PDA Network in	Enhancement
Oscar base configuration.	Emancement
Added the function of Oscar registration by	Enhancement
Nuwa.	Emancement
Added the limit to 5 survey points when	
connecting to general instruments of NMEA	Enhancement
mode.	
Corrected some translation errors in English	Bug Fix
language.	
Solved the problem that sometimes the	
number of satellites used is larger than the	Bug Fix
number of visible satellites.	
Solved the problem of software exception if	Bug Fix
click Device Info during NFC connection.	
Solved the problem of Nuwa software crash	
when connecting Oscar via NFC, if Nuwa is not	Bug Fix
provided system permission.	

Solved the problem in XML export that the solution state of all survey points are fixed. Solved the problem when repeated using the baseshift, the value of Base shift and the actual coordinate shift are not the same. Solved the problem that the survey points in the Survey interface may not be displayed when the Survey Style is Detail. Solved the problem that the point cannot be selected to stakeout when importing NE points to the Stakeout point library. Solved the problem of Nuwa crash for some android 9.0 models. Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including inablity to perform software automatic update			
Solved the problem when repeated using the baseshift, the value of Base shift and the actual coordinate shift are not the same. Solved the problem that the survey points in the Survey interface may not be displayed when the Survey Style is Detail. Solved the problem that the point cannot be selected to stakeout when importing NE points to the Stakeout point library. Solved the problem of Nuwa crash for some android 9.0 models. Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Bug Fix 2.1.0.5 Bug Fix	Solved the problem in XML export that the	Rug Fiv	
baseshift, the value of Base shift and the actual coordinate shift are not the same. Solved the problem that the survey points in the Survey interface may not be displayed when the Survey Style is Detail. Solved the problem that the point cannot be selected to stakeout when importing NE points to the Stakeout point library. Solved the problem of Nuwa crash for some android 9.0 models. Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change, including Bug Fix 2.1.0.5 Bug Fix	solution state of all survey points are fixed.	Bug I IA	
coordinate shift are not the same. Solved the problem that the survey points in the Survey interface may not be displayed when the Survey Style is Detail. Solved the problem that the point cannot be selected to stakeout when importing NE points to the Stakeout point library. Solved the problem of Nuwa crash for some android 9.0 models. Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change, including Bug Fix 2.1.0.5 Bug Fix	Solved the problem when repeated using the		
Solved the problem that the survey points in the Survey interface may not be displayed when the Survey Style is Detail. Solved the problem that the point cannot be selected to stakeout when importing NE points to the Stakeout point library. Solved the problem of Nuwa crash for some android 9.0 models. Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Bug Fix 2.1.0.5 Bug Fix	baseshift, the value of Base shift and the actual	Bug Fix	
the Survey interface may not be displayed when the Survey Style is Detail. Solved the problem that the point cannot be selected to stakeout when importing NE points to the Stakeout point library. Solved the problem of Nuwa crash for some android 9.0 models. Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	coordinate shift are not the same.		
when the Survey Style is Detail. Solved the problem that the point cannot be selected to stakeout when importing NE points to the Stakeout point library. Solved the problem of Nuwa crash for some android 9.0 models. Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	Solved the problem that the survey points in		
Solved the problem that the point cannot be selected to stakeout when importing NE points to the Stakeout point library. Solved the problem of Nuwa crash for some android 9.0 models. Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	the Survey interface may not be displayed	Bug Fix	
selected to stakeout when importing NE points to the Stakeout point library. Solved the problem of Nuwa crash for some android 9.0 models. Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	when the Survey Style is Detail.		
to the Stakeout point library. Solved the problem of Nuwa crash for some android 9.0 models. Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	Solved the problem that the point cannot be		
Solved the problem of Nuwa crash for some android 9.0 models. Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Bug Fix 2.1.0.5 Bug Fix	selected to stakeout when importing NE points	Bug Fix	
android 9.0 models. Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	to the Stakeout point library.		
android 9.0 models. Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	Solved the problem of Nuwa crash for some	Due Fiv	
direction quality and Heading quality in tilt measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including Bug Fix 2.1.0.5	android 9.0 models.	Bug Fix	
measurement. Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	Adjusted the display of Tilt Angle quality, Tilt		
Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	direction quality and Heading quality in tilt	Bug Fix	
Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	measurement.		
avoided by calculating according to the XYZ coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including Bug Fix 2.1.0.5	Adjusted the algorithm for calculating the		
coordinate in the case of projection unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	Distance to base, the incorrect result can be		
unselected. Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	avoided by calculating according to the XYZ	Bug Fix	
Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	coordinate in the case of projection		
prompt distance(long) from 5s to 2s at a time. Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including Bug Fix 2.1.0.5	unselected.		
Fixed the crash when connecting devices using Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including	Changed the tone frequency of stakeout	Dug Fiv	
Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including Bug Fix 2.1.0.5	prompt distance(long) from 5s to 2s at a time.	bug rix	
Android 9 caused by the API level change. Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including 2.1.0.5	Fixed the crash when connecting devices using	Pug Eiv	
obtain HTTP permissions using Android 9 caused by the API level change, including	Android 9 caused by the API level change.	bug rix	
obtain HTTP permissions using Android 9 caused by the API level change, including	Fixed the problems that Nuwa is unable to		2105
caused by the API level change, including	obtain HTTP permissions using Android 9	Rug Fiv	2.1.0.3
inablity to perform software automatic update	caused by the API level change, including	Dug I IX	
	inablity to perform software automatic update		

and online map display.		
Added moving direction indicator arrow in stakeout interface.	Enhancement	
Added the circle display whose radius is equal to the prompt tone distance in stakeout	Enhancement	
interface.		
The prompt tone in different grades in stakeout interface. When the surveyor is approaching to the point to stake out, Nuwa beeps every 5 seconds. When the surveyor arrives at the point to stake out, Nuwa beeps every 1 second.	Enhancement	
Added the XML format export which supports being imported to EZSurv to post process Stop&Go data.	Enhancement	
Adjusted DXF export, add height coordinate and height annotation. Distinguish layers according to different kinds of annotations and point feature property.	Enhancement	2.1.0.3
Added GNSS Linework function. The survey line will be displayed in survey interface. The survey line allows operations such as delete point, insert point, and continue surveying.	Enhancement	
Change the API level to 28 and re-launch on Google Play.	Bug Fix	
Fixed the issue that the point coordinate saved to the Point database may be wrong in the case of the Base Shift.	Bug Fix	
Fixed incomplete import Stakeout Point	Bug Fix	

	I	
selecting all from Survey Point.		
Fixed the crash issue when turning on location	Bug Fix	
share function for some android devices.		
Tilt compensation function is available for	Falancia	
Oscar Ultimate model.	Enhancement	
Added elevation stakeout for point stakeout		
and line stakeout.	Enhancement	
Opened the TCP Client function for the		
receiver network.	Enhancement	
Solved the problem that conversion from NEh		
to BLH may be incorrect when there are seven	Bug Fix	
parameters.		
Solved the problem that selecting the		
coordinate system from the Coord System List	Due Fiv	
is not effective when editing the project	Bug Fix	
parameters.		2046
Solved the crash problem caused by the name		2.0.1.6
containing illegal characters when creating a	Bug Fix	
new project.		
After setting the latitude and longitude format		
to DD:MM.MMM, the number of decimal	Bug Fix	
places is changed to 7 digits.		
Solved the problem that the link and		
differential delay are not displayed on the	B . 5	
survey interface when Oscar is set as the	Bug Fix	
receiver network rover mode.		
Solved the problem that the debug button in		
the device info interface sometimes is opened	Bug Fix	
illegally when switching from connecting David		
L	1	

to connecting Oscar.		
Corrected the English expression of the		
altitude and geodetic height on the survey	Bug Fix	
interface.		
Corrected the English expression of long press		
to cancel the Bluetooth match on the	Bug Fix	
connection interface.		
The display of base point coordinates is		
changed to ground when base antenna height	Enhancement	
is obtained.		
The display of north / east direction STD is		
added to the survey point attribute which is	Enhancement	
allowed to be exported.		
During the point survey process, it is allowed	Enhancement	2.0.1.4
to stop the survey by pressing the stop button.	Limancement	2.0.1.4
Fixed the issue that after configuring David by		
Nuwa to stop the base mode, restarting David	Bug Fix	
it still displays as Base.		
Fixed the probabilistic crash issue of returning		
to the main interface after completing the	Bug Fix	
point staking.		
Open Oscar Reset function	Enhancement	
The Collection End time of points in the point		
library will change with the software time zone	Enhancement	
setting		2.0.1.2
The project list is arranged in reverse	Enhancement	2.0.1.2
chronological order by edit time	Limancement	
Fixed crash caused by choosing an empty	Bug Fix	
coordinate system	242.14	

Fixed the probabilistic crash in NFC connection	Bug Fix	
Fixed the probabilistic crash of setting Ntrip server after Oscar connection	Bug Fix	
Fixed failure of setting up TCPClient in connecting David	Bug Fix	
Solved the problem that modifying antenna parameters does not take effect after the survey of smooth points is completed	Bug Fix	
Solved the problem that Base points would not increase after reaching 9	Bug Fix	
Fixed HTML export crash when there are stakepoints	Bug Fix	
Solved the problem that the export Collection End time property has no hour, minute, or second, when the separator is a space in custom export	Bug Fix	
Solved the problem that the searched results for the point library based on time is empty	Bug Fix	
Fix the severe problem that modification of Ant Height is not effective in the Survey Config	Bug Fix	2.0.0.9
Supports new model Oscar	Enhancement	
Added display of base shift, datum transition, plane adjustment and height fitting in the interface of Satellite Info - Position	Enhancement	
For data import, it supports data preview before importing data	Enhancement	2.0.0.8
For data export, it added HTML export	Enhancement	
Custom import and export format support editing, viewing and deleting	Enhancement	

Added related tips in the Bluetooth pairing and device connection interface	Enhancement	
The base supports RTCM3.0 format	Enhancement	
The logic of Detailed Point acquisition is		
modified to pop up confirmation dialogue after	Enhancement	
the acquisition is completed		
Added threshold distance setting for stakeout	Enhancement	
tone		
In the survey configuration - Display		
configuration interface, added the check box of	Enhancement	
displaying all stake out points		
Solve the flashback problem of Nuwa in landscape orientation display	Bug Fix	
Unify NEh coordinates and RMS data, retain 4		
decimal places	Bug Fix	
Solve the application crash caused by the	D	
special registration date in the Demo Key	Bug Fix	
Solve the problem of incomplete display of	Bug Fix	
part of the Spanish interfaces	Bug 1 ix	
Solve the problem that the seven parameters		
and the correction parameters are not	Bug Fix	
imported into the project parameters in the	Bugin	
newly created project		
Solve the problem of search failure according	Bug Fix	
to time in point library search		
Solve the problem that exporting the custom	Bug Fix	
interface cannot slide		
Solve the problem that in the survey interface	Bug Fix	
the speed is not refreshed		

Adjust default antenna	Bug Fix	
Added Japanese JGD2011 coordinate system	Enhancement	1.0.9.7
Optimized the stakeout prompt message	Enhancement	
Fixed the problem of wrong name for the Portugal coordinate system	Bug Fix	
Fixed the problem of inaccurate acquisition time during the point collection	Bug Fix	
Optimized the SHP export coordinate format	Enhancement	
Optimized online upgrade information prompts	Enhancement	
Optimized Tools Offset Point calculation	Enhancement	1005
Optimized Tools Azimuth and Intersection Angle calculation	Enhancement	1.0.9.5
Optimized OSM online map loading	Enhancement	
Optimized the seven parameters calculation	Enhancement	
Optimized Survey Config options	Enhancement	
Optimized the function of adding stakeout points and control points	Enhancement	
Added Ghana's predefined coordinate system	Enhancement	
Added Portuguese predefined coordinate system	Enhancement	
Optimized static storage	Enhancement	
Optimized elevation fitting calculation	Enhancement	
Fixed elevation problems caused by geoid model during data inverse calculation	Bug Fix	1.0.8.0
Fixed the flashback issue caused in certain situations	Bug Fix	
Optimize DXF export	Enhancement	
Fixed the problem that the default is the	Bug Fix	

control point library when importing points for		
stakeout point library		
Fixed the problem that the interface has no		
prompt when the stakeout point is	Bug Fix	
approaching the stakeout point library		
Support collecting points with physical	Falancia	
collection button in TC20 controller	Enhancement	
Support quick points collecting in 'point		
stakeout' and 'line stakeout' with physical	Enhancement	
collection button		
Add 'survey hotkey' in point survey	Enhancement	1.0.4.1
configuration page	Elmancement	
Fix average collection problem if the solution	Bug Fix	
can't meet the requirements	Bug I IX	
Change the display of coordinate axis in	Enhancement	
projection parameters as X->North Y->East	Emancement	
Optimized the calculation of parameters and		
the secondary calculation process of point	Enhancement	
correction		
Optimized the device connection experience	Enhancement	
Optimized the device registration experience	Enhancement	1.0.3.3
Optimized antenna management	Enhancement	1.0.3.3
In the survey configuration, the survey epoch	Enhancement	
is changed to be editable by users	Emaneement	
Added Oscar preview in Device Connection, so	Enhancement	
stay tuned!!		
Added support for common NMEA devices	Enhancement	
Added the function of automatically zooming	Enhancement	1.0.3.2
the scale when approaching the stakeout point		

Added multi-point selection function when importing stakeout points Solved the connection stability of NtripClient function under Spanish and other languages Added the functions of Device Debug and static mutual exclusion Fixed the display problem when NtripClient and TCPClient are connected Modified the GNSS point coordinates displayed in the base shift as BLH Optimized static record Station ID setting function Fixed crash when switching languages in Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Fixed the error of multiple repetitive Bug Fix Bug Fix		
Solved the connection stability of NtripClient function under Spanish and other languages Added the functions of Device Debug and static mutual exclusion Fixed the display problem when NtripClient and TCPClient are connected Modified the GNSS point coordinates displayed in the base shift as BLH Optimized static record Station ID setting function Fixed crash when switching languages in Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift	during point stakeout/line stakeout	
importing stakeout points Solved the connection stability of NtripClient function under Spanish and other languages Added the functions of Device Debug and static mutual exclusion Fixed the display problem when NtripClient and TCPClient are connected Modified the GNSS point coordinates displayed in the base shift as BLH Optimized static record Station ID setting function Fixed crash when switching languages in Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Fix the stakeout point error on the map and coordinates error after the base shift	Added multi-point selection function when	Enhancement
Added the functions of Device Debug and static mutual exclusion Fixed the display problem when NtripClient and TCPClient are connected Modified the GNSS point coordinates displayed in the base shift as BLH Optimized static record Station ID setting function Fixed crash when switching languages in Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift	importing stakeout points	Ennancement
function under Spanish and other languages Added the functions of Device Debug and static mutual exclusion Fixed the display problem when NtripClient and TCPClient are connected Modified the GNSS point coordinates displayed in the base shift as BLH Optimized static record Station ID setting function Fixed crash when switching languages in Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Bug Fix Bug Fix	Solved the connection stability of NtripClient	F.1
Fixed the display problem when NtripClient and TCPClient are connected Modified the GNSS point coordinates displayed in the base shift as BLH Optimized static record Station ID setting function Fixed crash when switching languages in Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift	function under Spanish and other languages	Ennancement
Fixed the display problem when NtripClient and TCPClient are connected Modified the GNSS point coordinates displayed in the base shift as BLH Optimized static record Station ID setting function Fixed crash when switching languages in Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift	Added the functions of Device Debug and	Fahanaanaat
and TCPClient are connected Modified the GNSS point coordinates displayed in the base shift as BLH Optimized static record Station ID setting function Fixed crash when switching languages in Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Bug Fix Bug Fix	static mutual exclusion	Ennancement
and TCPClient are connected Modified the GNSS point coordinates displayed in the base shift as BLH Optimized static record Station ID setting function Fixed crash when switching languages in Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Bug Fix Bug Fix	Fixed the display problem when NtripClient	Pug Fiv
in the base shift as BLH Optimized static record Station ID setting function Fixed crash when switching languages in Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift	and TCPClient are connected	bug rix
in the base shift as BLH Optimized static record Station ID setting function Fixed crash when switching languages in Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift	Modified the GNSS point coordinates displayed	Enhancement
function Fixed crash when switching languages in Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift	in the base shift as BLH	Emancement
function Fixed crash when switching languages in Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift	Optimized static record Station ID setting	Enhancement
Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift	function	Limancement
Spanish and other languages Combined the mount point and rover configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift	Fixed crash when switching languages in	Rug Fiv
configuration to solve the problem of the display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift	Spanish and other languages	Bug I IX
display of the mount point history data Fixed the problem that the collection time epoch does not take effect in the survey Bug Fix configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Bug Fix Bug Fix	Combined the mount point and rover	
Fixed the problem that the collection time epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift	configuration to solve the problem of the	Enhancement
epoch does not take effect in the survey configuration Fixed the problem of not displaying NEh coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Bug Fix Bug Fix Bug Fix	display of the mount point history data	
configuration Fixed the problem of not displaying NEh coordinates when manually starting the base Bug Fix station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Bug Fix Bug Fix	Fixed the problem that the collection time	
Fixed the problem of not displaying NEh coordinates when manually starting the base Bug Fix station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Bug Fix	epoch does not take effect in the survey	Bug Fix
coordinates when manually starting the base station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Bug Fix Bug Fix	configuration	
station Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Bug Fix Bug Fix	Fixed the problem of not displaying NEh	
Fixed the problem that the base point cannot be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Bug Fix Bug Fix	coordinates when manually starting the base	Bug Fix
be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Bug Fix Bug Fix	station	
be selected in the base shift Fix the stakeout point error on the map and coordinates error after the base shift Bug Fix	Fixed the problem that the base point cannot	Rug Fiv
coordinates error after the base shift Bug Fix	be selected in the base shift	DUB I IV
coordinates error after the base shift	Fix the stakeout point error on the map and	Bug Fix
Fixed the error of multiple repetitive Bug Fix	coordinates error after the base shift	
	Fixed the error of multiple repetitive	Bug Fix

calculations in the base shift		
Added support for north-south/east-west hemisphere	Enhancement	
Optimize continuous point survey by distance	Enhancement	
Optimize continuous point survey by time	Enhancement	
Add the predefined coordinate systems of Malaysia and Romania	Enhancement	
Add the function of station-id setting during static measurement	Enhancement	
Add the function of Inner RTK control	Enhancement	
Add the function of importing projects	Enhancement	
Add preview function for predefined coordinate system	Enhancement	
Optimize the arrangement and display of countries or regions in the predefined coordinate systems	Enhancement	4000
Optimize the display of satellite quantity	Enhancement	1.0.2.9
Optimize the display of antenna height interface	Enhancement	
'Connected' at the top of the main interface is changed to 'Connected'	Enhancement	
The position status of satellite interface for base station is changed to 'Base Manual' and 'Base Auto'	Enhancement	
Fix the problem of not displaying NEh coordinates when manually starting the base station	Bug Fix	
Add new projections: Cassini, Oblique Stereographic Alternative, Stereographic, and	Enhancement	

Transverse Cylindrical Equal Area		
Fix the problem of imported line files are not identified	Bug Fix	
Fix the problem of crashing when creating new projects and point survey under Spanish language	Bug Fix	
Optimize database upgrade	Enhancement	
Add predefined coordinate system	Enhancement	
Modify the satellite quantity display as 'satellite tracked / satellite used'	Bug Fix	
Optimize the export format of dxf file	Enhancement	
Fix the problem that the elevation increases when manually starting the base station	Bug Fix	
Optimize base shift experience	Enhancement	
Change shp/dxf export coordinates to local coordinates	Enhancement	1.0.2.8
Fix the problem that satellites on the Sat Tab interface has always shown true	Bug Fix	
Add differential data format display when using Ntrip to obtain source list	Enhancement	
Optimize system stability	Enhancement	
System compatibility is improved, compatible with upgrades on older software	Enhancement	
Fixed the problem that the antenna height disappeared in the device connection interface after reloading the software	Bug Fix	100-
Fixed the problem of the invalidity of static survey after canceling auto-start	Bug Fix	1.0.2.6
Fixed the problem of the Ntrip Client set up	Bug Fix	

failure for the rover		
Fixed the problem of the antenna height		
configuration failure for the rover	Bug Fix	
Optimize the software automatic update	Enhancement	
experience	Ennancement	
Optimize the device connections	Enhancement	
Optimize continuous acquisition by time	Enhancement	
Add Geoid Model: (1) support EGM96 and		
EGM08 at the same time; (2) optimize data		
loading and reduce waiting time for different	Enhancement	
devices; (3) simplify algorithm calculation		
process and save system resources		
Add UTM projection support for the southern	Enhancement	
hemisphere	Emiancement	
Optimize the rules for point acquisition	Enhancement	
automatic naming	Elinancement	
Optimize the base shift function: (1) support		
multiple times of base shift; (2) support		
real-time modification of the shift parameters;	Enhancement	
(3) reorganize the base shift logic; (4) redesign		
the base shift UI		
Optimize the solution state of the data export,	Enhancement	
which is the same as the board definition	Limancement	
Optimize the display of the antenna height	Enhancement	
when manual-starting the base station	Liniancement	
Repair of other problems	Enhancement	
Antenna height display optimization	Enhancement	
Survey configuration: display configuration optimization	Enhancement	1.0.2.

Re-enter static storage, status optimization	Enhancement	
Static storage antenna optimization when self-starting the base station	Enhancement	
Line stakeout 'distance' distinguishes between positive and negative	Enhancement	
Add column name for coordinate export	Enhancement	
Remove the 'Acquisition Status' of the 'Text Acquisition' interface	Enhancement	
'Smoothing' and 'Acquisition' are combined	Enhancement	
Ntrip site management: IP address display is incomplete	Bug Fix	
Click base/rover configuration without changing order	Enhancement	
Support for name modification of base/rover configuration User-defined name can be changed, the system default name cannot be changed	Enhancement	
Add reminder when creating a new project	Enhancement	
Change the logic of antenna type choosing, the antenna type must be choosing before connection	Enhancement	
Change the default antenna height as pole height in surveying, change the default antenna height as slant height in static surveying	Enhancement	1.0.2.3
Support choosing file type in import file	Enhancement	
Add GPS mock location	Enhancement	
Fixed the error of configuration when build a new project	Bug Fix	

Optimized the interface freeze if there are too many points in point survey interface	Enhancement	
Optimized the display of export interface	Enhancement	
Optimized the display of the result in two point intersection	Enhancement	
Optimized the display of title bar	Enhancement	
Optimized the option logic in import interface	Enhancement	
Change the voice output frequency in point stakeout	Enhancement	
Add RTCM1230 message in base model	Enhancement	
Fixed software crashed when sharing project	Bug Fix	
Optimized the logic to register David	Enhancement	
Optimized the device connection	Enhancement	
Support auto start static mode	Enhancement	
Add xyz apporoximate in rinex file	Enhancement	
Optimized the speed to log in CORS.	Enhancement	
Add point name and code in dxf format	Enhancement	
Fix the abnormity H value if the antenna slant height is zero	Bug Fix	
Change the 'Projection' to 'CRS'	Enhancement	1.0.2.2
Change the threshold value in collect points by distance	Enhancement	
Optimized auto collect function by distance	Enhancement	
Optimized software access authority (it need		
location information authority at the same time when using Bluetooth if your android version is higher than Android 6.0)	Enhancement	1.0.2.1
Optimized auto update function	Enhancement	
Optimized the display of system language	Enhancement	

Optimized many default value	Enhancement	
Optimized the pop-up message when getting the first fixed solution	Enhancement	
Optimized the language of pop-up messages	Enhancement	
Fixed the display error in height fitting title panel	Bug Fix	
Default to open update auto test function	Enhancement	
Fixed software crash due to the display of decimal point in some language	Bug Fix	
Optimized the display of project information	Enhancement	
Fixed the bug that the QR code can't refresh when project parameters changed	Bug Fix	1.0.2.0
Fixed the title can't be changed with system language changed	Bug Fix	
Fixed numeric keypad have no decimal point problem in some cellphone	Bug Fix	
Fixed the unusual local coordinate value under some ellipsoid	Bug Fix	